

[Manuals.plus](#) /

› [VASAGLE](#) /

› VASAGLE Electric Height Adjustable Sit-Stand Desk, 140 x 60 cm, Rustic Brown (Model LSD314KD03)

VASAGLE LSD314KD03

VASAGLE Electric Height Adjustable Sit-Stand Desk

Model: LSD314KD03 | Dimensions: 140 x 60 cm | Color: Rustic Brown

INTRODUCTION

Thank you for choosing the VASAGLE Electric Height Adjustable Sit-Stand Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new desk. Please read all instructions carefully before use and retain this manual for future reference.

VASAGLE

by SONGMICS HOME



The VASAGLE Electric Height Adjustable Sit-Stand Desk in a modern office environment.

SAFETY INFORMATION

WARNING: This desk is equipped with an electric motor. Please read the instructions carefully before use.

- Do not place objects on the desktop during height adjustment.
- Do not adjust the desk height when objects or people are on the desktop.
- Observe the maximum load capacity of 70 kg.

- Do not force the desktop movements.
- In case of overload or blockage, immediately stop use and contact customer service.
- Keep children and pets away from the desk during operation.
- Ensure all cables are properly routed to prevent pinching or damage.

PACKAGE CONTENTS

Before assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer service.

- 1 x Electric Height Adjustable Desk (Desktop and Frame)
- Assembly Hardware (numbered parts)
- Illustrated Instruction Manual
- 2 x Cable Grommets
- 2 x Hooks

SETUP AND ASSEMBLY

The VASAGLE Electric Height Adjustable Sit-Stand Desk is designed for quick and easy assembly. Follow the illustrated instructions provided in the package. All necessary tools are included, except for a Phillips head screwdriver which may be useful.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble the Tabletop:** If the tabletop comes in multiple sections, connect them as per the instructions.
3. **Assemble the Frame:** Attach the reinforced legs to the main crossbar using the provided hardware.
4. **Attach Tabletop to Frame:** Securely fasten the assembled tabletop to the desk frame.
5. **Install Accessories:** Attach the cable grommets and hooks to their designated positions.
6. **Connect Power:** Plug the power cable into a suitable electrical outlet.



Capacité de charge statique max. :

80 kg



Quelle taille de plateau est faite pour vous ?



Visual guide for the assembly process, showing tabletop, frame, and final attachment.

OPERATING INSTRUCTIONS

Your electric sit-stand desk offers convenient height adjustment and smart features to enhance your work experience.

Height Adjustment:

- Use the **Up** (▲) and **Down** (▼) buttons on the control panel to manually adjust the desk height. The current

height will be displayed on the digital screen.

- The desk can be adjusted from a minimum height of 72 cm to a maximum height of 120 cm.

Memory Presets:

The desk features 4 programmable memory height settings.

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the **M** button (or similar memory set button) followed by one of the numbered preset buttons **1, 2, 3, or 4**). The height is now saved to that preset.
3. To recall a saved height, simply press the corresponding numbered button.

Réglage en hauteur fluide & structure robuste

70 kg

20 000

Testé sur 20 000 cycles de levage

Montée et descente stables



Aucun
vacillement



Légers
tremblements

The desk's height adjustment range (72-120 cm) and the 4-height memory function.

Sedentary Reminder:

The desk includes a sedentary reminder function to encourage alternating between sitting and standing. This feature is often integrated with one of the memory presets (e.g., preset 4). Consult your specific control panel instructions for activation and customization.

Crochets pratiques

- Pour suspendre sacs, écouteurs, etc.



The sedentary reminder feature prompts users to change positions for better health.

Locking Function:

To prevent unintentional height adjustments, especially around children, use the locking function.

- **To Lock:** Press and hold the **Up (▲)** and **Down (▼)** buttons simultaneously for 3 seconds. The display may show "LOC" or a lock icon.
- **To Unlock:** Press and hold the **Up (▲)** and **Down (▼)** buttons simultaneously for 3 seconds again. The display will return to showing the height.



The control panel features a locking function for safety.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your desk.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.

- **Cable Management:** Periodically check that all cables are securely routed through the cable grommets and are not pinched or tangled.
- **Motor Inspection:** Listen for any unusual noises during height adjustment. If you notice any issues, discontinue use and contact support.
- **Weight Distribution:** Ensure weight is evenly distributed on the desktop and does not exceed the maximum load capacity of 70 kg.

TROUBLESHOOTING

If you encounter any issues with your desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk does not move	Power cable disconnected; Locking function active; Overload	Check power connection; Unlock the desk (see Operating Instructions); Reduce weight on desktop.
Uneven height adjustment	Obstruction; Uneven weight distribution	Check for obstructions under the desk; Redistribute weight evenly.
Motor noise is excessive	Normal operation; Internal issue	Some motor noise is normal. If unusually loud or grinding, discontinue use and contact support.
Memory presets not working	Not properly saved	Re-save the desired height to the memory preset (see Operating Instructions).

If the problem persists after attempting these solutions, please contact VASAGLE customer support.

SPECIFICATIONS

Feature	Detail
Brand	VASAGLE
Model Number	LSD314KD03
Desk Design	Sit-Stand Desk
Product Dimensions (D x W x H)	60 x 140 x 120 cm
Color	Rustic Brown
Top Material Type	Particleboard
Frame Material	Alloy Steel
Minimum Height	72 cm
Maximum Height	120 cm

Feature	Detail
Item Weight	20 Kilograms
Recommended Maximum Load	70 Kilograms
Special Features	Adjustable, 4 Height Memory, Sedentary Reminder, Locking Function, Cable Grommets, Hooks
Assembly Required	Yes
Country of Origin	China
UPC	194343464794

WARRANTY AND SUPPORT

Your VASAGLE Electric Height Adjustable Sit-Stand Desk comes with a limited warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official VASAGLE website.

For technical support, troubleshooting assistance, or to report missing/damaged parts, please contact VASAGLE customer service. Contact information can typically be found on the product packaging or the official brand website. When contacting support, please have your model number (LSD314KD03) and proof of purchase readily available.