

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Gamtimer](#) /

› [Gamtimer Gaming Chair G10 Instruction Manual](#)

Gamtimer G10

Gamtimer Gaming Chair G10 Instruction Manual

Model: G10

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Gamtimer Gaming Chair G10. Please read this manual thoroughly before assembly and use to ensure proper function and safety.

IMPORTANT SAFETY INFORMATION

- Always assemble the chair according to the provided instructions.
- Do not exceed the maximum weight capacity of 400 lbs (181 kg).
- Be cautious when adjusting the chair's position to prevent any sudden movements that could cause injury.
- Keep the chair away from heat sources to prevent damage to the material.
- Ensure all screws and bolts are securely tightened before use and periodically check for looseness.

COMPONENTS OVERVIEW

Your Gamtimer Gaming Chair G10 package includes the following main components:

- Seat Cushion
- Backrest
- Headrest Pillow
- Lumbar Support Pillow
- Armrests (2)
- Chair Base with Casters
- Gas Lift Cylinder
- Mechanism Plate (for seat adjustments)
- Footrest Assembly
- Assembly Hardware (screws, washers, Allen wrench)

PRODUCT DETAILS



Figure 1: Overview of chair components including headrest, lumbar support, and footrest.

SETUP AND ASSEMBLY

Follow these steps to assemble your Gamtimer Gaming Chair G10. It is recommended to have a clear, flat workspace.

Step 1: Assemble the Chair Base

1. Insert the five casters into the holes at the end of each leg of the chair base. Push firmly until they click into place.
2. Insert the gas lift cylinder into the central hole of the assembled chair base. Place the telescopic cover over the gas lift.

Step 2: Attach the Mechanism Plate to the Seat Cushion

3. Place the seat cushion upside down on a soft, clean surface to prevent damage.
4. Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Ensure the "FRONT" arrow on the mechanism plate points towards the front of the seat.

5. Secure the mechanism plate using the four provided screws and the Allen wrench. Tighten all screws evenly.

Step 3: Attach the Armrests

6. Attach each armrest to the sides of the seat cushion using the designated screws. Ensure the armrests are oriented correctly (left and right).
7. Tighten all screws securely.

Step 4: Attach the Backrest to the Seat Cushion

8. Align the backrest with the metal brackets on the sides of the seat cushion.
9. Insert the screws through the holes and tighten them with the Allen wrench.

Step 5: Attach the Footrest

10. Slide the footrest assembly into the designated slots under the seat cushion.
11. Secure it with the provided fasteners, ensuring it can extend and retract smoothly.

Step 6: Connect the Seat Assembly to the Gas Lift

12. Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the central hole of the mechanism plate aligns with the top of the gas lift.
13. Press down firmly to secure the connection.

ADJUSTABLE BACKREST

FIND A MOST COMFORTABLE POSITION TO RELAX YOURSELF



Figure 2: The fully assembled Gamtimer Gaming Chair, ready for use.

OPERATING INSTRUCTIONS

Height Adjustment

To adjust the chair's height, pull the lever located on the right side of the seat upwards. While holding the lever, either stand up to raise the chair or remain seated and apply pressure to lower it. Release the lever to lock the height.

Backrest Recline

The backrest can be reclined between 90° and 150°. To recline, pull the lever on the left side of the seat upwards and lean back to your desired angle. Release the lever to lock the backrest in position.

Footrest Operation

To use the footrest, pull it out from underneath the seat. The padded section will flip up, providing support for your legs. To retract, push the padded section down and slide the footrest back under the seat.

Lumbar and Headrest Support

The headrest and lumbar support pillows are adjustable. You can slide them up or down along the backrest straps to find the most comfortable position for your neck and lower back.



Figure 3: The ergonomic design provides support for neck, shoulders, back, and lumbar regions.

MAINTENANCE

- **Cleaning:** For PU leather surfaces, wipe with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Casters:** Periodically check casters for hair or debris and clean as needed to ensure smooth rolling.
- **Fasteners:** Regularly inspect all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability and safety.
- **General Care:** Avoid exposing the chair to direct sunlight for prolonged periods to prevent material degradation.

TROUBLESHOOTING

- **Chair does not adjust height:** Ensure the gas lift lever is fully engaged and the gas lift cylinder is correctly seated in the base and mechanism plate.
- **Chair wobbles:** Check all assembly screws and bolts, especially those connecting the mechanism plate to the seat and the backrest to the seat. Tighten any loose fasteners.
- **Casters do not roll smoothly:** Inspect casters for trapped debris (hair, lint) and remove. Ensure they are securely inserted into the chair base.
- **Footrest is stiff:** Check for any obstructions in the sliding mechanism. Apply a small amount of silicone lubricant if necessary.

SPECIFICATIONS

Feature	Detail
Brand	Gamtimer
Model Name	G10
Color	Grey
Product Dimensions	21"D x 21"W x 52"H
Maximum Weight Capacity	400 lbs
Material	PU Leather, Sponge Fill
Back Style	High Back (90°-150° Recline)
Special Features	Adjustable Headrest, Lumbar Support, Retractable Footrest, 360° Swivel
Item Weight	42 pounds

PRODUCT DIMENSION



HEIGHT	RECOMMENDED	MAX LOAD
	47-83in	85in
WEIGHT	RECOMMENDED	MAX LOAD
	88-265lbs	400lbs

Figure 4: Detailed product dimensions.

WARRANTY AND SUPPORT

Gamtimer offers a one-month free replacement policy and a one-year parts warranty for your peace of mind. For any questions, concerns, or support needs, please contact our professional customer service team, available 24/7. Contact information for customer service can typically be found on the product packaging or the official Gamtimer website.