

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [DUMOS](#) /
- › [DUMOS 42-Inch Electric Fireplace Heater User Manual - Model BLQ0142IN](#)

## DUMOS BLQ0142IN

# DUMOS 42-Inch Electric Fireplace Heater

MODEL: BLQ0142IN

Brand: DUMOS

[Introduction](#)   [Safety Information](#)   [Package Contents](#)   [Setup](#)   [Operating Instructions](#)   [Maintenance](#)  
[Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. INTRODUCTION

Thank you for purchasing the DUMOS 42-Inch Electric Fireplace Heater. This manual provides essential information for the safe operation, installation, and maintenance of your new electric fireplace. Please read it thoroughly before use and retain it for future reference.

This electric fireplace offers versatile heating and ambiance with its 1500W/750W heat settings, 13 adjustable flame colors, 13 carbon bed colors, and a 12-hour timer. It can be installed as a recessed, wall-mounted, or freestanding unit, providing flexibility for various living spaces.



Front view of the DUMOS 42-Inch Electric Fireplace Heater.

## 2. SAFETY INFORMATION

**WARNING: To reduce the risk of fire, electric shock, or injury, read all instructions before using this appliance.**

- Always plug the heater directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- To disconnect heater, turn controls to off, then remove plug from outlet.

- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

### 3. PACKAGE CONTENTS

---

Before beginning assembly, ensure all parts are present and accounted for. If any parts are missing or damaged, do not attempt to assemble or operate the fireplace. Contact customer support for assistance.

- Electric Fireplace Unit
- Remote Control
- Base Legs (for freestanding installation)
- Grate (decorative)
- Log Holder (decorative)
- Decorative Crystals
- User Manual

### 4. SETUP

---

#### 4.1 Installation Methods

Your DUMOS electric fireplace offers three installation options:

1. **Recessed:** The unit can be built into a wall for a flush, integrated look. Ensure proper framing and ventilation clearances are maintained.
2. **Wall-Mounted:** The fireplace can be securely mounted directly onto a wall surface.
3. **Freestanding:** Attach the included base legs to the bottom of the unit for a portable, floor-standing setup.

# Enjoy Comfort & Silent Warmth

Five types of flame brightness & speed



1-12H Timer



Low noise

Illustration of the three available installation methods: Recessed, Wall-Mounted, and Freestanding with feet.

## 4.2 Decorative Media Installation

To install the decorative crystals and logs:

1. Carefully remove the front glass panel of the fireplace.
2. Distribute the decorative crystals evenly across the ember bed.
3. Arrange the decorative logs on top of the crystals as desired.
4. Reattach the front glass panel securely.

Your browser does not support the video tag.

Video demonstrating the DUMOS electric fireplace, including setup and operation.

## 5. OPERATING INSTRUCTIONS

The fireplace can be controlled using the included remote control or the touch screen panel on the unit.

### 5.1 Remote Control Functions

# Enjoy Whole Room Heating



Overview of the remote control and touch screen interface.

- **POWER:** Turns the unit On/Off.
- **HEATER:** Activates or deactivates the heating function. Cycles between 750W (Low) and 1500W (High) heat settings.
- **BRIGHTNESS (DIMMER):** Adjusts the brightness of the flame effect (6 levels).
- **FLAME:** Changes the flame color (13 options).
- **CARBON BED:** Changes the carbon bed color (13 options).
- **SPEED:** Adjusts the speed of the flame effect (5 settings).
- **TEMP +/-:** Adjusts the thermostat temperature from 59°F to 95°F (15°C to 35°C).
- **TIMER:** Sets the automatic shut-off timer from 1 to 12 hours.
- **LOCK (Child Lock):** Engages or disengages the child lock feature to prevent accidental changes.
- **SLEEP MODE:** Activates slow flames and dim light for relaxation.
- **RECREATION MODE:** Activates fast flames, bright light, and dynamic flame colors for lively gatherings.

## 5.2 Touch Screen Controls

The touch screen panel on the fireplace unit provides access to most functions available on the remote control,

including power, heat, flame color, carbon bed color, brightness, speed, temperature, and timer settings.

### 5.3 Flame and Carbon Bed Colors

The fireplace offers 13 distinct flame colors and 13 carbon bed colors, allowing for 169 unique color combinations. A color cycle mode is also available, changing colors every 3 seconds for dynamic ambiance.



Visual representation of the 13 flame colors and 13 carbon bed colors.

### 5.4 Heating Function

The heater provides 5100 BTU of heat output, with flexible 750W (low) and 1500W (high) heating modes. The temperature can be adjusted from 59°F to 95°F (15°C to 35°C).



The fireplace offers comfort and silent warmth with adjustable flame brightness and speed, along with a 1-12 hour timer.

## 6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your electric fireplace.

- **Cleaning:** Always unplug the fireplace before cleaning. Use a soft, damp cloth to wipe down the exterior surfaces. Do not use abrasive cleaners or sprays.
- **Glass Panel:** Clean the glass panel with a soft cloth and glass cleaner. Do not scratch the surface.
- **Air Vents:** Keep the air intake and exhaust vents clear of dust and debris to ensure proper airflow and prevent overheating. Use a vacuum cleaner with a brush attachment to gently clean the vents.
- **Storage:** If storing the fireplace for an extended period, unplug it and store it in a dry, dust-free location.

## 7. TROUBLESHOOTING

If you experience issues with your electric fireplace, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Fireplace does not turn on.	Not plugged in, power outlet issue, main power switch off.	Ensure the unit is securely plugged into a working outlet. Check the main power switch on the unit. Test the outlet with another appliance.
No heat output.	Heater function not activated, thermostat set too low, overheating protection activated.	Activate the heater function using the remote or touch panel. Increase the thermostat setting. Unplug the unit for 15 minutes to reset the overheating protection.
Remote control not working.	Dead batteries, remote not aimed correctly, signal obstruction.	Replace batteries in the remote. Ensure there are no obstructions between the remote and the fireplace sensor. Aim the remote directly at the unit.
Flame effect not visible or flickering.	Brightness set too low, motor issue.	Increase the flame brightness setting. If the issue persists, contact customer support.

If the problem persists after attempting these solutions, please contact DUMOS customer support.

## 8. SPECIFICATIONS

Feature	Detail
Brand	DUMOS
Model Name	DUMOS 42" Freestanding Electric Fireplace
Item Model Number	BLQ0142IN
ASIN	B0FSRGLNRF
UPC/GTIN	753747462098
Power Source	Corded Electric
Product Dimensions	4"D x 42"W x 18.11"H (10.16 cm D x 106.68 cm W x 46 cm H)
Item Weight	43 pounds (19.5 kg)
Finish Type	Polished
Installation Type	Wall Mount, Recessed, Freestanding
Heat Output	1500 Watts (5100 BTU)
Heating Coverage	Up to 510 sq ft

Feature	Detail
Special Features	Adjustable Flame, Flame Effect, Multicolor Flame, Timer, Touch Screen, Remote Control, Sleep Mode, Recreation Mode, Child Lock
Color	Inky
Ventilation Type	Vent Free
Included Components	Remote Control, Base Legs, Grate, Log Holder

## 9. WARRANTY & SUPPORT

---

### 9.1 Warranty Information

This DUMOS electric fireplace comes with a Limited Warranty. Please refer to the warranty card included in your package for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

### 9.2 Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact DUMOS customer support through the retailer where the product was purchased or visit the official DUMOS website for contact information.