

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TOKSOM](#) /

› [TOKSOM 47.2-inch Walnut Lift-Top Coffee Table Model 7772 User Manual](#)

TOKSOM 7772

TOKSOM 47.2-inch Walnut Lift-Top Coffee Table Model 7772 User Manual

Model: 7772 | Brand: TOKSOM

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your TOKSOM 47.2-inch Walnut Lift-Top Coffee Table, Model 7772. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The TOKSOM 47.2-inch Walnut Lift-Top Coffee Table, showcasing its modern design and fluted details.

SAFETY INFORMATION

- Always follow assembly instructions carefully. Incorrect assembly can lead to instability and injury.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as needed.
- Do not exceed the recommended weight limits for the tabletop or storage compartments. Excessive weight can cause damage or collapse.
- Keep hands and fingers clear of the lift-top mechanism during operation to prevent pinching.
- This product is designed for indoor use only.
- Keep small parts away from children during assembly.

SETUP AND ASSEMBLY

Assembly is required for this coffee table. It is recommended that two adults perform the assembly to ensure safety and

ease of construction. Please ensure all parts are present before beginning.

Unpacking and Component Identification

1. Carefully unpack all components from the packaging.
2. Lay out all parts on a clean, soft surface to prevent scratches.
3. Refer to the included hardware list and diagrams to identify each component. If any parts are missing or damaged, contact customer support immediately.

Assembly Steps

Follow the step-by-step instructions provided in the separate assembly guide included with your product. Pay close attention to the orientation of each piece and the type of hardware used for each connection.



Image: The TOKSOM coffee table in a living room setting, illustrating its assembled form. This image represents the final product after successful assembly.

OPERATING INSTRUCTIONS

Lift-Top Mechanism

The coffee table features a pneumatic lift-top mechanism for smooth and quiet operation. To raise the tabletop, gently pull the front edge of the tabletop upwards. The mechanism will assist in lifting it to a comfortable height for working, dining, or other activities. To lower, gently push the tabletop down until it rests in its original position. Ensure no objects are

obstructing the mechanism during movement.



Image: The coffee table with its lift-top raised, showcasing the hidden storage compartment and the extended surface for use.



Image: A close-up view of the metal lift mechanism, highlighting its sturdy construction and smooth operation.

Storage Drawers and Hidden Compartment

The table includes two side storage drawers and a large hidden compartment beneath the lift-top. These areas are designed to store various items such as blankets, books, laptops, and remote controls, helping to keep your living space organized.



Image: A close-up of one of the side storage drawers, showing its capacity and smooth gliding mechanism.

Product Video

Your browser does not support the video tag.

Video: This short video demonstrates the smooth operation of the lift-top mechanism and highlights the table's storage capabilities.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the walnut finish. The surface is designed to be scratch-resistant and waterproof, but immediate cleanup of spills is recommended.
- **Protection:** Use coasters under drinks and placemats under hot items to protect the tabletop from heat and moisture rings.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary to maintain stability.
- **Environment:** Avoid placing the table in direct sunlight or near heat sources, which can cause the wood to fade or warp.




Image: Water droplets on the table surface, demonstrating its water-resistant properties for easy cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lift-top mechanism is stiff or noisy.	Lack of lubrication; mechanism obstruction; loose hardware.	Apply a silicone-based lubricant to moving parts. Check for any objects blocking the mechanism. Ensure all screws are tight.
Drawers do not slide smoothly.	Misaligned drawer slides; debris in tracks; loose hardware.	Check that drawer slides are correctly installed and aligned. Clean tracks of any debris. Tighten all screws on drawer slides.
Table feels wobbly or unstable.	Loose assembly hardware; uneven floor.	Re-tighten all assembly screws. Ensure the table is on a level surface; use furniture pads if necessary.
Missing parts during assembly.	Packaging error.	Contact TOKSOM customer support with your product model number and a description of the missing parts.

SPECIFICATIONS

Brand:	TOKSOM
Model Number:	7772
Product Dimensions (D x W x H):	22.04"D x 47.2"W x 17.71"H
Item Weight:	75 Pounds
Frame Material:	Engineered Wood
Color:	Walnut
Number of Drawers:	2
Assembly Required:	Yes
Indoor/Outdoor Usage:	Indoor




Image: Detailed diagram showing the dimensions of the TOKSOM 47.2-inch Walnut Lift-Top Coffee Table.

WARRANTY INFORMATION

For specific warranty details, please refer to the warranty card included with your product or contact TOKSOM customer support. Warranty coverage typically includes defects in materials and workmanship under normal use.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact TOKSOM customer support. Have your model number (7772) and purchase information ready for faster service.

TOKSOM Customer Service: [Visit the TOKSOM Store on Amazon](#)

