

Homiflex B0FPCZ1NJH

Homiflex Kitchen Island with Storage and LED Light

MODEL: B0FPCZ1NJH

User Manual

[Introduction](#)

[Safety](#)

[Contents](#)

[Assembly](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

1. Introduction

Thank you for choosing the Homiflex Kitchen Island with Storage and LED Light. This versatile furniture piece is designed to enhance your kitchen or dining area with its functional storage, mobile design, integrated power hub, and customizable LED lighting. This manual provides essential information for safe assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your product.



Image 1.1: The Homiflex Kitchen Island with Storage and LED Light, showcasing its design and functionality in a kitchen environment.

2. General Safety Information

Please read and understand all safety warnings before assembly and use.

- Do not exceed the weight capacity of 141.81 lbs (64.32 kg) on the countertop or shelves.
- Use caution when moving the island on uneven surfaces to prevent tipping.
- Be careful around sharp edges during assembly to avoid injury.
- Ensure all parts are properly secured and tightened before using the island.
- Do not allow children to play on, with, or around the cart.
- Keep electrical components (power outlets, LED lights) away from water and moisture.

3. Package Contents

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Kitchen Island Frame and Panels
- Storage Cabinet Doors (with glass inserts)
- Adjustable Shelves
- LED Lighting Kit
- 4 Universal Wheels (2 lockable)
- Integrated Power Outlet Unit (2 AC outlets, 2 USB ports)
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Instruction Manual

4. Assembly Instructions

The Homiflex Kitchen Island is designed for straightforward assembly. Please follow the detailed, illustrated instructions provided in the separate assembly guide included with your package. Assembly typically takes approximately 60 minutes with two people.

1. Unpack all components and verify against the package contents list.
2. Identify all parts, which are clearly labeled.
3. Follow the step-by-step diagrams and written instructions in the assembly manual.
4. Ensure all fasteners are securely tightened upon completion.

Note: For best results and safety, it is recommended to have two adults for assembly.

5. Operating Instructions

5.1 Mobile Functionality

The kitchen island is equipped with four smooth-rolling universal wheels, allowing for easy repositioning within your space. Two of these wheels are lockable to secure the island in place when needed.

- To move the island: Unlock the two lockable wheels by flipping their levers. Gently push the island to your desired location.
- To secure the island: Once in position, engage the locks on the two lockable wheels by flipping their levers back.



Image 5.1: Detail of the universal wheels, highlighting their 360-degree rotation for flexible movement.

5.2 RGB Illuminated Dining Experience

The integrated RGB LED lighting along the oversized tabletop allows you to customize the ambiance of your kitchen island. Use the included remote control (if applicable) to select various colors and lighting modes.

- Connect the LED light power adapter to a standard electrical outlet.
- Use the remote control to turn the lights on/off, change colors, adjust brightness, and select dynamic lighting effects.



Image 5.2: The kitchen island with its internal LED lighting set to different colors, demonstrating the customizable illumination.

5.3 Smart Charging & Power Hub

The integrated power station provides convenient access to electricity for small appliances and charging devices.

- Plug the island's main power cord into a standard wall outlet.
- Use the two AC outlets for kitchen appliances such as blenders, toasters, or coffee makers.
- Utilize the two high-speed USB ports to charge smartphones, tablets, or other USB-powered devices.



Image 5.3: A detailed view of the power outlets and USB ports, showing a device being charged.

5.4 Adjustable Mega-Storage Capacity

The island features an extra-deep cabinet with adjustable shelving to accommodate various kitchen items, from large appliances to pantry goods.

- To adjust shelves: Remove all items from the shelf. Carefully lift the shelf and reposition the shelf pins to the desired height. Ensure the shelf is level and securely seated on all four pins before placing items back.
- The spacious cabinet helps keep utensils, pots, cookbooks, and small appliances organized and out of sight.



Image 5.4: The multi-layer storage cabinet with its doors open, demonstrating its capacity for various kitchen items.

5.5 Product Video Overview

Your browser does not support the video tag.

Video 5.5: An official product video from Homiflex showcasing the features and functionality of the kitchen island, including its storage, LED lighting, and power outlets.

6. Maintenance

Regular maintenance will help preserve the appearance and functionality of your Homiflex Kitchen Island.

- **Cleaning the Surface:** Wipe the engineered wood and countertop surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the finish.
- **Glass Care:** Clean glass cabinet doors with a standard glass cleaner and a soft cloth.
- **Electrical Components:** Ensure the power outlets and LED lights are kept dry. Do not attempt to clean them with liquids while plugged in.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.
- **Wheels:** Keep the wheels free of debris to ensure smooth movement.

7. Troubleshooting

If you encounter any issues with your kitchen island, refer to the following common solutions:

Problem	Possible Cause	Solution
LED lights not working	Power adapter unplugged; remote control battery dead; loose connection.	Ensure power adapter is securely plugged in. Replace remote control battery. Check all LED strip connections.
Power outlets/USB ports not working	Island's main power cord unplugged; circuit breaker tripped.	Verify the island's main power cord is fully inserted into a wall outlet. Check your home's circuit breaker.
Island is unstable or wobbly	Loose fasteners; uneven floor.	Retighten all assembly screws and bolts. Ensure the island is on a level surface; use shims if necessary.
Wheels not rolling smoothly	Wheels locked; debris caught in wheels.	Unlock the wheels. Clear any hair or debris from the wheel casters.

8. Specifications

Detailed product specifications for the Homiflex Kitchen Island (Model B0FPCZ1NJH).

Feature	Detail
Product Dimensions (D x W x H)	27.6" x 55.12" x 31.5" (70cm x 140cm x 80cm)
Material	Engineered Wood
Frame Material	Engineered Wood
Color	Walnut
Item Weight	98.3 Pounds (44.59 kg)
Weight Capacity	141.81 lbs (64.32 kg)
Number of Shelves	3
Included Components	Storage Cabinet, LED Lights, 4 Wheels, Power Outlet Unit
Required Assembly	Yes

PRODUCT SIZE




Image 8.1: Product dimensions diagram, illustrating the overall size and key measurements of the kitchen island.

9. Warranty and Support

Homiflex is committed to providing quality products. For any warranty claims, missing parts, or technical support, please contact Homiflex customer service directly. Refer to your purchase documentation for specific warranty terms and contact information.

You can typically find support contact details on the Homiflex official website or through the retailer where you purchased the product.