

## Roroom TSZH6806

# Roroom DIY Book Nook Kit (TSZH6806) Instruction Manual

Model: TSZH6806

## INTRODUCTION

---

This instruction manual provides comprehensive guidance for the assembly, operation, and maintenance of your Roroom DIY Book Nook Kit, model TSZH6806. This kit is designed for individuals aged 14 and above, offering an engaging and creative building experience. Please read all instructions carefully before beginning assembly.

## SETUP AND ASSEMBLY

---

The Roroom DIY Book Nook Kit is not a pre-assembled product. It requires careful assembly of various components to create the miniature scene. A detailed color manual is included to guide you through each step.

### Required Materials (Not Included)

- Silicone liquid glue
- 2 x AAA batteries (for LED lighting)

### Assembly Steps

1. **Unpack Components:** Carefully unbox all parts and verify against the included parts list in your color manual.
2. **Familiarize Yourself:** Review the color manual to understand the overall structure and sequence of assembly.
3. **Prepare Parts:** Gently detach wooden pieces from their frames. Use fine sandpaper if necessary to smooth any rough edges.
4. **Follow Manual Instructions:** Assemble the components step-by-step as indicated in the color

manual. Pay close attention to part numbers and orientation.

5. **Apply Glue:** Use silicone liquid glue sparingly to secure parts. Allow adequate drying time between steps.
6. **Install LED Lighting:** Follow the manual's instructions for wiring and installing the LED lights. Ensure connections are secure before inserting batteries.
7. **Add Decorative Elements:** Once the main structure is complete, add the miniature furniture, plants, and other decorative items.
8. **Attach Dust Cover:** Secure the dust cover as the final step to protect your finished book nook.



**Figure 1:** The book nook with its side panel open, illustrating the removable locomotive and detailed interior components. This feature allows for easy access and rearrangement of elements.

## OPERATING INSTRUCTIONS

---

### LED Lighting

The Roroom DIY Book Nook Kit includes an LED lighting system to illuminate your miniature scene. To operate the lights:

1. Ensure 2 AAA batteries are correctly installed in the designated battery compartment, observing polarity.
2. Locate the power switch, typically found on the back or bottom of the book nook.
3. Toggle the switch to the 'ON' position to activate the LED lights.
4. Toggle the switch to the 'OFF' position when not in use to conserve battery life.

## MAINTENANCE

---

Proper care will ensure the longevity and appearance of your Roroom DIY Book Nook Kit.

- **Cleaning:** Use a soft, dry cloth or a small brush to gently remove dust from the components. Avoid using liquid cleaners directly on the wooden or paper parts.
- **Dust Cover:** Keep the dust cover in place when the book nook is not being actively viewed or handled to protect it from dust and environmental elements.
- **Storage:** Store the book nook in a dry environment, away from direct sunlight and extreme temperatures, which can cause materials to warp or fade.
- **Battery Replacement:** Replace AAA batteries when the LED lights dim or cease to function. Ensure proper disposal of old batteries.

## TROUBLESHOOTING

---

### Common Issues and Solutions

- **Missing Parts:** If you find any parts missing upon unboxing, please contact Roroom customer support via Amazon for assistance.
- **LED Lights Not Working:**
  - Check if the AAA batteries are correctly inserted with the correct polarity.
  - Ensure the batteries are fresh and not depleted.
  - Verify all wiring connections are secure and not loose or damaged.
  - Confirm the power switch is in the 'ON' position.
- **Parts Not Fitting:**
  - Double-check the part numbers and refer to the color manual to ensure you are using the correct pieces for the step.
  - Ensure the orientation of the parts is correct.
  - Apply gentle, even pressure. Avoid forcing parts, which can cause damage.

## SPECIFICATIONS

---

# EXQUISITE DETAILS



Figure 2: Key product information and specifications for the Roroom DIY Book Nook Kit.

<b>Model Number</b>	TSZH6806
<b>Finished Size (L x W x H)</b>	10.8 x 7.4 x 4.3 inches (27.5 x 19 x 11 cm)
<b>Material</b>	Wood, Paper, Plastic
<b>Suitable Age</b>	14+ years old
<b>Estimated Completion Time</b>	2-3 days
<b>Difficulty Level</b>	Medium (3 out of 5 stars)
<b>Included Components</b>	All furniture, Dust cover, LED lights

## WARRANTY INFORMATION

Specific warranty details for the Roroom DIY Book Nook Kit (TSZH6806) are not explicitly provided. For any concerns regarding product defects or missing parts, please retain your proof of purchase and contact customer support.

## **CUSTOMER SUPPORT**

---

For any questions, concerns, or assistance with your Roroom DIY Book Nook Kit, please contact Roroom customer service. The most efficient way to reach support is through the Amazon platform where the product was purchased. Navigate to your order history and select the option to contact the seller.