

[Manuals.plus](#) /

› [OYLUS](#) /

› OYLUS Space Heater with Humidifier - Portable Tower Heater Instruction Manual (Model KPT-2000 5172(02)L)

OYLUS KPT-2000 5172(02)L

OYLUS Space Heater with Humidifier Instruction Manual

Model: KPT-2000 5172(02)L

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

General Safety Precautions:

- Always plug the heater directly into a wall outlet. Never use with an extension cord or relocatable power tap.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions, has been dropped or damaged in any manner.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- Do not use outdoors.
- Do not use in bathrooms, laundry areas, or similar indoor locations where water is present.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- Always unplug the heater when not in use.

Integrated Safety Features:

- **Tip-Over Protection:** The heater automatically shuts off if it is accidentally tipped over.
- **Overheat Shut-Off:** The heater will power off if it detects an internal temperature that is too high.
- **30-Second Residual Heat Cooling System:** After turning off, the fan continues to run for 30 seconds to dissipate residual heat, enhancing safety.
- **Flame-Retardant Materials:** Constructed with materials designed to resist fire.
- **Shielded Plug Design:** Features an enhanced safety plug for reliable power connection.



**Overheat
Protection**

**Flame-Retardant
Materials**



**Safety
Tip-Over
Shut-Off**



**Shielded
Plug
Design**

Image: Visual representation of the OYLUS Space Heater's multi-layer safety features, including tip-over protection, overheat shut-off, flame-retardant materials, and a shielded plug design.

2. PRODUCT OVERVIEW

The OYLUS Space Heater with Humidifier provides efficient heating and comfortable humidification for indoor spaces. Its compact tower design and advanced features ensure a cozy and safe environment.

Key Features:

- **3 Heat Settings:** Choose from Low, Medium, or High heat up to 1500W.
- **Adjustable Thermostat:** Fine-tune temperature between 50-90°F with 1°F precision.
- **Built-in Humidifier:** Keeps air comfortably moist, preventing dryness. Features a 1L detachable tank.
- **Quiet Operation:** Designed for minimal noise, suitable for bedrooms and offices.
- **1-12 Hour Timer:** Set automatic shut-off for convenience.
- **90° Oscillation:** Spreads warmth evenly across the room.
- **Dual Control:** Operate via remote control or the integrated control panel.
- **Smart LED Display:** Shows current room temperature, set temperature, heat mode, and humidifier status.
- **Compact Design:** Lightweight and corner-friendly for easy placement.



Image: The OYLUS Space Heater with Humidifier, highlighting its modern white tower design.



Image: Infographic detailing key features such as 90° oscillation, quiet operation, easy portability, 3 heating modes, 12-hour timer, built-in humidifier, and remote control.

3. SETUP

Unpacking:

1. Carefully remove the heater from its packaging.
2. Remove all packaging materials, including any protective tape or films.
3. Inspect the heater for any signs of damage. If damaged, do not operate and contact customer support.

Placement:

- Place the heater on a firm, level surface.
- Ensure there is at least 3 feet (0.9 m) of clear space around the heater to prevent fire hazards.
- Do not place the heater directly under a power outlet.

Humidifier Water Tank Setup:

1. Locate the 1L detachable water tank at the base of the heater.
2. Remove the tank by pulling it out gently.
3. Unscrew the cap at the bottom of the tank and fill it with clean, cool tap water. Do not use hot water or add essential oils.
4. Securely screw the cap back on and reinsert the water tank into its compartment until it clicks into place.



Image: Illustration of the easy water refill process for the 1L humidifier tank, which provides up to 9 hours of humidification.

4. OPERATING INSTRUCTIONS

The OYLUS Space Heater can be operated using the control panel on top of the unit or the included remote control.

Control Panel & Remote Control:

- **Power Button:** Press to turn the heater ON or OFF.
- **Mode Button:** Cycle through heat settings (Low, Medium, High).
- **Temperature Adjustment (+/-):** Increase or decrease the desired temperature in 1°F increments.
- **Timer Button:** Set the automatic shut-off timer from 1 to 12 hours.
- **Oscillation Button:** Activate or deactivate the 90° oscillation feature.
- **Humidifier Button:** Turn the humidifier function ON or OFF independently of heating.

Smart LED Display:

The clear LED display shows:

- Current room temperature.
- Set temperature.
- Active heat mode (Low, Medium, High).
- Humidifier status icons.

Heater & Humidifier

Balanced Warmth and Comfort Without Dryness




Image: Close-up of the OYLUS Space Heater's control panel and remote, illustrating the various buttons for operation.

Video: Official OYLUS video demonstrating the features and operation of the Space Heater with Humidifier, including heat settings, humidifying mode, oscillation, and safety features.

Video: A short 8-second user-generated video demonstrating the humidifier mist function of the OYLUS Space Heater.

5. MAINTENANCE

Cleaning the Humidifier Tank:

- Regularly clean the humidifier tank to prevent mineral buildup and ensure optimal performance.
- Remove the tank, unscrew the cap, and drain any remaining water using the simple plug.
- Rinse the tank thoroughly with clean water. For stubborn mineral deposits, use a mild descaling solution (e.g., vinegar and water) and rinse well.
- Allow the tank to air dry completely before reassembling.

General Cleaning:

- Always unplug the heater before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners or solvents.
- Periodically clean the air inlet filter to maintain efficient operation. The filter is easily accessible and can be cleaned without tools.
- Ensure all parts are completely dry before plugging the heater back in.

6. TROUBLESHOOTING

Heater Does Not Turn On:

- **Check Power Connection:** Ensure the power cord is securely plugged into a working electrical outlet.
- **Verify Power Switch:** Make sure the main power switch (usually located at the back or bottom) is in the 'ON' position.
- **Tip-Over/Overheat Protection:** If the heater was tipped or overheated, it might have activated its safety shut-off. Place it upright on a stable surface and allow it to cool down for a few minutes before attempting to restart.
- **Remote Control Batteries:** If using the remote, check if the batteries need replacement.

No Heat Output:

- **Check Heat Mode:** Ensure a heat mode (Low, Medium, or High) is selected, not just the fan or humidifier mode.
- **Thermostat Setting:** Verify that the set temperature is higher than the current room temperature.

Humidifier Not Producing Mist:

- **Water Level:** Check if the water tank is empty. Refill if necessary.
- **Tank Placement:** Ensure the water tank is correctly seated in its compartment.
- **Mineral Buildup:** Clean the humidifier tank and transducer if there is mineral buildup.

If the issue persists after performing these checks, please contact OYLUS customer support for assistance.

7. SPECIFICATIONS

Brand	OYLUS
Model Number	KPT-2000 5172(02)L
UPC	607609477440
Color	White

Form Factor	Tower
Indoor/Outdoor Usage	Indoor
Power Source	AC (120 Volts)
Heating Method	Convection
Heat Output	1500 Watts
Number of Speeds	3
Min Temperature Setting	50 Degrees Fahrenheit
Max Temperature Setting	95 Degrees Fahrenheit
Item Dimensions (D x W x H)	10.24"D x 10.24"W x 29.53"H
Item Weight	7.5 Pounds

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official OYLUS website. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

