

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VINGLI](#) /

› [VINGLI Lockable Display Cabinet G47001194 User Manual](#)

## VINGLI G47001194

# VINGLI Lockable Display Cabinet G47001194 User Manual

Model: G47001194

## 1. INTRODUCTION

---

Thank you for choosing the VINGLI Lockable Display Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.

This cabinet features a heavy-duty metal structure, tempered glass doors, and five adjustable shelves, designed for versatile storage in various environments such as homes, offices, and garages. It includes a secure locking mechanism and an anti-tip design for enhanced safety.



Image 1.1: Overview of the VINGLI Lockable Display Cabinet, highlighting its dimensions (15.8"D x 31.5"W x 71"H) and the 120 lbs per shelf load capacity. It also illustrates the tempered glass panel feature compared to standard glass.

## 2. SAFETY INFORMATION

---

- Always assemble the cabinet on a soft, clean surface to prevent scratches.
- Ensure all parts are present before assembly. Do not proceed if any parts are missing or damaged.
- Use the provided anti-tip kit to secure the cabinet to a wall, especially in households with children or pets, to prevent accidental tipping.
- Do not overload shelves. Each shelf has a maximum weight capacity of 120 pounds (approximately 54 kg).
- Keep children and pets away from the assembly area.
- Exercise caution when handling glass components to avoid injury.

## 3. PACKAGE CONTENTS

---

Before assembly, verify that all components listed below are included in your package:

- Cabinet Panels (Top, Bottom, Sides, Back)
- Glass Doors (2)
- Adjustable Shelves (5)
- Shelf Supports/Pins
- Locking Mechanism with 2 Keys
- Door Hinges and Hardware
- Anti-Tip Kit
- Assembly Hardware (screws, bolts, etc.)
- Assembly Instructions

## 4. ASSEMBLY INSTRUCTIONS (SETUP)

---

Assembly typically requires two people. Follow the steps carefully to ensure proper construction.

### Step 4.1: Prepare the Base

1. Unpack all components and lay them out on a protected surface.
2. Attach the bottom panel to the side panels using the provided hardware. Ensure all connections are secure.

### Step 4.2: Install Back Panel and Top Panel

1. Slide the back panel into the grooves of the side panels. Note the pre-drilled holes on the back panel for potential LED light installation.
2. Attach the top panel to the side and back panels, securing it with the appropriate hardware.

## Special Pre-Drilled Design



Image 4.2: Illustration of the cabinet's back panel featuring pre-drilled holes designed for easy LED light installation and cable management. This design helps maintain a neat appearance by keeping wires organized.

### Step 4.3: Attach Doors and Locking Mechanism

1. Install the hinges onto the glass doors and the cabinet frame according to the detailed assembly diagram.
2. Carefully attach the glass doors to the cabinet. Adjust hinges as needed for proper alignment.
3. Install the locking mechanism and handle onto one of the doors. Ensure the lock functions correctly with the provided keys.

# Thoughtful Design




Smooth Metal Handle



High-Security Lock with 2 Keys



Metal Shelf Support



Pre-drilled Holes for Led

Image 4.3: Detailed view of the cabinet's thoughtful design elements, including the smooth metal handle, the high-security lock with two keys, robust metal shelf supports, and the pre-drilled holes for LED lighting.

## Step 4.4: Install Adjustable Shelves

1. Insert the shelf supports into the desired pre-drilled holes on the inner side panels.
2. Place the adjustable shelves onto the supports. Ensure they are level and securely seated.

## Step 4.5: Secure with Anti-Tip Kit

1. Position the cabinet in its final location.
2. Attach the anti-tip bracket to the top rear of the cabinet and secure it to a wall stud using the provided hardware. This step is crucial for stability and safety.

## 5. OPERATING INSTRUCTIONS

---

### 5.1: Adjusting Shelves

The cabinet features five adjustable shelves to accommodate items of various sizes. To adjust a shelf:

1. Empty the shelf of all contents.
2. Carefully lift the shelf and remove the four shelf supports from their current holes.
3. Reinsert the shelf supports into the desired new set of holes, ensuring they are at the same height on all four corners.
4. Place the shelf back onto the supports, ensuring it is stable before placing items on it.



Image 5.1: Visual representation of the cabinet's adjustable shelves, demonstrating how they can be reconfigured to create personalized storage spaces for items of varying heights and sizes.

## 5.2: Using the Locking Mechanism

The cabinet is equipped with a three-point locking system for securing your items.

- **To Lock:** Close both glass doors completely. Insert a key into the lock cylinder on the right door and turn it clockwise until the mechanism engages. Remove the key.

- **To Unlock:** Insert a key into the lock cylinder and turn it counter-clockwise. The doors can then be opened.

Keep spare keys in a safe and accessible location.

## 6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your VINGLI display cabinet.

- **Cleaning the Metal Frame:** Wipe the metal surfaces with a soft, damp cloth. For stubborn marks, a mild, non-abrasive cleaner can be used. Dry immediately with a clean cloth to prevent water spots.
- **Cleaning the Glass Doors:** Use a standard glass cleaner and a lint-free cloth. Spray the cleaner onto the cloth, not directly onto the glass, to avoid dripping onto the metal frame.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong chemical agents, as these can damage the paint finish and glass.
- **Check Hardware:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.
- **Door Alignment:** If doors become misaligned, adjust the hinges as per the assembly instructions.

## 7. TROUBLESHOOTING

If you encounter issues with your cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cabinet is wobbly/unstable	Loose hardware; uneven floor; anti-tip kit not installed.	Ensure all screws are tightened. Move cabinet to a level surface or use shims. Install the anti-tip kit securely to a wall stud.
Doors do not close properly or are misaligned	Hinges are loose or improperly adjusted.	Adjust the screws on the hinges to align the doors. Refer to the assembly instructions for hinge adjustment details.
Lock mechanism is stiff or not engaging	Mechanism needs lubrication; doors are not fully closed.	Apply a small amount of graphite lubricant to the lock cylinder. Ensure both doors are fully closed and aligned before attempting to lock.
Shelves are not level	Shelf supports are not inserted at the same height.	Remove the shelf and reinsert the shelf supports into corresponding holes on all four sides to ensure even height.

## 8. SPECIFICATIONS

Feature	Detail
Model Name	Metal Display Cabinet
Item Model Number	G47001194
Brand	VINGLI
Color	White

Feature	Detail
Material	Metal, Tempered Glass
Product Dimensions (D x W x H)	40.1D x 80W x 180.3H Centimeters (approx. 15.8"D x 31.5"W x 71"H)
Item Weight	40 kg 400 g (approx. 89 lbs)
Number of Shelves	5 (Adjustable)
Shelf Weight Capacity	Up to 120 pounds (approx. 54 kg) per shelf
Special Features	Adjustable Shelf, Anti-Tipping, Heavy Duty, Lockable, Pre-Drilled Back Panel (for LED)
Mounting Type	Floor Mount (with wall anchor for anti-tip)
Included Components	Keys, Shelves

## 9. WARRANTY AND SUPPORT

---

VINGLI is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this document, our customer service team is available to assist with any inquiries or issues you may encounter.

For assistance with assembly, missing parts, or any other concerns, please contact VINGLI customer service. Our responsive team is available 24/7 to provide support.

Please have your model number (G47001194) and purchase information ready when contacting support.

