

[Manuals.plus](#) /

› [Luqeeq](#) /

› Luqeeq 320ml Automatic Foaming Soap Dispenser Instruction Manual

Luqeeq Luqeeqip84w731zq-12

Luqeeq 320ml Automatic Foaming Soap Dispenser

Model: Luqeeqip84w731zq-12

INTRODUCTION

Thank you for choosing the Luqeeq 320ml Automatic Foaming Soap Dispenser. This manual provides essential information for the safe and efficient use of your new device. Please read it thoroughly before operation and retain it for future reference.

SAFETY INFORMATION

- **Do not soak** the dispenser in water. While the device is IPX6 water-resistant, it is not designed for submersion.
- **Do not tilt or invert** the product during operation or storage to avoid damage to internal components or leakage.
- Keep out of reach of children.
- Use only the provided USB data cable for charging.
- Avoid using highly corrosive liquids or thick, gel-like soaps that may clog the dispenser mechanism.

IPX6 Water proof,Not afraid of water
Should Not Be Submerged in Wate



Image: The dispenser positioned near a sink, illustrating its water-resistant design. Note: The device is splash-proof (IPX6) but should not be submerged in water.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Luqeeeg Automatic Foaming Soap Dispenser
- 1 x USB Data Cable

PRODUCT OVERVIEW

The Luqeeeg Automatic Foaming Soap Dispenser features a touchless design, intelligent display, and adjustable foam output for a hygienic handwashing experience.

Intelligent Display
5 gear Liquid Output Adjustment
IPX6 Water proof



Image: Front view of the dispenser, showcasing its intelligent display with temperature and time, and highlighting adjustable foam output and water resistance.



Image: A detailed view of the dispenser's display and infrared sensor, which enables touchless operation.

SETUP

1. Charging the Dispenser

The dispenser is equipped with a 3000mAh rechargeable lithium-ion battery. Before first use, or when the battery indicator on the display shows low power, charge the device.

1. Locate the Type-C charging port, usually found on the top or back of the device, protected by a rubber cover.
2. Open the rubber cover and connect the provided USB data cable to the dispenser and a suitable USB power adapter (not included).
3. The display will indicate charging status. A full charge ensures long-lasting use.



Image: A close-up of the Type-C charging port, typically located on the top of the dispenser, used for recharging the internal battery.

2. Filling with Soap

The dispenser has a 320ml capacity. It is compatible with most liquid soaps, including dishwashing soap, shower gel, shampoo, hand soap, or facial cleanser. For optimal foaming, we recommend using a standard hand soap that is not too thick or gel-like. Dilution with water may be necessary for thicker soaps.

1. Twist the top section of the dispenser counter-clockwise to separate it from the soap reservoir.
2. Pour your desired liquid soap into the reservoir. Do not overfill.
3. If using a concentrated soap, dilute it with water according to the soap manufacturer's instructions or until it reaches a suitable consistency for foaming. A common ratio is 1 part soap to 3-5 parts water. Gently swirl to mix, do not shake vigorously.
4. Align the top section with the reservoir and twist clockwise to secure it firmly.

OPERATION

1. Dispensing Soap

The dispenser features an automatic touchless sensor for hygienic operation.

1. Ensure the dispenser is powered on.
2. Place your hand under the nozzle. The intelligent sensor will detect your hand.
3. The dispenser will automatically dispense a pre-set amount of foam soap.



Image: A user activating the dispenser by placing their hand beneath the sensor, illustrating the touchless dispensing feature.

2. Adjusting Foam Output

The dispenser offers 5 gear liquid output adjustments to suit different preferences and scenarios.

1. Locate the adjustment button or touch area, typically near the display.
2. Press or tap the button/area to cycle through the 5 different foam output levels. The current level may be indicated on the intelligent display.
3. Select the desired output level for your needs.

Gear Foaming Adjustment to Meet Different Scenarios and User Needs



Image: A hand collecting foam from the dispenser, demonstrating the adjustable foam output feature.

MAINTENANCE

Cleaning

- Wipe the exterior of the dispenser with a soft, damp cloth. Do not use abrasive cleaners or immerse the device in water.
- If the nozzle becomes clogged, gently clean it with a small brush or cotton swab.
- Regularly clean the soap reservoir when refilling to prevent residue buildup.

Refilling

Refer to the 'Filling with Soap' section under Setup for instructions on how to refill the soap reservoir.

TROUBLESHOOTING

- **Dispenser not working:** Ensure the device is charged. Check if the soap reservoir is properly filled and

secured.

- **No foam or weak foam:** The soap may be too thick; try diluting it with water. The nozzle might be clogged; clean it as described in the Maintenance section.
- **Sensor not detecting hand:** Ensure there are no obstructions in front of the sensor. Make sure your hand is placed directly under the nozzle within the detection range.
- **Leakage:** Ensure the top section is securely twisted onto the reservoir. Do not tilt or invert the dispenser.

SPECIFICATIONS

Item Type	Automatic Foaming Soap Dispenser
Brand	Luqeeq
Model Number	Luqeeqip84w731zq-12
Material	ABS
Capacity	320ml
Battery Type	Lithium Ion Battery (Built-in)
Battery Capacity	3000mAh
Product Size	Approx. 211x70mm / 8.3x2.8in (Height x Diameter)
Product Dimensions	5.51"L x 3.93"W x 3.14"H (Note: This may refer to packaging or a different measurement, refer to 211x70mm for device size)
Item Weight	Approx. 409.00g / 14.43oz
Color	Black

98mm / 3.9in





211mm / 8.3in

70mm / 2.8in

Image: A technical drawing illustrating the key dimensions of the soap dispenser, including its height and diameter.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Luqeeq customer service through the retailer where the product was purchased or visit the official Luqeeq brand store online. Please have your model number (Luqeeqip84w731zq-12) and purchase details available.

Luqeeq Brand Store: [Visit the Luqeeq Store on Amazon](#)

© 2026 Luqeeq. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FSSQMCKX>

More documents and user manuals: **<https://manuals.plus/>**