Carevac A001

Carevac 500W Handheld Carpet and Upholstery Cleaner User Manual

Model: A001

Introduction

Thank you for choosing the Carevac 500W Handheld Carpet and Upholstery Cleaner. This portable deep cleaner is designed to effectively remove pet stains, dirt, and odors from carpets, rugs, upholstered furniture, and car interiors. Please read this manual thoroughly before operating the device to ensure safe and efficient use.



Image: The Carevac cleaner demonstrating versatile cleaning on various surfaces including carpet, upholstery, and a hard floor with a spill.

Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury. Keep this manual for future reference.

- Read all instructions before use.
- Do not immerse the appliance in water or other liquids.
- Do not operate with a damaged cord or plug.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only cleaning solutions recommended for carpet and upholstery cleaners.
- Unplug from outlet when not in use and before cleaning or servicing.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Package Contents

Verify that all items are present in the package:

- Carevac 500W Handheld Carpet and Upholstery Cleaner
- Standard Brush Head
- Round Brush Head
- Flat Crevice Tool
- User Manual

Product Overview

Familiarize yourself with the components of your Carevac cleaner.



Image: A close-up view of the Carevac cleaner highlighting the 480ml clean water tank, 900ml dirty water tank, spray button, and the 5-meter power cable.

1. **Clean Water Tank:** Holds water and cleaning solution. Capacity: 480 ml.
2. **Dirty Water Tank:** Collects extracted dirty water. Capacity: 900 ml.
3. **Spray Button:** Activates the spray function to dispense cleaning solution.
4. **Power Cord:** Connects the unit to an AC power outlet. Length: 5 meters.
5. **Brush Attachment Area:** Where different brush heads are connected.

Setup

1. Unpacking

Remove the cleaner and all accessories from the packaging. Dispose of packaging materials responsibly.

2. Filling the Clean Water Tank

1. Press the release button and detach the clean water tank from the main unit.
2. Unscrew the cap of the clean water tank.
3. Fill the tank with warm tap water (max 40°C) up to the water fill line. Add the recommended amount of carpet/upholstery cleaning solution according to the solution manufacturer's instructions. Do not overfill.
4. Securely screw the cap back on.
5. Reattach the clean water tank to the main unit, ensuring it clicks into place.

3. Attaching Brush Heads

Select the appropriate brush head for your cleaning task:

- **Standard Brush Head:** For general cleaning of larger carpeted or upholstered areas.
- **Round Brush Head:** Ideal for focused stain removal and detailing in smaller areas like car interiors.
- **Flat Crevice Tool:** Designed for reaching tight spaces, corners, and crevices between cushions.

To attach, align the chosen brush head with the attachment area on the front of the cleaner and push firmly until it locks into position.

Operating Instructions

1. Preparation

- Vacuum the area to be cleaned to remove loose dirt and debris.
- Test the cleaning solution on an inconspicuous area of the material to be cleaned for colorfastness.

2. Powering On

Plug the power cord into a grounded electrical outlet.

3. Cleaning Procedure

1. Place the brush head firmly against the surface to be cleaned.
2. Press and hold the spray button to dispense cleaning solution while slowly pulling the cleaner over the stained area.
3. Release the spray button and continue to pull the cleaner over the wet area to suction up the dirty solution. Repeat this step until the area is clean and as dry as possible.
4. For heavily soiled areas, you may need to repeat the spray and suction process multiple times.



Image: The Carevac cleaner being used on a mattress, with a close-up inset showing the spray button for targeted stain treatment.

4. Self-Cleaning Function

After each use, it is recommended to use the self-cleaning function to flush the internal hoses and brush head:

1. Ensure the clean water tank has some clean water (without solution).
2. Place the cleaner over a sink or bucket.
3. Press and hold the spray button while simultaneously pressing the self-clean button (if available, otherwise run clean water through the system by spraying into a sink). The unit will spray clean water and then suction it back, flushing the system.
4. Continue until the water being suctioned appears clear.

5. Emptying the Dirty Water Tank

Empty the dirty water tank when it reaches the 'MAX' fill line or after each cleaning session.

1. Press the release button and detach the dirty water tank from the main unit.

2. Carefully carry the tank to a sink or toilet.
3. Open the tank's lid and pour out the dirty water.
4. Rinse the tank thoroughly with clean water.
5. Reattach the dirty water tank to the main unit, ensuring it is securely latched.

Maintenance

1. Cleaning Brush Heads

After each use, detach the brush head and rinse it under running water to remove any trapped debris or cleaning solution residue. Allow it to air dry completely before reattaching or storing.

2. Cleaning the Unit

Wipe the exterior of the cleaner with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure all parts are dry before storage.

3. Storage

Store the Carevac cleaner in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure both water tanks are empty and clean before storage.



Image: The Carevac cleaner stored compactly inside a cleaning cupboard, demonstrating its space-saving design.

Troubleshooting

Problem	Possible Cause	Solution
No spray	Clean water tank empty or not properly seated. Spray nozzle clogged.	Refill clean water tank. Ensure tank is securely attached. Clean spray nozzle with a small brush.
No suction	Dirty water tank full or not properly seated. Suction nozzle clogged. Hose blockage.	Empty dirty water tank. Ensure tank is securely attached. Clear any blockages from the suction nozzle or hose.
Leaking	Water tanks not properly sealed or damaged.	Ensure tank caps are tightly closed and tanks are correctly seated. Check tanks for cracks or damage.

Problem	Possible Cause	Solution
Poor cleaning performance	Incorrect cleaning solution concentration. Brush head worn or dirty.	Adjust cleaning solution concentration. Clean or replace brush head.

Specifications

Feature	Detail
Brand	Carevac
Model Name	A001
Power	500W
Clean Water Tank Capacity	480 ml
Dirty Water Tank Capacity	900 ml
Power Source	AC
Item Weight	7 pounds (approx. 3.17 kg)
Package Dimensions	16 x 9.5 x 7.8 inches (approx. 40.6 x 24.1 x 19.8 cm)
Power Cable Length	5 meters

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.