

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Mxnsewr](#) /

> [Mxnsewr MX-100A All-in-One Steam Mop Instruction Manual](#)

Mxnsewr MX-100A

Mxnsewr MX-100A All-in-One Steam Mop Instruction Manual

Model: MX-100A

1. INTRODUCTION

The Mxnsewr MX-100A Steam Mop is a versatile cleaning appliance designed for various surfaces in your home. Utilizing high-temperature steam, it effectively cleans and sanitizes without the need for harsh chemicals. This manual provides essential information for safe and efficient operation, maintenance, and troubleshooting.

2. SAFETY INFORMATION

- Read all instructions before use.
- Use only distilled or demineralized water to prevent mineral buildup.
- Do not direct steam at people, pets, or electrical appliances.
- Keep the appliance out of reach of children and pets.
- Always unplug the steam mop before filling, emptying, or cleaning.
- Ensure the power cord is not damaged and avoid kinking or stretching it.
- Do not use on unsealed hardwood floors or surfaces that are sensitive to heat or moisture.
- The steam mop operates at high temperatures; avoid direct contact with steam or hot parts.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- Main Body (Steam Unit)
- Extended Tube (x2)
- Hose Assembly
- Main Brush (Mop Head)
- Microfiber Pads (x2)
- Sponge Brush
- Carpet Glider
- Shoulder Strap
- 2-in-1 Brush
- Detail Brush
- Round Scrubbing Brush
- Wall Mount Bracket
- Measuring Cup
- Funnel
- Instruction Manual

Multi-Purpose Steam Cleaning




Image: All included accessories for the Mxnsewr MX-100A Steam Mop, including the main unit, extension tubes, various brushes, mop pads, and a shoulder strap.

4. SETUP

4.1 Assembly

1. Attach the main brush (mop head) to the steam unit.
2. Connect the extended tubes to the steam unit and then to the handle. Ensure they click securely into place.
3. Attach a microfiber pad to the bottom of the main brush using the Velcro fasteners.

4.2 Filling the Water Tank

1. Ensure the steam mop is unplugged.
2. Open the water tank cap located on the main unit.
3. Use the provided measuring cup and funnel to fill the 380ml detachable water tank with distilled or demineralized water. Do not overfill.
4. Securely close the water tank cap.



Image: The Mxnsewr MX-100A Steam Mop highlighting the detachable 380ml water tank with filtration system and the included wall mount for convenient storage.

5. OPERATING INSTRUCTIONS

5.1 Powering On and Heating

1. Plug the power cord into a grounded electrical outlet.
2. Press the power button on the main unit. The indicator light will illuminate.
3. Allow approximately 15-20 seconds for the steam mop to heat up. The indicator light will change when ready.

5.2 Adjusting Steam Levels

The liquid crystal display screen shows the steam temperature in real-time. Switch between two steam levels (High Steam and Low Steam) by pressing the steam icon on the main unit.

- **Low Steam:** Suitable for delicate surfaces like sealed hardwood floors.
- **High Steam:** Ideal for tough stains on tiles, grout, and carpets.

Press the steam icon to change the steam gear



High Steam



Low Steam



Image: Close-up of the Mxnsewr MX-100A Steam Mop's digital display for steam level selection and the flexible mop head reaching under furniture.

5.3 Upright Mop Mode

Use the steam mop in its upright configuration for cleaning various floor types:

- **Hardwood, Tile, Laminate, Stone:** Select the appropriate steam level. Move the mop head slowly and steadily over the surface. The mop head can be adjusted up and down by 90° and left and right by 180° for easy maneuverability.
- **Carpet:** Attach the carpet glider over the microfiber pad. Use High Steam for refreshing and cleaning carpets.

5.4 Handheld Steamer Mode

Detach the steam unit from the extended tubes to use it as a handheld steamer. Connect the hose assembly and desired accessories for targeted cleaning.

- **Detail Brush:** For cleaning grout, stove tops, sinks, and tight corners.
- **Round Scrubbing Brush:** For tougher grime on various surfaces.
- **2-in-1 Brush:** For cleaning clothes, glass, and furniture.
- **Shoulder Strap:** Attach the shoulder strap to the main unit for comfortable, hands-free operation during extended handheld cleaning tasks.



Image: The Mxnsewr MX-100A Steam Mop demonstrating both traditional handheld use and the new shoulder strap

mode for more relaxed cleaning.

Multi-Purpose Steam Cleaning




Image: A visual guide to the multi-purpose cleaning capabilities of the Mxnsewr MX-100A Steam Mop, showing different attachments used for stove, toilet, upholstery, clothes, windows, and carpets.

5.5 Aromatherapy Function

The mop head features a scent container. Add aromatherapy oils or essential oils to this container to infuse your home with a fresh aroma while cleaning.

New Aromatherapy Function

Add aromatherapy and essential oils
Make your home cleaner and
more comfortable



Image: The Mxnsedr MX-100A Steam Mop in use, highlighting the new aromatherapy function where essential oils can be added to the mop head for a pleasant scent during cleaning.

5.6 Official Product Video

Video: Official product video demonstrating the Mxnsedr MX-100A All-in-one Steam Mop in various cleaning scenarios, showcasing its versatility and ease of use.

6. MAINTENANCE

6.1 Cleaning Microfiber Pads

The microfiber pads are reusable and machine washable. After each use, remove the pad from the mop head and wash it with mild detergent. Air dry or tumble dry on low heat.

6.2 Water Tank Filtration System

The detachable water tank includes a filtration system to reduce tiny substances in the water, minimizing water stain formation and nozzle clogging. Regularly check and clean the filter as per the instructions in the full manual to ensure optimal performance.

6.3 Storage

After use, ensure the water tank is empty and the unit is cool. Store the steam mop using the provided wall-mounted device in a dry, safe place away from direct sunlight.

7. TROUBLESHOOTING

- **No Steam:** Check if the water tank is filled and properly secured. Ensure the unit is plugged in and powered on. Allow sufficient time for heating.
- **Low Steam Output:** Verify the selected steam level. Clean the water tank filter if it appears clogged.
- **Water Leakage:** Ensure all connections are secure and the water tank cap is tightly closed.
- **Auto Shut-off:** The unit features anti-dry burning protection and will automatically stop working if there is a water shortage. Refill the water tank.

8. SPECIFICATIONS

Feature	Specification
Brand	Mxnsewr
Model Name	MX-100A
Special Feature	Portable, Detachable Handheld, Aromatherapy
Surface Recommendation	Hardwood, Grout, Tile, Laminate, Stone, Carpet
Wattage	1200 watts
Tank Volume	380 Milliliters
Heat Time	15 Seconds
Maximum Temperature	260 Degrees Fahrenheit (126.6°C)
Power Source	AC
Voltage	110 Volts (AC)
Item Weight	8.63 pounds
Power Cord Length	16.4 inches (approx. 4.9 meters)

9. WARRANTY AND SUPPORT

The Mxnsewr MX-100A Steam Mop comes with a standard manufacturer's warranty. Please refer to the warranty card included in your packaging for specific terms and conditions. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Mxnsewr customer service through the details provided on your warranty card or the official Mxnsewr website.