



[Manuals.plus](#) /

> [XINFUTE](#) /

> XINFUTE MR25GA AKB76046602 LG Magic Voice TV Remote Control User Manual

XINFUTE MR25GA AKB76046602

XINFUTE MR25GA AKB76046602 LG Magic Voice TV Remote Control User Manual

Model: MR25GA AKB76046602

1. PRODUCT OVERVIEW

The XINFUTE MR25GA AKB76046602 is a replacement TV remote control designed for LG 2025 Smart TVs. It features universal magic remote capabilities, intelligent voice recognition, and intuitive mouse-like pointing and wheel control for enhanced navigation. This remote provides a convenient and efficient way to interact with your compatible LG television.



Figure 1: Front and back view of the XINFUTE MR25GA AKB76046602 remote control.

2. SETUP

2.1 Battery Installation

The remote control requires 2 x AAA batteries (not included). To install the batteries, follow these steps:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 2: Back view of the remote control with the battery compartment.

3. OPERATING INSTRUCTIONS

3.1 Basic Functions

- **Power Button (Red):** Located at the top, this button turns the TV on or off.
- **Number Buttons (0-9):** Use these to directly select TV channels.
- **Volume Up/Down:** Adjusts the television's audio level.
- **Channel Up/Down:** Navigates through TV channels sequentially.
- **Home Button:** Provides access to the TV's main menu or smart hub interface.
- **Back Button:** Returns to the previous screen or menu.
- **Settings Button:** Opens the TV's settings menu for configuration adjustments.

3.2 Special Features

- **Magic Remote Functionality:** Point the remote at the TV screen to activate an on-screen cursor, allowing for intuitive navigation and selection.
- **Voice Recognition:** Press the microphone button and speak commands to search for content, control TV functions, or access smart features.
- **Quick Access Buttons:** Dedicated buttons for popular streaming services such as Netflix and Prime Video offer instant access to these platforms.

Your browser does not support the video tag.

Video 1: Demonstration of the LG Magic Remote's universal functionality and quick access buttons.

4. COMPATIBILITY

This remote control is compatible with the following LG 2025 TV series:

- OLED G5 Series
- OLED C5 Series
- OLED B5 Series

- QNED 92A Series
- QNED 85A Series
- QNED 80A Series
- UA77 Series

5. TROUBLESHOOTING

- **Remote not responding:**
 - Check battery levels and replace with fresh AAA batteries if necessary.
 - Ensure there are no physical obstructions between the remote control and the TV's infrared receiver.
 - Try re-pairing the remote with your TV. Specific pairing instructions can usually be found in your LG TV's user manual.
- **Voice control not working:**
 - Verify that the remote is properly paired with the TV and within operational range.
 - Confirm that voice recognition features are enabled in your TV's settings menu.
- **On-screen pointer not appearing:**
 - Gently shake the remote control or press the dedicated pointer activation button (if available) to activate the on-screen cursor.
 - Ensure the remote is pointed directly at the television screen for optimal cursor tracking.

6. SPECIFICATIONS

Brand	XINFUTE
Model	MR25GA AKB76046602
Material	ABS Material
Power Source	2 x AAA batteries (not included)
Connectivity Technology	Infrared
Compatible Devices	Television
Special Features	Ergonomic design, Voice Control, Pointer Functionality, Quick Access Buttons

7. WARRANTY AND SUPPORT

This product comes with a one-year warranty from the date of purchase. If you encounter any issues or are not satisfied with your purchase, please contact the seller directly within 24 hours of receiving the product for assistance and support.