Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Voukad BLG-HT-006

Voukad BLG-HT-006 Beard Trimmer Instruction Manual

Model: BLG-HT-006 | Brand: Voukad

1. Introduction

Thank you for choosing the Voukad BLG-HT-006 Beard Trimmer. This all-in-one grooming kit is designed for precise trimming, edging, and sculpting of hair on the beard, face, neck, mustache, head, chest, legs, and nose. It features 40 adjustable length settings, a waterproof design for easy cleaning, and a long-lasting battery for consistent performance.

2. Package Contents

Please check the box for the following items:

- 1x Voukad BLG-HT-006 Beard Trimmer Unit
- 1x U-shaped Beard Trimmer Attachment
- 1x Detailer Trimmer Attachment
- 1x Nose Hair Trimmer Attachment
- 2x Adjustable Comb Guards (for 1-40mm length settings)
- 1x USB-C Charging Cable
- 1x Cleaning Brush
- 1x Lubricating Oil Bottle
- 1x Storage Pouch
- 1x User Manual



Image: The Voukad Beard Trimmer unit with its precision dial and two adjustable comb attachments.

3. Setup

3.1 Initial Charging

Before first use, fully charge the trimmer. Connect the USB-C charging cable to the trimmer and plug the other end into a compatible USB power adapter (not included). The trimmer requires approximately 240 minutes for a full charge, providing up to 240 minutes of cordless runtime.

3.2 Attaching/Detaching Trimmer Heads

To attach a trimmer head (U-shaped, detailer, or nose trimmer), align the head with the main unit and gently push until it clicks into place. To detach, firmly pull the head away from the unit.

3.3 Attaching/Detaching Comb Guards

For the U-shaped beard trimmer, select one of the two adjustable comb guards. Slide the comb onto the trimmer head until it securely locks. Ensure the comb is properly seated before use. To remove, gently pull the comb off the head.

4. Operating Instructions

4.1 Power On/Off

Press the power button to turn the trimmer on or off. The display will illuminate when powered on.

4.2 Adjusting Trimming Length

With an adjustable comb guard attached, rotate the precision dial on the trimmer body to select your desired hair length. The dial offers 40 settings, from 1mm to 40mm, in 0.5mm steps. Ensure the trimmer is off when adjusting the comb or head.



Image: Overview of the trimmer's features, including the precision dial for length adjustment.

4.3 Trimming Techniques

- **Beard and Face:** Use the U-shaped trimmer with an adjustable comb. Start with a longer setting and gradually reduce it until you achieve the desired length. Move the trimmer against the direction of hair growth for an even cut.
- **Detailing and Edging:** Use the detailer trimmer attachment for precise lines, edges, and intricate styling around the beard, mustache, and sideburns.
- **Nose Hair:** Attach the nose hair trimmer. Gently insert the trimmer tip into your nostril or ear canal and move it in a circular motion to trim unwanted hair.
- **Body Hair:** The U-shaped trimmer with comb guards can also be used for trimming hair on the chest, underarms, legs, and other body areas.



Image: The trimmer is versatile for various body parts, including chest, underarms, legs, intimate areas, nose, face, and head.

4.4 Travel Lock Function

To prevent accidental activation during travel, the trimmer may feature a travel lock. Consult the included quick guide for specific instructions on how to activate and deactivate this function.

5. Maintenance

5.1 Cleaning

The Voukad BLG-HT-006 trimmer is IPX7 waterproof, allowing for easy cleaning under running water. After each use:

1. Turn off the trimmer and detach the comb guard and trimmer head.

2. Rinse the trimmer head and comb guard under warm running water to remove hair clippings.
3. Use the provided cleaning brush to remove any stubborn hair from the blades and internal components.
4. Rinse the main unit if necessary, ensuring the charging port cover is securely closed.
5. Allow all parts to air dry completely before reassembling or storing.



Image: The trimmer is water-resistant for easy cleaning under running water.

5.2 Lubrication

Regularly apply a small drop of the provided lubricating oil to the trimmer blades to maintain optimal performance and extend blade life. Apply oil after every few uses or when the trimmer feels less smooth.



Image: Close-up of the ultra-sharp stainless steel blades, which benefit from regular lubrication.

6. Troubleshooting

- **Trimmer not turning on:** Ensure the trimmer is fully charged. If the screen flashes and the power button cannot turn it on, press and hold the power button for 5 seconds to reset the machine.
- **Poor trimming performance:** Clean the blades thoroughly and apply lubricating oil. Ensure the comb guard is correctly attached.
- **Battery not charging:** Check the USB-C cable and power adapter for damage. Ensure the cable is securely connected to both the trimmer and the power source.

7. Specifications

Feature	Detail
Model Number	BLG-HT-006
Brand	Voukad
Blade Material	Stainless Steel
Power Source	Battery Powered (Lithium-Ion)

Charging Time	240 minutes
Runtime	Up to 240 minutes
Adjustable Length Settings	40 (0.5mm to 40mm)
Waterproof Rating	IPX7
Included Components	Trimmer, 3 Attachments, 2 Combs, Charging Cable, Cleaning Brush, Oil, Pouch
UPC	850071880922

8. Warranty and Support

The Voukad BLG-HT-006 Beard Trimmer comes with a lifetime warranty. To activate your warranty and ensure peace of mind, please register your product on the Voukad website. An activation code is provided in the packaging. For any issues or support, please contact Voukad customer service via the email provided in your product documentation.
Important: Before charging, ensure the machine is completely dry. If the screen flashes and the power button cannot be turned on, press and hold the power button for 5 seconds to reset the machine.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FSX4VPLR

More documents and user manuals: **https://manuals.plus/**