

[Manuals.plus](#) /

› [DoubleCare](#) /

› DoubleCare 75-Piece Crochet Kit with Large Yarn Bag and 20 Yarn Colors (Blue)

## DoubleCare DE-Crochet Bag-Blue

# DoubleCare 75-Piece Crochet Kit Instruction Manual

Model: DE-Crochet Bag-Blue

## INTRODUCTION

---

Thank you for choosing the DoubleCare 75-Piece Crochet Kit. This comprehensive kit is designed for both beginners and experienced crafters, providing a wide array of tools and materials to support your creative projects. This manual will guide you through the components, setup, operation, and maintenance of your kit to ensure a satisfying crafting experience.



Image: Overview of the DoubleCare 75-Piece Crochet Kit, showcasing the yarn bag, various crochet hooks, and accessories.

## Kit Components

Your DoubleCare 75-Piece Crochet Kit includes the following items:

- 20 x Skeins of Acrylic Yarn (various colors)
- 1 x Large Multifunctional Yarn Storage Bag (Blue, 33 x 28 cm)
- 8 x Thin Crochet Hooks (0.6mm, 0.75mm, 0.9mm, 1.0mm, 1.1mm, 1.25mm, 1.5mm, 1.75mm)
- 8 x Thick Crochet Hooks (2.5mm, 3.0mm, 3.5mm, 4.0mm, 4.5mm, 5.0mm, 5.5mm, 6.0mm)
- 3 x Knitting Needles
- 4 x Yarn Needles
- 1 x Measuring Tape (1.6 meters / 60 inches)
- 10 x Stitch Holders
- 4 x Stitch Markers

- 4 x Hook Point Protectors
- 1 x Yarn Cutter
- 2 x Row Counters
- 1 x Thimble
- 1 x Organizer Case (for small accessories)

# 75 Pcs Crochet Kit

## ALL YOU NEED IN ONE BOX



Image: A detailed layout of all 75 pieces included in the kit, showing hooks, yarn, and various accessories.

## SETUP AND ORGANIZATION

Upon receiving your kit, unpack all components and familiarize yourself with each item. The large yarn storage bag is designed for efficient organization.

### Yarn Bag Features:

- **Main Compartment:** Store your yarn skeins here. The bag can accommodate multiple large skeins.

- **Exterior Pockets:** Three front pockets are ideal for storing crochet hooks, knitting needles, and the small organizer case. A transparent pocket allows for quick identification of smaller items like stitch markers or yarn needles.
- **Mesh Pocket:** A breathable mesh pocket on the side is suitable for items requiring ventilation or quick access.
- **Yarn Feed Openings:** The top of the bag features four openings designed to feed yarn smoothly, preventing tangles and snags during your projects.

# CAPACITÉ LUGU

## SAC À OUTILS DE TRICOT



Image: The yarn bag highlighting its main compartment, three front pockets for hooks, a transparent pocket, and four yarn feed openings on top.

## OPERATING INSTRUCTIONS

### Using the Yarn Bag:

1. **Loading Yarn:** Open the main zipper compartment and place your yarn skeins inside.
2. **Feeding Yarn:** For active projects, thread the end of your yarn through one of the four top openings. This keeps your yarn contained and prevents it from rolling away or tangling.

3. **Accessing Tools:** Utilize the exterior pockets to keep your crochet hooks, stitch markers, and other small tools readily accessible.

## Carrying the Bag:

The yarn bag offers multiple carrying options for convenience:

- **Top Handle:** Use the reinforced, non-slip top handle for hand-carrying.
- **Shoulder Strap:** Attach the removable and adjustable shoulder strap for shoulder or cross-body carrying. Adjust the strap length for comfort.



Image: Demonstrates the versatility of the yarn bag, showing it being carried by its top handle and with the detachable shoulder strap.

## Using Crochet Hooks and Accessories:

Select the appropriate hook size for your yarn and project. The kit includes a range of sizes for various yarn weights and stitch requirements. Use stitch markers to keep track of your progress, and yarn needles for weaving in ends. The yarn cutter provides a safe and convenient way to trim yarn.

## ***Easy to Carry***

**Comfortable velcro  
reinforced handle**

**Detachable shoulder  
strap**



Image: A selection of the 20 acrylic yarn skeins, showing their vibrant colors and indicating material (100% acrylic) and weight (35g / 1.23oz, #4 Medium Worsted).

## **MAINTENANCE**

---

### **Cleaning the Yarn Bag:**

The yarn bag is made from durable, waterproof polyester. To clean, wipe with a damp cloth and mild soap if necessary. Allow to air dry completely. Do not machine wash or tumble dry.

# Tissus de haute qualité



Tissu cationique 600d



Tissu imperméable interne



Résistant à l'abrasion et aux froissements



Image: A close-up view of the yarn bag's fabric, illustrating its cationic 600D material, internal waterproof layer, and resistance to abrasion and wrinkles.

## Storing Tools and Yarn:

Always store your crochet hooks and small accessories in the provided organizer case or the bag's designated pockets to prevent loss or damage. Keep yarn in the main compartment, away from direct sunlight and moisture, to maintain its quality.

## TROUBLESHOOTING

### Yarn Tangling in Bag:

Ensure yarn is fed through the designated top openings. If using multiple colors, separate them within the bag to prevent intertwining. The smooth openings are designed to minimize friction and tangles.

### Lost Small Accessories:

Utilize the small organizer case for items like stitch markers, yarn needles, and hook point protectors. The transparent pocket on the bag also helps keep frequently used small items visible and secure.

## SPECIFICATIONS

|                  |                                            |
|------------------|--------------------------------------------|
| Brand            | DoubleCare                                 |
| Model Number     | DE-Crochet Bag-Blue                        |
| Color            | Blue                                       |
| Item Weight      | 1.25 Kilograms                             |
| Number of Pieces | 75                                         |
| Yarn Material    | 100% Acrylic                               |
| Yarn Weight      | 35g / 1.23oz per skein (#4 Medium Worsted) |
| Bag Dimensions   | Approximately 33 x 28 cm                   |

## WARRANTY INFORMATION

Specific warranty details for the DoubleCare 75-Piece Crochet Kit are not provided in this manual. Please refer to the product packaging or contact the retailer/manufacturer directly for information regarding warranty coverage and terms.

## CUSTOMER SUPPORT

For any questions, concerns, or assistance with your DoubleCare 75-Piece Crochet Kit, please contact DoubleCare customer service through the retailer's platform or visit the official DoubleCare website for support options.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question