

## Luna Pro Age Massager

# Golden Glow Luna Pro Age Massager User Manual

## 1. INTRODUCTION

---

Thank you for choosing the Golden Glow Luna Pro Age Massager. This device is designed to provide a relaxing and invigorating experience with its ergonomic design, multiple modes, and convenient features. Please read this manual carefully before first use to ensure proper operation, maintenance, and safety.

## 2. SAFETY INFORMATION

---

- Do not use the massager on broken, swollen, or inflamed skin.
- Consult a physician before use if you have any medical conditions, are pregnant, or have a pacemaker.
- Keep out of reach of children.
- Do not immerse the charging port in water. Ensure the charging port is dry before connecting the charger.
- Discontinue use if you experience any discomfort or pain.
- Use only the provided charging cable or a compatible USB charger.

## 3. PACKAGE CONTENTS

---

- 1 x Golden Glow Luna Pro Age Massager
- 1 x USB Charging Cable
- 1 x User Manual

## 4. PRODUCT OVERVIEW

---

The Golden Glow Luna Pro Age Massager features a compact, ergonomic design for comfortable handling and effective use. It offers both powerful suction and intense vibration functionalities.



Image 4.1: The Golden Glow Luna Pro Age Massager, showcasing its ergonomic shape and suction head.

### Key Features:

- **Compact Portable Design:** Lightweight and easy to carry, ideal for travel.
- **USB Rechargeable:** Convenient charging via USB.
- **Ergonomic Design:** Shaped for comfortable grip and optimal application.
- **Waterproof and Easy to Clean:** Designed for simple maintenance and hygiene.
- **Low Noise Operation:** Provides a quiet and serene massage experience.

# Product features



Image 4.2: Detailed view highlighting the powerful suction and intense vibration capabilities of the massager.

## 5. CHARGING THE DEVICE

The Golden Glow Luna Pro Age Massager is equipped with a magnetic charging port for convenience.

1. Ensure the massager is turned off before charging.
2. Locate the magnetic charging port on the device.
3. Connect the USB charging cable to the magnetic port. The cable will snap into place.
4. Plug the other end of the USB cable into a compatible power source such as a PC, car charger, power bank, or a USB wall adapter.
5. The indicator light will illuminate during charging and turn off or change color when fully charged (specific behavior may vary).
6. A full charge typically takes approximately 2-3 hours.

# Product Introduction



Image 5.1: Illustration of the magnetic charging method and compatible USB power sources.

## 6. OPERATING INSTRUCTIONS

Familiarize yourself with the control buttons located on the massager for power, suction, and vibration functions.

# Product Size




Image 6.1: Close-up of the massager's control panel, indicating the power, suction, and vibration buttons.

## Power On/Off:

- To turn on: Press and hold the power button (usually marked with a power symbol) for approximately 3 seconds.
- To turn off: Press and hold the power button for approximately 3 seconds.

## Adjusting Modes:


The massager offers a variety of vibration and suction patterns.

- Once powered on, press the 'suction' button to cycle through the 10 available suction modes.
- Press the 'vibrating' button to cycle through the 10 available vibration modes.
- Experiment with different modes to find your preferred setting.

# 10 Kinds



## 10 vibration modes



## 10 suction modes




Image 6.2: Visual representation of the 10 vibration modes and 10 suction modes available on the device.

## 7. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your massager and ensure hygienic use.

- The massager is waterproof, making it easy to clean.
- After each use, wash the massager with mild soap and warm water.
- Rinse thoroughly to remove all soap residue.
- Dry the massager completely with a soft, lint-free cloth before storing.
- Do not use alcohol, petroleum-based cleaners, or abrasive materials, as these may damage the silicone.
- Store the massager in a clean, dry place away from direct sunlight and extreme temperatures.

## 8. TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Press and hold the power button for 3 seconds.

- **Weak vibration/suction:** The battery might be low. Recharge the device.
- **Charging issues:** Ensure the magnetic charging cable is properly connected and the USB power source is functional. Check for any debris in the charging port.
- If problems persist, please refer to the warranty and support section.

## 9. SPECIFICATIONS

Attribute	Detail
Product Name	Golden Glow Luna Pro Age Massager
Model Number	B0FSXVRQF6
Color Options	Purple, Rose Red
Dimensions	15.5 × 7.5 × 4.5 cm (approx. 6.1 x 2.95 x 1.77 inches)
Unit Weight	0.159 kg (approx. 0.35 lbs)
Charging	USB Magnetic Charging
Waterproof Rating	Yes
Vibration Modes	10
Suction Modes	10



Image 9.1: The Golden Glow Luna Pro Age Massager available in both purple and rose red colors.

## 10. WARRANTY AND SUPPORT

---

For any questions, concerns, or issues regarding your Golden Glow Luna Pro Age Massager, please contact the seller or manufacturer through your purchase platform. Please retain your proof of purchase for warranty claims, if applicable.