

[Manuals.plus](#) /

> [weselon](#) /

> weselon Farmhouse End Table with Carved Floral Door (B0FSYM497V) Instruction Manual

weselon B0FSYM497V

weselon Farmhouse End Table with Carved Floral Door (B0FSYM497V) Instruction Manual

Model: B0FSYM497V | Color: Antique Black-brown

1. PRODUCT OVERVIEW

The weselon Farmhouse End Table is a versatile furniture piece designed to complement various home decors, including farmhouse, traditional, and modern styles. It features a carved floral door, fluted side detailing, and an adjustable interior shelf for flexible storage. Crafted from durable MDF and supported by solid pine wood legs, this table is built for stability and longevity.



Image 1.1: The weselon Farmhouse End Table in Antique Black-brown, showcasing its carved floral door and overall design.

Key Features:

- **Elegant Carved Design:** High-gloss door with intricate floral embossing and classic fluted side detailing.
- **Durable Construction:** Crafted from premium, scratch-resistant MDF and solid pine wood legs.
- **Adjustable Storage:** Features an adjustable shelf for customizable interior space.
- **Versatile Use:** Suitable as a nightstand, sofa table, end table, or entryway accent cabinet.
- **Raised Footing:** Protects against floor moisture and adds stability.

2. SAFETY INFORMATION

WARNING: This product requires assembly. Follow the included instructions carefully to avoid injury. Do not exceed the maximum weight recommendation of 100 pounds to maintain stability. Ensure the table is properly assembled and stable before use.

- Always assemble the product on a soft, clean surface to prevent scratches.

- Ensure all screws and fasteners are securely tightened before use.
- Do not stand or sit on the table.
- Keep small parts away from children during assembly.

3. SETUP AND ASSEMBLY

The weselon Farmhouse End Table is designed for easy assembly. All necessary hardware and clear instructions are included in the package. Assembly typically takes approximately one hour for a single person, potentially less with assistance.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface. Verify all parts and hardware are present against the included parts list.
2. **Assemble Side Panels:** Attach the side panels to the base using the provided screws and dowels. Ensure proper alignment.
3. **Attach Top Panel:** Secure the top panel to the assembled side panels.
4. **Install Legs:** Attach the solid pine wood legs to the bottom of the table. These provide a strong foundation and protect your floors.
5. **Install Adjustable Shelf:** Insert the shelf support pegs into the desired height holes inside the cabinet. Place the adjustable shelf on top of the pegs.
6. **Attach Door Hinges:** Secure the quality metal hinges to the cabinet doors and the main frame.
7. **Install Door Knobs:** Attach the brass-looking metal door knobs to the carved floral doors.
8. **Install Magnetic Latches:** Screw the magnetic latch components onto the doors and the inside of the cabinet frame to ensure the doors close securely.
9. **Cover Holes:** Use the provided stickers to cover any visible screw holes for a finished look.



Image 3.1: Detailed product dimensions, including height, width, and depth, and weight capacities for the top and interior shelf.

Product Details



Metal Handle

Exquisite Embossed
Carving Design



Anti-tipping Device

Raised Sturdy Footing



Image 3.2: Interior view of the cabinet with the adjustable shelf, illustrating the three possible height settings for customized storage.

Assembly Video:

Video 3.1: Official product video from Weselon Furniture demonstrating the features and assembly process of the Farmhouse End Table.

4. OPERATING INSTRUCTIONS

The weselon Farmhouse End Table is designed for straightforward use, offering both surface space and enclosed storage.

Using the Storage Cabinet:

- **Opening/Closing Doors:** Gently pull the brass knobs to open the two carved floral doors. The magnetic latch system ensures the doors remain securely closed when not in use.
- **Adjusting Shelf Height:** To adjust the interior shelf, remove all items from the shelf. Carefully lift the shelf and reposition the four support pegs into the desired holes on the cabinet sides. Ensure all four pegs are securely in place before placing the shelf back down.
- **Weight Capacity:** The tabletop can support up to 100 pounds. The adjustable shelf is designed for lighter items such as books, remotes, or small electronics. Do not overload the shelves.



Image 4.1: The end table in use, demonstrating its spacious top surface and practical interior storage for various

items.

5. MAINTENANCE

To ensure the longevity and appearance of your weselon Farmhouse End Table, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage, especially since the product is not stain-resistant.
- **Protection:** Use coasters under drinks and placemats under decorative items to protect the tabletop from scratches and heat.
- **Stability Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Floor Protection:** The raised footing helps protect against floor moisture. For additional protection on delicate flooring, consider adding felt pads to the bottom of the legs.

6. TROUBLESHOOTING

If you encounter any issues with your weselon Farmhouse End Table, refer to the following common troubleshooting tips:

Common Issues:

- **Wobbly Table:** Ensure all screws and fasteners are fully tightened. Check that the table is on a level surface. Adjust the position if needed.
- **Doors Not Closing Properly:** Verify that the magnetic latches are correctly installed and aligned. Check the door hinges for any looseness or misalignment and adjust as necessary.
- **Difficulty During Assembly:** Review the assembly instructions carefully. Ensure all parts are oriented correctly. If a power drill was used, ensure screws are not overtightened, which can strip holes.
- **Scratches or Chips:** For minor cosmetic damage, touch-up pens or furniture repair kits matching the Antique Black-brown finish may be used.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Brand	weselon
Model Number	B0FSYM497V
Product Dimensions (D x W x H)	21.65" x 23.9" x 25.59"
Item Weight	47 Pounds
Maximum Weight Recommendation (Top)	100 Pounds
Frame Material	Engineered Wood
Leg Material	Solid Pine Wood
Color	Antique Black-brown
Shape	Square
Table Design	End Table
Number of Doors	2
Number of Shelves	2 (1 adjustable)
Special Features	Adjustable Interior Shelf, Carved Floral Door Design, Fluted Sides, Raised Footing
Assembly Required	Yes

8. WARRANTY AND SUPPORT

For warranty information or customer support regarding your weselon Farmhouse End Table, please refer to the contact details provided at the point of purchase or visit the official weselon website. Keep your purchase receipt for any warranty claims.