Gizoon KC71

Gizoon KC71 Kitchen Island with Drop Leaf and Trash Storage

Model: KC71 | Brand: Gizoon

1. Product Overview

The Gizoon KC71 Kitchen Island is a multi-functional and mobile storage solution designed to enhance kitchen utility and organization. It features a durable countertop, a convenient drop-leaf extension, a concealed trash can cabinet, and various storage compartments including a drawer, adjustable shelves, and a spice rack. Equipped with smooth-rolling, lockable wheels, this island offers flexibility in placement and stability during use.



Figure 1.1: Fully assembled Gizoon KC71 Kitchen Island with storage compartments open.



Figure 1.2: Overview of the various storage options available on the kitchen island.

2. Important Safety Information

- Ensure all parts are properly secured before and during use to prevent instability.
- Do not allow children to play on, with, or around the kitchen island.
- Exercise caution when moving the island to prevent tipping or accidental collisions.
- Be careful around sharp edges during assembly and use.
- Do not exceed the weight capacity of the shelves or countertop.
- Keep liquids away from electrical components if any are added to the island.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. Refer to the included parts list in your

physical manual. If any parts are missing or damaged, contact customer support immediately.



Figure 3.1: Dimensional breakdown of the kitchen island components.

The package typically includes:

- Main body panels (sides, back, bottom, top)
- Drawer components
- Door panels and hinges
- Adjustable shelves and shelf pins
- Drop leaf countertop and support brackets
- Trash cabinet door and tilt mechanism
- Casters (wheels), two with locking brakes
- Hardware pack (screws, dowels, cam locks, handles, etc.)
- Assembly instructions

4. Assembly Instructions

Assembly requires two or more people and approximately 3-4 hours. Clear a spacious area for assembly and keep all parts and hardware organized. Follow the numbered steps in the provided physical instruction manual carefully.

General Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all panels and hardware. Match each piece to the corresponding label in the instruction manual.
2. **Assemble Base Structure:** Connect the side panels to the bottom panel using the specified hardware.
3. **Install Casters:** Attach the five metal casters to the bottom of the island. Ensure the two casters with locking mechanisms are placed on the front for easy access.
4. **Construct Internal Compartments:** Assemble the internal dividers and shelf supports.
5. **Assemble and Install Drawer:** Follow the specific steps for drawer assembly, then install it into its designated slot.
6. **Attach Doors:** Secure hinges to the doors and then attach the doors to the main cabinet body.
7. **Install Trash Cabinet Mechanism:** Assemble the tilt-out trash cabinet door and its mechanism.
8. **Attach Drop Leaf Countertop:** Secure the drop leaf extension and its support brackets to the main countertop.
9. **Install Handles and Knobs:** Attach all handles and knobs to the drawer and doors.
10. **Final Adjustments:** Ensure all connections are tight and the island is stable. Adjust door hinges if necessary for proper alignment.



Figure 4.1: Detail of the drop leaf support mechanism during assembly.




Figure 4.2: Assembly detail for the tilt-out trash cabinet.



Figure 4.3: Adjustable shelf pin holes for customizable storage.

5. Operating Your Kitchen Island

5.1 Using the Drop Leaf Countertop

To extend the countertop, gently pull the drop leaf upwards until the support brackets lock into place. To fold it down, release the locking mechanism on the brackets and carefully lower the leaf. This expands the usable surface area for food preparation or dining.

MULTIPLE STORAGE SPACE



Figure 5.1: Extending the drop leaf countertop for additional workspace.



Figure 5.2: Kitchen island with drop leaf extended, ready for use.

5.2 Utilizing the Concealed Trash Cabinet

The island features a tilt-out cabinet designed to discreetly store a trash can (not included). To access, pull the cabinet door forward from the top. To close, push the door back until it is flush with the island's front. This helps contain odors and keeps your kitchen tidy.



Figure 5.3: The tilt-out trash cabinet in the open position.

5.3 Adjusting Shelves

The internal shelves are adjustable to accommodate items of various heights. To adjust a shelf, remove all items, then carefully lift the shelf and remove the four shelf pins. Reinsert the pins into the desired holes at the new height, ensuring they are level, and then place the shelf back on the pins.



Figure 5.4: Adjustable shelves providing flexible storage options.

5.4 Moving and Securing the Island

The island is equipped with five casters for easy mobility. To move the island, ensure the locking brakes on the two front casters are disengaged. Once the island is in the desired position, engage the locking brakes by pressing down on the lever on each brake to secure the island in place and prevent unwanted movement.



Figure 5.5: Detail of the casters, including the lockable wheels.

6. Care and Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or water damage, especially on the countertop.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Avoid Excessive Heat/Moisture:** Do not place hot items directly on the countertop without protection. Avoid prolonged exposure to high humidity.
- **Moving:** When moving the island, lift slightly if possible, rather than dragging, to prevent damage to the casters or floor.

7. Troubleshooting

- **Island is Wobbly:** Ensure all assembly screws are fully tightened. Check that the floor surface is even.
- **Drawer Does Not Slide Smoothly:** Verify that the drawer slides are correctly installed and aligned. Check for any obstructions in the tracks.
- **Doors Are Misaligned:** Adjust the hinges on the cabinet doors. Most hinges allow for minor adjustments to align doors properly.
- **Drop Leaf Does Not Lock:** Ensure the support brackets are fully extended and engaged. Check for any debris obstructing the locking mechanism.
- **Casters Not Rolling/Locking:** Clean any debris from the caster wheels. Ensure the brake levers are fully engaged or disengaged as intended.

If you encounter issues not listed here or require further assistance, please contact customer support.

8. Product Specifications

Feature	Detail
Model Number	KC71
Brand	Gizoon
Product Dimensions (D x W x H)	31.9" x 51.6" x 35.4" (with drop leaf extended)
Item Weight	117.5 pounds
Material	Engineered Wood
Color	White
Shelf Type	Adjustable
Assembly Required	Yes

9. Warranty and Customer Support

Gizoon products are manufactured with quality and customer satisfaction in mind. For specific warranty details, please refer to the documentation included with your purchase or visit the official Gizoon website. If you have any questions, require replacement parts, or need assistance with assembly or operation, please contact Gizoon customer support. Our team is available to provide answers within 24 hours.

Contact Information: Please refer to your purchase receipt or the Gizoon brand store for the most current customer service contact details.

© 2026 Gizoon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question