

[Manuals.plus](#) /

› [VAL CUCINA](#) /

› VAL CUCINA 6-in-1 Retro Air Fryer Toaster Oven Combo (Model VCO12TMB) User Manual

VAL CUCINA VCO12TMB

VAL CUCINA 6-in-1 Retro Air Fryer Toaster Oven Combo User Manual

Model: VCO12TMB

Brand: VAL CUCINA

INTRODUCTION

Thank you for choosing the VAL CUCINA 6-in-1 Retro Air Fryer Toaster Oven Combo. This versatile appliance is designed to simplify your cooking with six functions: air fry, bake, toast, roast, reheat, and broil. Its compact 12.7 QT design is ideal for small kitchens, apartments, dorms, and RVs, capable of fitting a 9-inch pizza or 4 slices of toast. Please read this manual thoroughly before use to ensure safe and efficient operation.



Image: The VAL CUCINA 6-in-1 Retro Air Fryer Toaster Oven Combo in dark grey, showcasing its compact design and various cooking functions.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs. Always use oven mitts or potholders when handling hot materials.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.

- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for other than intended use.

KEY PRODUCT FEATURES

- **6-in-1 Cooking Modes:** Air fry, bake, toast, roast, reheat, and broil in one compact unit.
- **Even Toasting:** Hexagon hybrid heating element ensures over 92% toasting uniformity for consistent results.
- **Compact Design:** 12.7 QT capacity, ideal for small spaces, fitting 4 slices of toast or a 9-inch pizza.
- **Simple Knob Control:** Intuitive manual knobs for easy selection of time, temperature, and cooking mode.
- **Durable Enamel Baking Pan:** Food-safe, scratch-resistant, high-heat resistant, and PFAS-free for easy cleanup.



Perfect Toast Every Morning

Hexagon Heat eliminates the hot spots that ruin your toast, ensuring

92%
uniform browning.

Image: Illustration of the hexagon heating element providing uniform heat distribution for perfect toast.

360°

Rapid Air Circulation

450°F Superheated
air circulates rapidly for
instant, rigid crisping



Image: Visual representation of 360-degree rapid air circulation for efficient air frying.

WHAT'S INCLUDED

Your VAL CUCINA Air Fryer Toaster Oven comes with the following accessories:

- Air Fry Basket
- Baking Pan (Enamel)
- Crumb Tray
- Wire Rack

Multipurpose Use


With Full Accessories



▲
Air Fry Basket



▲
Enamel Baking Pan



▲
Baking Rack



▲
Removable Crumb Tray

Image: A visual display of the Air Fry Basket, Enamel Baking Pan, Baking Rack, and Removable Crumb Tray.

SETUP GUIDE

1. **Unpack:** Carefully remove the appliance and all accessories from the packaging. Remove any protective film or stickers.
2. **Clean:** Wash the Air Fry Basket, Baking Pan, Wire Rack, and Crumb Tray with warm, soapy water. Wipe the interior and exterior of the oven with a damp cloth. Dry all parts thoroughly.
3. **Placement:** Place the oven on a stable, heat-resistant, and level surface. Ensure there is adequate space (at least 4 inches) on all sides and above the oven for proper ventilation. Do not place near flammable materials.
4. **Initial Run:** Before first use, operate the oven empty on the "Bake" function at 400°F (200°C) for 15 minutes to burn off any manufacturing residues. A slight odor or smoke is normal during this process. Ensure the area is well-ventilated.

OPERATING YOUR OVEN

Control Panel Overview

The VAL CUCINA Air Fryer Toaster Oven features three intuitive control knobs:

- **Temperature Knob:** Adjusts cooking temperature from 200°F to 450°F.
- **Function Knob:** Selects the desired cooking mode (Air Fry, Bake, Toast, Roast, Reheat, Broil).
- **Timer Knob:** Sets the cooking time up to 60 minutes. For toast, specific shade settings are available.

No-Slip Grip

Textured dials ensure easy operation, even with wet or messy hands.



Image: A hand adjusting the textured control knobs, demonstrating ease of use.

Cooking Modes

Air Fry:

Ideal for crispy foods like fries, chicken wings, and vegetables. Uses rapid air circulation for a fried texture with less oil.

Bake:

Perfect for cakes, cookies, casseroles, and other baked goods.

Toast:

For bread, bagels, and frozen waffles. Adjust the timer knob to select desired toast shade.

Roast:

Suitable for roasting meats and vegetables, providing even cooking.

Reheat:

Gently warms leftovers without drying them out.

Broil:

For quick browning, melting cheese, or cooking thin cuts of meat.

Video Demonstration

Your browser does not support the video tag.

Video: Official VAL CUCINA demonstration of the 6-in-1 Air Fryer Toaster Oven Combo, highlighting its various functions and ease of use.

CLEANING AND CARE

Regular cleaning will ensure the longevity and optimal performance of your appliance.

1. **Always unplug** the oven and allow it to cool completely before cleaning.
2. **Accessories:** The Air Fry Basket, Enamel Baking Pan, Wire Rack, and Crumb Tray are dishwasher safe or can be washed by hand with warm, soapy water. The enamel baking pan is designed for easy cleaning.
3. **Interior:** Wipe the interior walls with a damp cloth and mild liquid soap. For stubborn stains, use a non-abrasive cleaner. Avoid using steel wool or abrasive pads.
4. **Exterior:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners or scourers as they may damage the finish.
5. **Crumb Tray:** Empty the crumb tray regularly to prevent grease buildup and potential fire hazards.

100% Toxic-Free Cooking

Bake with peace of mind using our PFAS-free, high-heat/scratch resistant enamel.



PFAS Free



Instant Clean



Built to Last

Image: A hand cleaning the durable enamel baking pan, demonstrating its ease of maintenance.

TROUBLESHOOTING GUIDE

If you encounter any issues with your VAL CUCINA Air Fryer Toaster Oven, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; timer not set.	Ensure the power cord is securely plugged into a working outlet. Turn the timer knob past 20 minutes, then back to the desired time.
Food is not cooking evenly.	Overcrowding the basket/pan; incorrect temperature or time setting.	Avoid overcrowding; cook in smaller batches if necessary. Adjust temperature and time according to recipe or food type. Ensure proper rack position.

Problem	Possible Cause	Solution
Smoke coming from the oven.	Food residue or grease buildup; high-fat foods.	Clean the interior and accessories thoroughly. For high-fat foods, use the baking pan to catch drips and ensure proper ventilation.

TECHNICAL SPECIFICATIONS

- **Brand:** VAL CUCINA
- **Model Name:** VCO12TMB
- **Capacity:** 12.7 Quarts (12L)
- **Product Dimensions:** 12.7"D x 11.6"W x 11.8"H
- **Item Weight:** 11.6 Pounds (5.3 kg)
- **Wattage:** 1450 watts
- **Temperature Range:** 200-450°F Degrees Fahrenheit
- **Control Type:** Knob Control
- **Material:** Galvanized Steel (Body), Metal and Tempered Glass (Door)
- **Special Features:** 360° Air Frying, 6 Cooking Modes, Enamel Baking Pan, Hexagon Hybrid Heating Element, Multi-level Cooking

REAL COUNTERTOP SIZE, SPACE-SAVING DESIGN

Compact 12.7QT oven — ideal for small kitchens, apartments & dorms



SEE IT IN YOUR KITCHEN

Compact size fits most countertops perfectly.



Image: Detailed dimensions of the compact 12.7 QT oven, showing its height, width, and depth.

WARRANTY AND CUSTOMER SUPPORT

Your purchase automatically comes with **1 year of warranty**. You can extend your warranty by 1 extra year, for a total of 2 years, by registering your product within 14 days of purchase.

For further assistance, troubleshooting, or warranty claims, please contact VAL CUCINA customer support through their official website or the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can the VAL CUCINA VCO12TMB Air Fryer Toaster Oven be used with 220V power in South Korea?

Based on the technical specifications for the VAL CUCINA VCO12TMB, this appliance is designed for the North American market with a power rating of 1450 watts. While the manual does not explicitly state the...

[Read full answer](#)