

[Manuals.plus](#) /

> [FELEMAN](#) /

> FELEMAN Model 122 12-inch Portable Dual Screen Car DVD Player Instruction Manual

FELEMAN 122

FELEMAN Model 122 12-inch Portable Dual Screen Car DVD Player Instruction Manual

Model: 122

INTRODUCTION

This manual provides detailed instructions for the proper setup, operation, and maintenance of your FELEMAN Model 122 12-inch Portable Dual Screen Car DVD Player. Please read this manual thoroughly before using the device to ensure optimal performance and safety. Keep this manual for future reference.

PACKAGE CONTENTS

Verify that all items listed below are included in your package. If any items are missing or damaged, please contact customer support.

- FELEMAN 12-inch Portable Dual Screen Car DVD Player (2 units)
- AV Cable
- Car Charger
- AC Adapter
- RCA Cable
- AUX Cable
- User Manual
- Headrest Straps (6 units)
- Remote Control (2 units)
- Mounting Bracket (2 units)
- Quick Start Guide
- Screwdriver

Package Listing



AV Cable



Car Charger



AC Adapter



RCA Cable



AUX Cable



User Manual



Headrest Strap * 6



Remote Control * 2



Mounting Bracket * 2



Quick Start Guide



Screwdriver

Figure 1: All components included in the FELEMAN Model 122 package.

SETUP AND INSTALLATION

Headrest Installation

The FELEMAN Model 122 is designed for easy installation on car headrests without requiring special tools. Follow these steps:

1. **Install the Base:** Attach the mounting bracket base to the headrest posts.
2. **Align and Tighten:** Align the holes and use the provided screwdriver to tighten the screws, securing the bracket firmly.
3. **Insert Player:** Slide the portable DVD player onto the installed mounting bracket.
4. **Adjust Screen Angle:** Loosen the screw on the bracket to adjust the screen to your desired viewing angle (up to 135 degrees), then tighten to secure.

For additional security, use the provided headrest straps to further stabilize the players.

Fast and Easy Installation




Figure 2: Step-by-step guide for headrest mounting.

Powering the Device

The device features a built-in rechargeable battery for portable use. For extended use or charging, three power options are available:

- **Built-in Battery:** Provides power for cord-free operation.
- **AC Adapter:** Connect to a standard wall outlet for home use or charging.
- **Car Charger:** Connect to your vehicle's 12V power outlet for use in the car or charging on the go.



Figure 3: Available power and charging methods.

OPERATING INSTRUCTIONS

Dual Screen Functionality

The FELEMAN Model 122 features two independent 12-inch Full HD (1080P) screens. You can configure them to:

- **Watch Two Different Movies:** Each player operates independently, allowing different content to be viewed on each screen.
- **Share the Same Movie:** Connect the two players using the included AV cable to synchronize playback and display the same content on both screens.

One Order to Get Double Happiness




Figure 4: Dual screen viewing options.

HDMI Input (Screen Mirroring)

The HDMI input port allows you to connect external devices and mirror their content onto the DVD player's screen in up to 1080P. This is useful for playing videos, games, or shows from smartphones, tablets, laptops, or gaming consoles (e.g., Nintendo Switch).

Note:

- This device supports HDMI **input only**, not output.
- HDMI input is applicable only to devices with HDMI output functionality.
- A 3-in-1 smartphone to HDMI cable is required for smartphone mirroring (not included).

HDMI Input--Screen Mirroring

Sync up To 1080P Full HD video to the player via 3 in 1 smartphone to HDMI Cable(not included)



Raspberry Pi



Xbox



PlayStation



Switch



Phone



Computer



Kindle Fire



TV Stick



Note: 1.Only support HDMI input, not output.
2.HDMI input only applicable to the devices with HDMI output function.

Figure 5: Using the HDMI input for screen mirroring.


Media Compatibility and Auto-Resume

The player supports a wide range of media formats:

- **DVD Formats:** DVD, CD, VCD, SVCD, DVD±R, DVD±RW, CD±R, CD±RW (Blu-Ray discs are not supported).
- **Video Formats (via USB):** VOB, AVI, FLV, DAT, XVID, DIVX, MPEG 1, MPEG 2 (USB port supports up to 32GB).
- **Audio Formats:** MP3, WMA.
- **Image Formats:** JPG, JPEG.

The **Auto-Resume** function remembers the last playback position. If the player is powered off or a disc is removed, playback will resume from where it stopped when powered on again.

Last Memory & Multi-Formats



Video Formats:

VOB / AVI / FLV / DAT / XVID / DIVX / MPEG 1, MPEG 2



DVD Formats:

DVD, CD, VCD, SVCD, DVD±R, DVD±RW, CD±R, CD±RW (Blu-Ray not supported)



Audio Formats:

MP3, WMA



Image Formats:

JPG/JPEG

Figure 6: Media format compatibility and auto-resume feature.

Audio and Viewing Experience

- **Built-in Speakers:** Each player has dual front-facing speakers for clear audio.
- **Headphone Jacks:** Individual headphone jacks on each screen allow for private listening.
- **Adjustable Viewing Angles:** Screens can be tilted to optimize viewing comfort.

Syncing to a Television

You can connect the portable DVD player to a television using the included RCA cable to enjoy content on a larger screen. Connect the RCA cable from the DVD player's AV output to the corresponding AV input ports on your television.

Sync Screen to TV

Enjoy movies with your family



Figure 7: Connecting the DVD player to a TV.

Official Product Video

Your browser does not support the video tag.

Video 1: An official product video demonstrating the features of the FELEMAN Car DVD Player Dual Screen for Kids.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the screens and exterior of the players. Do not use liquid cleaners or abrasive materials.
- **Disc Care:** Handle discs by their edges. Store them in their cases to prevent scratches. Clean discs with a soft, lint-free cloth, wiping from the center outwards.
- **Storage:** When not in use, store the players in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in active use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Player does not power on.	Low battery or power connection issue.	Ensure the device is charged or connected to a power source (AC adapter or car charger). Check power cables for secure connection.
No image on screen.	Incorrect input source, disc issue, or cable connection.	Check if the correct input source is selected. Ensure the disc is clean and inserted correctly. Verify AV or HDMI cables are securely connected.
No sound.	Volume too low, mute activated, or audio cable issue.	Increase volume. Check if the device is muted. If using external speakers or headphones, ensure they are properly connected.
Disc skipping or freezing.	Dirty or scratched disc, or player movement.	Clean the disc. Try a different disc. Ensure the player is stable during use, especially in a moving vehicle.
HDMI input not working.	Source device not compatible or cable issue.	Ensure the connected device has HDMI output. Verify the HDMI cable is functional and securely connected. Remember the player supports HDMI input only .

SPECIFICATIONS

Feature	Detail
Model Number	122
Screen Size	12 Inches
Display Type	LED
Color	Black
Media Type	CD-R, CD-ROM, CD-RW, DVD+RW, DVD-R
Batteries	2 Lithium Ion batteries required (included)
Item Weight	7.48 pounds
Package Dimensions	17.4 x 10.43 x 5.67 inches
Manufacturer	FELEMAN

WARRANTY INFORMATION

FELEMAN products are covered by a manufacturer's warranty. Please refer to the warranty card included in your package or visit the official FELEMAN website for detailed information regarding warranty terms, conditions, and registration procedures. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact FELEMAN customer support. Contact details can typically be found on the product packaging, the official FELEMAN website, or the warranty card.

For online resources, you may visit the FELEMAN store on Amazon: [FELEMAN Store](#)

