Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

comiso M11

comiso M11 Wearable Bluetooth Speaker User Manual

Model: M11

1. Introduction

Thank you for choosing the comiso M11 Wearable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it carefully before use.

Key Features:

- Powerful 5W Stereo Sound
- Advanced Bluetooth 6.0 Connectivity
- IPX7 Waterproof Rating
- Integrated Microphone for Hands-Free Calls
- True Wireless Stereo (TWS) Pairing Capability
- Secure Clip-On Wearable Design
- Up to 10 Hours Playtime
- Compact and Lightweight Design




Image: The comiso M11 Wearable Bluetooth Speaker, highlighting its compact and portable design.

2. Setup

2.1 What's in the Box

- comiso M11 Wearable Bluetooth Speaker
- USB-C Charging Cable
- User Manual

2.2 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided USB-C cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status.



Image: The comiso M11 speaker connected to a USB-C charging cable.

2.3 Power On/Off

- **To Power On:** Press and hold the Power button for approximately 3 seconds until you hear an audible prompt and the indicator light illuminates.
- **To Power Off:** Press and hold the Power button for approximately 3 seconds until you hear an audible prompt and the indicator light turns off.

2.4 Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode (the indicator light will flash).
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "M11" from the list.
4. Once connected, you will hear a confirmation sound, and the indicator light will remain solid.



Image: A smartphone screen showing the M11 speaker available for Bluetooth pairing.

Your browser does not support the video tag.

Video: An overview of the comiso M11 Wearable Bluetooth Speaker, demonstrating its features and design.

3. Operating Instructions

3.1 Basic Controls

The speaker features intuitive buttons for controlling playback and calls:

- **Power Button:** Press and hold to power on/off. Short press to play/pause music or answer/end calls.
- **Volume Up (+):** Short press to increase volume. Long press for next track.
- **Volume Down (-):** Short press to decrease volume. Long press for previous track.



Image: Exploded view of the speaker components, illustrating the internal design for stereo sound.

3.2 Hands-Free Calling

With the built-in microphone, you can answer calls directly through the speaker:

- **Answer Call:** Short press the Power button when a call comes in.
- **End Call:** Short press the Power button during a call.
- **Reject Call:** Long press the Power button when a call comes in.




Image: A person driving, using the clip-on speaker for a hands-free phone call.

3.3 True Wireless Stereo (TWS) Pairing

For an enhanced stereo experience, you can pair two M11 speakers together:

1. Ensure both M11 speakers are powered on and not connected to any other Bluetooth device.
2. Triple-press the Power button on **one** of the speakers. This speaker will enter TWS pairing mode.
3. The speakers will automatically connect to each other. You will hear a confirmation sound.
4. Once paired, connect your device to one of the speakers via Bluetooth as described in section 2.4. Both speakers will now play audio in stereo.



Image: Two comiso M11 speakers positioned to illustrate True Wireless Stereo (TWS) pairing.

3.4 Wearing the Speaker

The M11 speaker features a robust clip-on design for hands-free use. Attach it to your shirt, backpack strap, belt, or jacket. A lanyard is also included for additional carrying options.



Image: The comiso M11 speaker with its clip mechanism, shown attached to various clothing items.

4. Maintenance

4.1 Waterproofing (IPX7)

The M11 speaker is IPX7 waterproof, meaning it can be immersed in water up to 1 meter (3 feet) for 30 minutes. This makes it suitable for outdoor activities and use near water. However, it is not designed for prolonged submersion or use in saltwater.

- Ensure the charging port cover is securely closed before exposing the speaker to water.
- Do not charge the speaker if it is wet.



Image: The comiso M11 speaker partially submerged in water, demonstrating its IPX7 waterproof capability.

4.2 Cleaning and Storage

- Clean the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If not used for extended periods, charge the speaker every 3 months to maintain battery health.

5. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.

Problem	Possible Cause	Solution
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device Bluetooth off; too far from device.	Ensure speaker is in pairing mode. Turn device Bluetooth off/on. Move speaker closer to device (within 33 feet).
No sound or low volume.	Volume too low on speaker or device; speaker not connected.	Increase volume on both speaker and device. Re-pair the speaker.
Poor Bluetooth range or connection drops.	Obstructions between speaker and device; interference.	Reduce distance between speaker and device. Avoid placing objects between them. Minimize other wireless interference.
Poor call quality (noise, double voice).	Environmental noise; microphone obstruction.	Use in a quieter environment. Ensure microphone is not covered.

6. Specifications

Model Number	Comiso-M11
Bluetooth Version	6.0
Output Power	5 watts
Frequency Response	20000 hertz
Water Resistance	IPX7
Battery Capacity	650 mAh
Playtime	Up to 10 hours (at 50% volume)
Bluetooth Range	Up to 33 feet (10 meters)
Dimensions (D x W x H)	1.3" x 1.9" x 2.9"
Material	ABS Plastic, Rubber, Silicone

7. Warranty

The comiso M11 Wearable Bluetooth Speaker comes with a **1-Year Limited Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.
Please retain your proof of purchase for warranty claims.

8. Support

If you encounter any issues or have questions not covered in this manual, please contact comiso customer support:

- **Website:** Visit the comiso Store on Amazon
- **Email:** Refer to your product packaging or the comiso website for the most current contact information.

When contacting support, please have your model number (M11) and purchase details ready.

© 2026 comiso. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FSZ7Z2NJ

More documents and user manuals: **https://manuals.plus/**