

artfone G6 Pro

artfone G6 Pro Red 4G LTE Flip Phone User Manual

Model: G6 Pro

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your artfone G6 Pro 4G LTE Flip Phone. Please read it thoroughly before operating the device to ensure proper functionality and to understand all features.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your product package:

- 1x artfone G6 Pro Mobile Phone (Battery not installed)
- 1x 1300mAh Battery
- 1x USB Charger Cable
- 1x User Manual
- 1x Charging Base/Stand



Image: Package contents of the artfone G6 Pro, showing the phone, battery, USB cable, user manual, and charging dock.

3. SETUP

3.1. SIM Card and Battery Installation

1. **Remove the Back Cover:** Gently pry open the back cover of the phone.
2. **Insert SIM Card:** Locate the Nano SIM card slot. Insert your Nano SIM card with the gold contacts facing down, ensuring it clicks into place.
3. **Insert Micro SD Card (Optional):** If desired, insert a Micro SD card (up to 64GB) into the designated slot for expanded storage.
4. **Install Battery:** Place the 1300mAh battery into the battery compartment, aligning the gold contacts with the phone's terminals.
5. **Replace Back Cover:** Securely reattach the back cover.

Phone memory:128MB+48MB

Support micro SD card up to 64GB maximally




Image: Internal view of the artfone G6 Pro, illustrating the Nano SIM slot, Micro SD card slot, and battery placement.

3.2. Charging the Phone

Your artfone G6 Pro can be charged using the included USB-C cable or the charging dock.

- **Using the Charging Dock:** Place the phone into the charging dock. Ensure the charging indicator appears on the screen.
- **Using the USB-C Cable:** Connect the USB-C cable directly to the phone's charging port and to a power adapter.



Image: Charging the artfone G6 Pro using either the USB-C cable or the charging dock.

3.3. Power On/Off

To power on or off, press and hold the red 'End Call' button until the phone vibrates or the screen lights up/shuts down.

4. OPERATING INSTRUCTIONS

4.1. Basic Call Functions

- **Making a Call:** Dial the number using the keypad and press the green 'Call' button.
- **Answering a Call:** Open the flip to answer, or press the green 'Call' button.
- **Ending a Call:** Close the flip to hang up, or press the red 'End Call' button.

Your browser does not support the video tag.

Video: Demonstrates basic call functions, including answering by flipping open the phone and ending calls by closing it.

4.2. Sending Text Messages

Navigate to the 'Message' menu, select 'New Message', enter the recipient's number or select from contacts, type your message using the keypad, and send.

4.3. User Interface Navigation

The phone features an intuitive UI with large icons and clear text. Use the navigation keys to scroll through menu options like Contacts, Tools, Message, SOS, Calendar, Settings, Internet, Multimedia, and Call logs.

User-friendly UI

Excellent operation



Image: Overview of the artfone G6 Pro's user-friendly menu interface.

5. FEATURES OVERVIEW

5.1. Dual LCD Screens

The phone features a 2.4-inch inner screen and a 1.8-inch outer display. The outer display shows time, caller ID, and notifications without needing to open the phone.



Image: artfone G6 Pro displaying its dual screens, one on the exterior when closed and one on the interior when open.

5.2. SOS Emergency Function

The dedicated SOS button on the back of the phone allows you to quickly contact up to five pre-set emergency contacts. Press and hold the button for 3 seconds to activate the SOS function, which will automatically dial and send distress messages until someone answers.

Three side buttons and SOS

Tailored design for old people.

SOS



Three side buttons



High quality housing&perfect keypad

Image: Rear view of the artfone G6 Pro highlighting the SOS emergency button.

5.3. Speed Dial and Photo Contacts

Assign frequently called numbers to dedicated A/B keys and numbers 2-9 for quick dialing. You can also assign photos to contacts for easier identification of callers.

One button Speed Dial

#A. Jack +39...
#B Dana +39...
#1.Son +33...
#2.Dan +33...
...
...
#9. Jean +01...



Image: Demonstrating the one-button speed dial feature on the artfone G6 Pro.

5.4. Talking Clock (Time Reporting)

Hold the volume + key for 3 seconds, and the phone will audibly announce the current time.

Time reporting button



Image: The time reporting button on the artfone G6 Pro, which announces the current time audibly.

5.5. Flashlight

A dedicated flashlight button on the side of the phone allows for quick activation. Slide up/down to toggle the flashlight on or off.



Image: The artfone G6 Pro featuring a flashlight, FM radio, and a 3.5mm headphone jack.

5.6. Other Features

- **Camera:** A basic 0.3MP camera is included for capturing simple moments.

- **FM Radio:** Enjoy FM radio on the go.
- **Bluetooth:** Connect to compatible Bluetooth devices.
- **Tools:** Includes a calculator, alarm clock, and calendar. Multiple alarm settings are available for reminders.
- **Loud Audio:** AAC speakers and receivers provide clear and loud audio for calls.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the phone's exterior. Avoid liquid cleaners.
- **Battery Care:** To prolong battery life, avoid extreme temperatures and do not leave the phone fully discharged for extended periods.
- **Storage:** Store the phone in a cool, dry place when not in use.
- **Water Resistance:** This phone is not water-resistant. Avoid exposure to liquids.

7. TROUBLESHOOTING

7.1. No Service / Network Issues

- **Check SIM Card:** Ensure the Nano SIM card is correctly inserted and activated with a compatible carrier (T-Mobile and its virtual operators ONLY; not compatible with AT&T or Verizon).
- **Restart Phone:** Power off and then power on the phone.
- **Network Coverage:** Verify you are in an area with adequate 2G, 3G, or 4G LTE network coverage.

7.2. Phone Not Charging

- **Check Connections:** Ensure the USB-C cable and/or charging dock are securely connected to the phone and power source.
- **Verify Power Source:** Try a different power outlet or USB port.
- **Inspect Cable/Dock:** Check for any visible damage to the charging cable or dock.

7.3. Audio Issues

- **Volume Adjustment:** Adjust the call volume during a conversation.
- **Speaker/Receiver Obstruction:** Ensure the speaker and receiver are not blocked by debris.
- **Silent/Vibration Mode:** Long-press the # key to toggle silent/vibration modes. Ensure the phone is not in silent mode if you expect audible alerts.

7.4. MMS Not Downloading

- **Network Settings:** Ensure your carrier's MMS settings are correctly configured.
- **Storage:** Check if there is sufficient storage space on the phone or Micro SD card.
- **Secure Inbox:** Some MMS messages may require access through a 'secure inbox'. The default PIN is often 1234, but it is recommended to change this for security.

8. SPECIFICATIONS

Feature	Specification
Model Name	G6 Pro

Brand	artfone
Cellular Technology	4G (Compatible with T-Mobile and virtual operators ONLY)
Wireless Carrier	Unlocked
Operating System	artfone Mocer RTOS
Screen Size	2.4 Inches (Inner), 1.8 Inches (Outer)
Resolution	180 x 240, 240 x 180
RAM Memory Installed Size	48 MB
Memory Storage Capacity	0.3 GB (Expandable up to 64GB with Micro SD)
Battery Capacity	1300 Milliamp Hours
Phone Talk Time	8 Hours
Item Weight	8.1 ounces
Connectivity Technologies	Bluetooth, USB
Special Features	Basic Phone, Expandable Memory, Time Reporting, SOS Button, Charging Dock, Loud Speaker, Camera, Talking Clock, Speed Dial, Hands-free, Caller-ID, Large Fonts
Form Factor	Flip
Audio Jack	3.5 mm

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact artfone customer service. Refer to the contact details provided in your product packaging or visit the official artfone website. Please have your product model (G6 Pro) and purchase details available when contacting support.

Related Documents - G6 Pro

<p>artfone® F20</p>  <p>English P1-7 Deutsch P8-15 Français P16-23 Italiano P24-30 Español P31-38 Dutch P39-46</p>	<p>Artfone F20 User Manual - Guide and Instructions</p> <p>Comprehensive user manual for the Artfone F20 mobile phone, covering setup, features, SOS function, and troubleshooting. Available in multiple languages.</p>
<p>ARTFONE C1</p> 	<p>Artfone C1 Senior Mobile Phone User Manual - Features, SOS, and FAQ</p> <p>Explore the Artfone C1 senior mobile phone with this comprehensive user manual. Learn about its SOS function, speed dial, volume controls, and answers to frequently asked questions. Designed for simplicity and ease of use.</p>
<p>Artfone G3 Flip</p> 	<p>Artfone G3 Flip Phone User Manual</p> <p>Comprehensive user manual for the Artfone G3 Flip phone, detailing features, operation, and FAQs. Learn how to make calls, use the flashlight, SOS function, and manage settings.</p>
<p>artfone A400</p>  <p>English P1-10 Deutsch P11-21 Français P22-32 Italiano P33-43 Español P44-54 Dutch P55-65</p>	<p>Artfone A400 User Manual and Features</p> <p>Discover the Artfone A400 mobile phone. This guide covers features, operation, and troubleshooting for the Artfone A400, including language settings, SOS function, and charging instructions.</p>
<p>ARTFONE C1</p> 	<p>Artfone C1 User Manual: Simple Mobile Phone Guide with SOS</p> <p>This user manual provides comprehensive instructions for the Artfone C1 mobile phone, covering device layout, button functions, icon meanings, and step-by-step guides for operations like making calls, using the SOS feature, and adjusting settings. Includes a FAQ section.</p>
<p>artfone A400</p>  <p>English P1-10 Deutsch P11-21 Français P22-32 Italiano P33-43 Español P44-54 Dutch P55-65</p>	<p>Artfone A400 4G Mobile Phone User Manual and Guide</p> <p>Comprehensive user guide for the Artfone A400 4G mobile phone, covering setup, features, functions, and troubleshooting. Includes instructions on SIM card insertion, battery placement, charging, SOS function, and basic operations.</p>

