

## DEWINNER ZF-YC-C-04

# DEWINNER ZF-YC-C-04 3200W 2-in-1 Pet Dryer and Vacuum Instruction Manual

Model: ZF-YC-C-04

## 1. INTRODUCTION

Thank you for choosing the DEWINNER ZF-YC-C-04 2-in-1 Pet Dryer and Vacuum. This device is designed to provide efficient and convenient grooming for your pets, combining powerful drying and effective vacuuming functions. Please read this manual thoroughly before operation to ensure safe and optimal performance.

## 2. SAFETY INSTRUCTIONS

- Always ensure the power supply matches the voltage specified on the product label.
- Do not operate the device with wet hands or in wet environments to prevent electric shock.
- Keep the device away from water and other liquids.
- Unplug the device from the power outlet when not in use, before cleaning, or before changing accessories.
- Do not allow children or individuals with reduced physical, sensory, or mental capabilities to operate the device without supervision.
- Never block the air inlets or outlets during operation.
- Do not direct the airflow directly into your pet's eyes, ears, or sensitive areas for extended periods.
- Monitor your pet's comfort level during use. If your pet shows signs of distress, discontinue use.
- Do not use the vacuum function to suck up liquids.
- Regularly check the power cord and hose for damage. Do not use if damaged.

## 3. PACKAGE CONTENTS

Please check that all items are present and in good condition:

- DEWINNER ZF-YC-C-04 Main Unit
- Retractable Hose (2.15 meters)
- 5 Nozzles (Circular, Flat, Wide, Comb, Vacuum)
- Shower Brush
- Replaceable Filter Cotton Pad
- Instruction Manual



Image: An array of accessories included with the DEWINNER pet dryer and vacuum, including a replaceable filter pad, shower brush, various nozzles (circular, flat, wide, comb), and a retractable hose.

## 4. PRODUCT OVERVIEW

The DEWINNER ZF-YC-C-04 features a robust design with intuitive controls for both drying and vacuuming functions.



Image: The main DEWINNER pet dryer and vacuum unit in pink, shown with the flexible hose attached and various nozzles laid out in the foreground. A golden retriever and a cat are visible in the background.

## Key Components:

- **Main Unit:** Houses the motor, controls, and filter.
- **Hose Connection Ports:** Two ports for attaching the hose for either drying (output) or vacuuming (input).
- **Power Switch:** Turns the device on/off.
- **Speed Control Dial:** Infinitely variable adjustment for airflow speed.
- **Heating Switch:** Activates or deactivates the heating function.
- **Filter Compartment:** Located at the air intake for easy filter replacement.

# Stepless Speed Control

Separate blow and suction systems



**Warning: Do not use the vacuum function to suck up liquids.**



**Replaceable filter cotton pad**

Image: Close-up of the DEWINNER pet dryer's control panel, showing the stepless speed control dial and power/heating switches. An arrow indicates the replaceable filter cotton pad.

## 5. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Positioning:** Place the main unit on a stable, flat, and dry surface. Ensure there is adequate ventilation around the device.
3. **Hose Attachment:**
  - For **Drying Function:** Connect the flexible hose to the air **output** port (usually indicated by an arrow pointing outwards).
  - For **Vacuum Function:** Connect the flexible hose to the air **input** port (usually indicated by an arrow pointing inwards).
4. **Nozzle Selection:** Choose the appropriate nozzle for your task and securely attach it to the end of the hose.
5. **Power Connection:** Plug the power cord into a suitable electrical outlet.

## 6. OPERATING INSTRUCTIONS

## 6.1. Drying Function

1. Ensure the hose is connected to the air output port.
2. Select a suitable nozzle. The flat or wide nozzles are generally good for overall drying, while the comb nozzle can help with undercoats.
3. Turn on the main power switch.
4. Adjust the speed control dial to a low setting initially, gradually increasing as your pet becomes comfortable.
5. If desired, switch on the heating function for warm air. Monitor the temperature to ensure it is comfortable for your pet.
6. Direct the airflow over your pet's coat, moving the nozzle continuously to prevent overheating any single area.
7. For different pet sizes and coat types, adjust speed and temperature accordingly.
  - **Cats/Small Dogs:** Use lower speed and minimal heat. Drying time: 8-12 minutes.
  - **Medium Dogs:** Moderate speed and heat. Drying time: 15-20 minutes.
  - **Large Dogs/Long Coats:** Higher speed and heat may be used, but always monitor. Drying time: 25-40 minutes.



Image: Illustration showing estimated drying times for cats/small dogs, medium dogs, and large dogs using the DEWINNER pet dryer, with examples of each.



Ear/Paws/Small Areas



Vacuuming/Pet Hair Removal



Comb and Blow the Undercoats



Partial drying



Dealing with Heavy-coated Area

Image: Examples of different nozzle applications for the DEWINNER pet dryer, including drying ears/paws, partial drying, dealing with heavy-coated areas, and combing undercoats.

## 6.2. Vacuum Function

1. Ensure the hose is connected to the air **input** port.
2. Attach the vacuum nozzle to the end of the hose.
3. Turn on the main power switch.
4. Adjust the speed control dial to achieve the desired suction power.
5. Gently move the vacuum nozzle over your pet's coat to remove loose hair and dander. This can also be used to clean pet hair from furniture or floors.
6. **Warning:** Do not use the vacuum function to suck up liquids.

# No Hair Escapes to the Floor

Keep the shedding under control



Image: A person using the DEWINNER pet vacuum function to remove loose hair from a golden retriever, illustrating how it helps keep shedding under control.

## Adjustable Flow Speed



Image: The DEWINNER pet vacuum being used to clean pet hair from a car seat and a sofa, demonstrating its versatility for household cleaning.

## 7. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your DEWINNER Pet Dryer and

Vacuum.

- **Cleaning the Filter:** The filter cotton pad should be checked and cleaned regularly, especially after vacuuming. To clean, unplug the device, open the filter compartment, remove the filter, and gently brush off accumulated hair and debris. Replace the filter if it is heavily soiled or damaged.
- **Cleaning the Hose and Nozzles:** Detach the hose and nozzles from the main unit. Clean them with a damp cloth to remove any pet hair or residue. Ensure they are completely dry before reattaching.
- **Exterior Cleaning:** Wipe the main unit's exterior with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Storage:** Store the device in a cool, dry place, away from direct sunlight and out of reach of children and pets.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Not plugged in; power switch off; power outage.	Check power cord connection; ensure power switch is ON; check household power.
Weak airflow/suction.	Filter clogged; hose or nozzle blocked; hose not securely attached.	Clean or replace filter; check hose and nozzles for blockages; ensure hose is firmly connected.
Device overheats.	Blocked air inlets/outlets; prolonged use at high settings.	Ensure clear airflow paths; allow device to cool down; reduce usage time or settings.
Unusual noise.	Foreign object in motor; loose component.	Immediately turn off and unplug. Inspect for foreign objects. If noise persists, contact support.

## 9. SPECIFICATIONS

Feature	Specification
Model Number	ZF-YC-C-04
Power	3200W
Voltage	220-240V
Frequency	50/60 Hz
Wind Speed	65-100 m/s
Hose Length	2.15 meters (retractable)
Product Dimensions (L x W x H)	37 x 17 x 20 cm
Net Weight	2.5 kg
Noise Level	Approximately 60 dB
Material	ABS Plastic

**Size of the main machine**  
37x17x20 inch

**Net weight**  
2.3KG

**Power**  
3200W

**Voltage**  
220-240V

**Frequency**  
50/60 Hz

**Wind Speed**  
65-100 m/s

**Pipe length**  
215 CM



Mess-free



Powerful  
Suction



Easy compact  
and storage



6 Grooming  
Tools

Image: Diagram illustrating the dimensions of the DEWINNER pet dryer main unit and listing key specifications such as power, voltage, frequency, wind speed, and net weight.

## 10. WARRANTY AND SUPPORT

DEWINNER products are manufactured to high-quality standards. For warranty information or technical support, please refer to the warranty card included with your purchase or contact DEWINNER customer service through the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.

### Related Documents - ZF-YC-C-04



#### [DEWINNER DE-T1088 Angle Grinder User Manual and Safety Guide](#)

Comprehensive guide for the DEWINNER DE-T1088 Angle Grinder, covering intended use, safety instructions, technical specifications, mounting, operation, and maintenance. Includes safety warnings and electrical safety information.

