

Manuals.plus /

- › Trueque /
- › Trueque KM22 Ultra Wireless Keyboard and Mouse Combo Instruction Manual

Trueque KM22 Ultra

Trueque KM22 Ultra Wireless Keyboard and Mouse Combo

INSTRUCTION MANUAL

Introduction and Overview

The Trueque KM22 Ultra Wireless Keyboard and Mouse Combo offers a full-size, backlit typing experience with a comfortable wrist rest and convenient phone holder. Designed for versatility, it connects wirelessly via a 2.4G USB-A/Type-C receiver, making it compatible with various devices including PCs, laptops, Windows, and Chrome OS. Its quiet keys and long-lasting rechargeable battery ensure an efficient and undisturbed work or gaming environment.



Image: Trueque KM22 Ultra Wireless Keyboard and Mouse Combo, showcasing its full-size design and integrated wrist rest.

Package Contents

Verify that all items are present in your package:

- Trueque KM22 Ultra Wireless Keyboard
- Trueque Wireless Mouse

- 2-in-1 USB-A/Type-C Receiver
- USB Charging Cable
- User Manual

Your browser does not support the video tag.

Video: Unboxing the Trueque Wireless Keyboard and Mouse Combo, showing all included components.

Setup


1. **Locate the USB Receiver:** The 2-in-1 USB-A/Type-C receiver is stored in a compartment on the underside of the mouse. Gently remove it.
2. **Connect the Receiver:** Plug the USB receiver into an available USB-A or USB-C port on your computer or laptop. The system should automatically detect the devices.
3. **Power On:** Ensure both the keyboard and mouse are switched to the 'ON' position. The power switch for the mouse is located on its underside. The keyboard has a power switch near the top right.
4. **Initial Charge:** For optimal performance, it is recommended to fully charge both the keyboard and mouse before first use. Use the provided USB charging cable.

Stable 2.4 GHz Wireless

33Ft/10m



2 in 1
Plug & Play



33Ft
10m



Type-C Port



USB Port

Image: The 2.4G wireless receiver with both USB-A and Type-C adapter options for versatile connectivity.

Operating Instructions

Keyboard Functions

- **Backlight Control:** The keyboard features 5 lighting effects and 10 backlight colors. Use the dedicated backlight keys (often marked with a lightbulb icon) to cycle through modes and colors. Adjust brightness levels using the Fn key combined with specific arrow keys (refer to the keyboard's keycap legends for exact combinations).
- **Multimedia Keys:** Dedicated multimedia keys are located at the top of the keyboard for quick access to volume control, play/pause, and other media functions.
- **Wrist Rest & Tilt:** The integrated wide wrist support is designed for comfort during long typing sessions. Foldable 7° tilt legs on the underside of the keyboard can be extended for a more ergonomic typing angle.
- **Phone Holder Slot:** A built-in slot at the top of the keyboard accommodates mobile devices, allowing for easy viewing during multitasking or video calls.

Your browser does not support the video tag.

Video: Demonstration of keyboard backlight control, showing various modes and brightness adjustments.

Mouse Functions

- **DPI Adjustment:** The mouse supports multiple DPI settings (800, 1200, 1600 DPI) for adjustable cursor sensitivity. Use the dedicated DPI button, usually located near the scroll wheel, to cycle through settings.
- **Side Buttons:** The mouse includes side buttons for convenient forward and backward navigation in web browsers or other applications.
- **Backlight Control:** To turn the mouse backlight on or off, press and hold the scroll wheel for approximately 5 seconds.

Backlit Mouse



Quiet click



Ergo comfort

Note: Press the scroll wheel for 5s to turn off the backlight

Image: The Trueque wireless mouse, highlighting its backlit feature, DPI settings, and quiet click design.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For deeper cleaning, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the device.

- **Battery Care:** To prolong battery life, avoid fully discharging the devices frequently. Recharge when the low battery indicator appears. Store in a cool, dry place when not in use for extended periods.
- **Storage:** When transporting or storing, ensure the USB receiver is securely placed in its compartment within the mouse to prevent loss.

Troubleshooting

- **No Connection:** Ensure the USB receiver is firmly plugged into a working USB port. Check that both the keyboard and mouse are powered on. Try plugging the receiver into a different USB port.
- **Backlight Not Working:** Verify that the backlight is enabled using the dedicated keys. Adjust brightness levels. Ensure the device has sufficient battery charge.
- **Mouse Not Responding:** Check the mouse's power switch. Ensure the USB receiver is connected. If the mouse has a backlight, check if it's on, indicating power.
- **Mouse Scrolling Issues:** If the mouse scroll wheel is unresponsive, try turning the mouse off and on again. Ensure the mouse is fully charged.
- **Lag or Intermittent Connection:** Move the keyboard and mouse closer to the USB receiver. Avoid placing the receiver near other wireless devices that might cause interference.

Specifications

Product Dimensions	16.8 x 9 x 0.9 inches
Item Weight	2.59 pounds
Keyboard Battery Capacity	4000mAh (Rechargeable)
Mouse Battery Capacity	800mAh (Rechargeable)
Connectivity Technology	2.4Ghz Wireless Connection
Wireless Range	Up to 33 ft (10 meters)
Backlight	5 Lighting Effects, 10 Backlight Colors, 5 Brightness Levels
Mouse DPI	Up to 1600 DPI (Adjustable)
Special Features	Backlit, Light Up Keys, Ergonomic, Rechargeable, Spillproof, Wrist Rest, Phone Holder
Compatible Devices	Chromebook, Laptop, Notebook, MacBook Air, MacBook Pro, iMac, Tablet, Smartphone, Personal Computer, Television (Some shortcut keys may have limited function on macOS)

Designed for Work & Home Office

Quiet, backlit and rechargeable for everyday use




Image: Detailed dimensions of the Trueque KM22 Ultra Keyboard and Mouse.

Warranty and Support

Trueque offers a 12-month warranty and 360 days of brand care for this product. For any inquiries, technical support, or warranty claims, please contact our customer service team.

Customer Support Email: truequeservice@outlook.com



Image: Trueque customer support details, including contact information and warranty period.