

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VGR](#) /

> [VGR V-996 Professional Hair Trimmer User Manual](#)

VGR V-996 Professional

VGR V-996 Professional Hair Trimmer User Manual

Model: V-996 Professional

INTRODUCTION

This manual provides instructions for the safe and effective use of your VGR V-996 Professional Hair Trimmer. Please read all instructions carefully before first use and retain for future reference.

The VGR V-996 is a cordless hair and beard trimmer designed for precision grooming. It features ceramic and titanium-coated blades, a powerful 7000 RPM motor, an LED display, and a long-lasting lithium battery with USB Type-C charging.

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, injury, or damage, always follow these basic safety precautions:

- Keep the device out of reach of children.
- Do not use this appliance on animals.
- Avoid using the trimmer near water, in a bathtub, shower, or sink.
- Always turn off the trimmer before cleaning or attaching/detaching guide combs.
- Do not attempt to open or repair the device yourself. Contact customer support for assistance.
- Protect the trimmer from extreme temperatures and direct sunlight.
- Use the trimmer only for its intended purpose as described in this manual.
- Ensure the charging cable is not damaged before use.

PACKAGE CONTENTS

Your VGR V-996 Professional Hair Trimmer package includes:

- VGR V-996 Hair Trimmer
- 4 Guide Combs (1.5mm, 3mm, 6mm, 9mm)
- USB Type-C Charging Cable

- Cleaning Brush
- Lubricating Oil
- Blade Protection Cap



Image: VGR V-996 Hair Trimmer with its accessories, including guide combs, charging cable, cleaning brush, and oil.

SETUP AND CHARGING

1. **Initial Charge:** Before first use, fully charge the trimmer. Connect the USB Type-C charging cable to the trimmer's charging port and plug the other end into a compatible USB power adapter (not included). The LED display will indicate charging status. A full charge takes approximately 3 hours and provides up to 300 minutes of cordless runtime.

Long-Lasting Power

Keeps Running When You Need It Most



Image: The VGR V-996 trimmer connected to a USB-C charging cable, illustrating the charging process.

2. **Attaching Guide Combs:** Select the desired guide comb (1.5mm, 3mm, 6mm, or 9mm). Align the comb with the trimmer blade and push it firmly until it clicks into place.
3. **Detaching Guide Combs:** Gently pull the guide comb away from the blade to remove it.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Press the ON/OFF switch to turn the trimmer on or off. The LED display will activate upon power-on.
2. **Trimming:**
 - For best results, ensure hair is clean and dry.
 - Hold the trimmer with the blade flat against the skin or at a slight angle, depending on the desired cut.
 - Move the trimmer slowly against the direction of hair growth.
 - Use the guide combs for uniform length. For detailing or close trimming, remove the guide comb.



Shape & Define

Precision Detailing for Fine Lines & Edges

Image: A man using the VGR V-996 trimmer to precisely shape his beard and define lines.

3. **Turbo Mode:** The trimmer features a Turbo 7000 RPM motor for powerful cutting. The LED display will show the status of Turbo mode.
4. **LED Display:** The LED display shows the current battery level and indicates when Turbo mode is active.



Image: An overview of the VGR V-996 trimmer's key features, highlighting the LED display, ceramic and titanium blade, powerful motor, and lithium battery.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure optimal performance and extend the life of your trimmer.

1. **Cleaning the Blades:** After each use, turn off the trimmer and remove any attached guide comb. Use the provided cleaning brush to brush away loose hairs from the blades.

Ceramic & Titanium

Coated Blade for Sharper Cutting



Image: A detailed view of the VGR V-996 trimmer's ceramic and titanium-coated blade, emphasizing its precision cutting edge.

- Oiling the Blades:** Periodically, apply a small drop of the lubricating oil (provided) to the blades. Turn the trimmer on for a few seconds to allow the oil to distribute evenly. Wipe off any excess oil.
- Storage:** After cleaning and oiling, place the blade protection cap over the blades. Store the trimmer in a dry, cool place, away from direct sunlight and moisture.
- Battery Care:** To maintain battery health, avoid completely draining the battery frequently. Recharge when the battery indicator is low.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer fully.
Blades are pulling hair or cutting poorly.	Blades are dirty or not oiled.	Clean the blades thoroughly and apply lubricating oil.
Trimmer makes unusual noise.	Blades may be misaligned or dirty.	Clean and oil the blades. If the issue persists, contact customer support.
Charging indicator not working.	Faulty cable or power adapter.	Try a different USB Type-C cable and power adapter.

SPECIFICATIONS

Feature	Detail
Model Number	V-996 Professional
Blade Material	Ceramic, Titanium-coated Stainless Steel
Motor Speed	7000 RPM (Turbo Mode)
Battery Type	2000mAh Lithium Battery
Charging Time	Approx. 3 hours
Operating Time	Up to 300 minutes (cordless)
Charging Interface	USB Type-C
Guide Combs Included	1.5mm, 3mm, 6mm, 9mm
Display	LED Digital Display (Battery Level, Turbo Mode)
Dimensions (LxWxH)	16 x 4 x 3.5 cm
Weight	110 g
Power Source	Battery Powered
Country of Origin	China



Image: An internal diagram highlighting the powerful 7000 RPM motor of the VGR V-996 trimmer.

WARRANTY AND SUPPORT

For warranty information or customer support, please contact VGR directly using the details below:

- **Manufacturer:** Ningbo VGR Electric Appliance Co., Ltd.
- **Email:** customercare@vgrofficial.in
- **Phone:** 9667796740 (Available 10:00 AM to 6:00 PM, Monday to Saturday)
- **Website:** www.vgrofficial.in

Please retain your purchase receipt as proof of purchase for warranty claims.