



Manuals.plus /

› turelar /

› turelar Immersion Blender Handheld, Model HB8816 User Manual

turelar HB8816

turelar Immersion Blender Handheld

Model: HB8816

Your Kitchen Essential for Effortless Blending

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your turelar Immersion Blender. Keep this manual for future reference.

- **Electrical Safety:** Always unplug the appliance from the power outlet before cleaning, assembling, or disassembling parts. Do not immerse the motor unit in water or other liquids. Ensure your power supply matches the voltage specified on the appliance.
- **Blade Safety:** The blending blade is sharp. Handle with extreme care. Always ensure the appliance is unplugged before touching the blade.
- **Children and Supervision:** This appliance should not be used by children. Close supervision is necessary when any appliance is used near children.
- **Proper Use:** Do not use the appliance for anything other than its intended use. Avoid blending hard, dry ingredients that may damage the blade or motor.
- **Overheating Prevention:** To prevent overheating, operate the hand blender in one-minute intervals or less, allowing for brief pauses between cycles.
- **Damage:** Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.

2. PRODUCT OVERVIEW

The turelar Immersion Blender is designed for efficient and effortless blending. It consists of two main parts: the motor unit and the detachable blending shaft.

Components:

- **Motor Unit:** Contains the high-torque copper motor and control buttons (Power and Turbo).
- **Blending Shaft:** Made of food-grade stainless steel, featuring a 2-pronged blade and a splash guard design. This shaft is detachable for easy cleaning.



Image: The turelar Immersion Blender showing the motor unit with power and turbo buttons, and the blending shaft.

2-PRONGED BLADE

**Tested - Cut More Efficiently than
4 Blades and Easier to Clean**



Image: A close-up view of the 2-pronged stainless steel blade, designed for efficient blending and easy cleaning.

3. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the blending shaft in warm, soapy water. Rinse thoroughly and dry. Wipe the motor unit with a damp cloth.
3. **Assemble:** Align the blending shaft with the motor unit and twist until it locks securely into place.
4. **Power Connection:** Plug the power cord into a standard electrical outlet. The long cord provides flexibility for use around your kitchen.

Video: This video demonstrates the unboxing and assembly of the immersion blender, showing how the blending shaft attaches to the motor unit.

4. OPERATING INSTRUCTIONS

The turelar Immersion Blender features two mixing speeds and a pulse-activated sensor for precise control.

1. **Prepare Ingredients:** Place your ingredients in a suitable container (pot, bowl, jar, etc.). The slim stainless steel shaft is designed to fit most containers.
2. **Immerse Blender:** Submerge the blending shaft into the ingredients. Ensure the blade guard is fully covered to prevent splashing.
3. **Select Speed:**
 - **Normal Speed:** Press the top button for general blending tasks like soups, smoothies, and purees.
 - **TURBO Mode:** Press the bottom button for extra power to blend tougher ingredients or achieve a finer consistency.
4. **Blend:** Move the blender up and down gently through the ingredients until the desired consistency is reached.
5. **Usage Tip:** For optimal performance and to prevent motor strain, operate the blender in short bursts (e.g., 1 minute on, then a brief pause).

Versatile Applications:

- **Soups:** Blend directly in the pot for creamy soups.
- **Smoothies:** Create smooth and consistent fruit and vegetable blends.
- **Baby Food:** Easily puree cooked fruits and vegetables for homemade baby food.
- **Sauces & Dips:** Emulsify dressings, sauces, and dips with ease.



Image: A woman using the immersion blender to blend soup directly in a pot, demonstrating its ability to blend in any container.

Video: This video shows the immersion blender in action, demonstrating its effectiveness in making homemade mayonnaise.

5. CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity and hygiene of your immersion blender.

1. **Unplug:** Always unplug the blender from the power outlet before cleaning.
2. **Detach Shaft:** Twist and pull the blending shaft away from the motor unit.
3. **Clean Blending Shaft:** Wash the stainless steel blending shaft with warm, soapy water. You can also rinse it under running water. The 2-pronged blade design makes it easier to clean without trapping fibers.
4. **Clean Motor Unit:** The electronic and plastic part of the motor unit should **not** be washed in water. Wipe it clean with a damp cloth.
5. **Dry and Store:** Ensure all parts are completely dry before reassembling or storing. Use the top hanging ring for convenient storage, saving space in your kitchen.

DETACHABLE

For Easy Clean & Storage



Image: The detachable blending shaft being rinsed under running water, highlighting its easy-to-clean design.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in correctly; Power outage; Motor unit not securely attached to blending shaft.	Check power connection; Verify power supply; Reattach blending shaft securely.
Poor blending performance.	Too many ingredients; Ingredients too hard; Blade is dull or damaged.	Reduce ingredient quantity; Add liquid if necessary; Contact customer support if blade is damaged.
Motor overheats.	Continuous operation for too long; Overloaded.	Operate in short bursts (max 1 minute); Reduce load; Allow to cool down before resuming.

7. SPECIFICATIONS

- **Brand:** turelar
- **Model Number:** HB8816
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts
- **Number of Speeds:** 2 (Normal, Turbo)
- **Blade Material:** Thickened Stainless Steel
- **Material Type Free:** BPA Free
- **Product Dimensions:** 5"D x 2.5"W x 8.5"H
- **Item Weight:** 1.4 pounds
- **Included Components:** Immersion Blender

8. WARRANTY AND SUPPORT

Your turelar Immersion Blender comes with a **1 Year Limited Warranty** from the date of purchase.

This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accident, alteration, neglect, or unauthorized repair.

For warranty claims, technical support, or any questions regarding your product, please contact turelar customer support through the retailer where the product was purchased or visit the official turelar website for contact information.