

[Manuals.plus](#) /

> [Icango caddy](#) /

> Icango caddy G3 Electric Golf Cart Instruction Manual

Icango caddy G3

Icango caddy G3 Electric Golf Cart Instruction Manual

Model: G3

Brand: Icango caddy

1. PRODUCT OVERVIEW

The Icango caddy G3 Electric Golf Cart is designed to enhance your golfing experience with its advanced features and user-friendly design. This electric caddy offers multiple control modes, including smart auto-follow, remote control, and manual operation, ensuring convenience on the course. Its compact folding design allows for easy transport and storage, while the long-lasting battery supports extended play.

G3 ELECTRIC GOLF CART

Auto follow

Remote driving

One-click summon



Figure 1: The G3 Electric Golf Cart on a golf course, highlighting its auto-follow, remote driving, and one-click summon capabilities.

Your browser does not support the video tag.

Video 1: An overview of the G3 Electric Golf Cart, demonstrating its key features including quick assembly, battery installation, remote control, and smart follow function.

2. WHAT'S IN THE BOX

Verify that all components are present upon unboxing:

- G3 electric golf cart
- Charger and remote for electric golf caddy
- Drink holder
- Phone holder
- Umbrella holder



Figure 2: A visual representation of all items included in the G3 Electric Golf Cart package, such as the cart, remote, charger, and various holders.


3. SETUP AND ASSEMBLY

3.1 Unfolding the Cart

The G3 Electric Golf Cart features a 3-motion folding design for quick setup and collapse. To unfold, release the folding joints and extend the frame until it locks into place. Ensure all joints are securely fastened before use.



COLLAPSE



Fold the yellow circle joints to the corresponding position and fix them, adjust the red circle joints to the appropriate length, when climbing, please open the rear wheels

Figure 3: Step-by-step diagram illustrating how to collapse the golf cart by adjusting the yellow circle joints and extending the rear wheels for climbing.

3.2 Battery Installation

The battery is designed for quick disassembly and reassembly. Locate the battery compartment, insert the fully charged battery, and secure it in place. Refer to Video 1 for a visual guide on battery installation.

3.3 Attaching the Golf Bag

Place your golf bag onto the cart's support frame. Use the double leather strap carabiner to securely fasten the golf bag to prevent movement during operation. Refer to Video 1 for a visual guide on attaching the golf bag.

EASY FOLDING

Designed to Fit, Ready to Roll



Figure 4: The G3 Electric Golf Cart shown with its dimensions in both the unfolded and easily folded configurations, emphasizing its compact design.

4. OPERATING INSTRUCTIONS

4.1 Smart Auto-Follow Mode

Activate the smart auto-follow system to have the caddy automatically follow your movements. This mode frees your hands, allowing you to focus on your game. The caddy maintains a constant distance from you, adapting to various terrains.

ICANGO CADDY G3

Auto Follow Electric Golf Caddy
Swing Freely, It Follows Closely



Figure 5: A golfer walking on the course with the electric golf cart automatically following behind, demonstrating the smart auto-follow feature.

Your browser does not support the video tag.

Video 2: Demonstrates the electric golf cart's auto-follow function, showing it moving autonomously behind a golfer on the course.

4.2 Multi-Mode Control (Remote/APP/Manual)

The G3 caddy offers versatile control options:

- **Remote Control:** Use the portable remote to summon the cart, execute turns, or park it at a designated spot.
- **Smartphone App:** Connect via the dedicated app for advanced control, including adjusting direction, speed, and monitoring battery levels.
- **Manual Mode:** For short distances or specific maneuvers, you can push the cart manually using the ergonomic U-shaped handle.



Figure 6: An illustration of the multiple control modes available for the electric golf cart, including manual, auto-follow, remote control, and one-click recall.

Your browser does not support the video tag.

Video 3: Showcases the various control methods for the Icango Electric Golf Cart, including remote control, app control, and its ability to navigate different terrains and inclines.

4.3 Cruise Control

Utilize the cruise control feature to set a constant speed, allowing the cart to glide smoothly at a steady pace. This is particularly useful on flat fairways, conserving energy and reducing manual effort.

4.4 Anti-Tipping Wheels

The G3 is equipped with anti-tipping wheels to ensure stability, especially when navigating inclines or uneven terrain. These wheels provide additional support, preventing the cart from tipping over.




Figure 7: A detailed view of the anti-tipping wheels, designed to provide stability and prevent the golf cart from overturning on uneven ground or inclines.

4.5 App Connection

Download the dedicated smartphone application to personalize your golf cart settings. The app allows you to adjust various parameters, view operational data, and enhance your overall experience.



Figure 8: A smartphone displaying the personalized app connection interface, allowing users to adjust settings, view battery level, and track mileage for the electric golf caddy.

5. MAINTENANCE

To ensure the longevity and optimal performance of your G3 Electric Golf Cart, regular maintenance is recommended:

- Keep the cart clean by wiping it down after each use.
- Regularly check all moving parts and fasteners for tightness.
- Store the battery in a cool, dry place and ensure it is charged according to the manufacturer's guidelines.
- Inspect tires for wear and tear and maintain appropriate pressure.

6. TROUBLESHOOTING

If you encounter any issues with your G3 Electric Golf Cart, consider the following common solutions:

- **Cart not responding:** Ensure the battery is fully charged and correctly installed. Check if the remote control is paired and has sufficient power.
- **Erratic movement:** Verify that the terrain is suitable for operation. If using auto-follow, ensure no obstructions are interfering with the sensors.
- **Reduced battery life:** Confirm the battery is fully charged before use. Extreme temperatures can affect battery performance.

For persistent issues, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Item Package Dimensions L x W x H	30 x 23.6 x 13.8 inches
Package Weight	48 Pounds
Brand Name	Icango caddy
Model Name	G3
Color	Black electric golf cart
Material	Aluminum
Suggested Users	mens
Manufacturer	NERCH
Included Components	Charger and remote for electric golf caddy, G3 electric golf cart, drink holder, phone holder, umbrella holder

Anti-Tipping Wheels

Anti tip wheels conquer golf hills with ease,
every uphill swing feels light and right



Figure 9: The G3 Electric Golf Cart in its compact, folded state, easily fitting into the trunk of a car for convenient transportation.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The Icando caddy G3 Electric Golf Cart comes with a 1-year warranty. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, warranty inquiries, or any other support needs, please contact Icando customer service. Refer to the contact information provided with your product packaging or visit the official Icando caddy store on Amazon.