

[Manuals.plus](#) /

› [SEUNKWANG](#) /

› SEUNKWANG EWEADN X7S Wireless Keyboard Instruction Manual

## SEUNKWANG X7S

# SEUNKWANG EWEADN X7S Wireless Keyboard Instruction Manual

Model: X7S

## INTRODUCTION

---

This manual provides detailed instructions for the SEUNKWANG EWEADN X7S 2.4G Wireless Keyboard. This full-size keyboard features a durable metal panel, white backlighting, and a rechargeable battery, designed for comfortable and efficient use across various operating systems.



*Image: The SEUNKWANG EWEADN X7S wireless keyboard in white, showcasing its full-size layout and sleek design.*

## SETUP

---

The EWEADN X7S keyboard utilizes a 2.4G wireless connection for stable performance up to 10 meters. Follow these steps to connect your keyboard:

1. Locate the USB receiver. It is typically stored in a compartment on the keyboard or included separately in the packaging.
2. Insert the USB receiver into an available USB-A port on your computer (PC, laptop, etc.).
3. Turn on the keyboard using the power switch, usually located on the top edge or underside.
4. If the keyboard does not connect automatically, press the "ESC" key simultaneously with the "+/= " key (often labeled as the pairing key) to initiate pairing mode. The keyboard should then connect to the receiver.

# TWO IN ONE

2.4G Wireless Rechargeable



2.4G

Plug & Connect



Rechargeable

*Image: A close-up of the keyboard and a laptop, illustrating the 2.4G USB receiver connection and highlighting the rechargeable capability.*

## OPERATING INSTRUCTIONS


### Backlight Control

The keyboard features a single white backlight with adjustable settings:

- To increase brightness: Press **Fn + PU** (Page Up). There are 5 levels of brightness.
- To decrease brightness: Press **Fn + PD** (Page Down).
- To turn the backlight ON/OFF: Press **Fn + SL** (Scroll Lock).
- To switch between 'always on' and 'breathing light' modes: The backlight offers two modes: a steady 'always on' mode with 5 brightness levels, and a 'breathing light' mode with 5 speed adjustments. Use the backlight control keys to cycle through these options.

# 5 LEVELS

## Adjustable & Simple White Light



Brightness+



Brightness-



ON/OFF Light

Image: The keyboard displaying its white backlight, with indicators for brightness adjustment (Fn+PU, Fn+PD) and light on/off (Fn+SL).

### Ergonomics and Typing Experience

The EWEADN X7S keyboard is designed for comfort and efficiency:

- **Water Drop Keycaps:** Enhanced concave and convex keycap design conforms to your fingertips for a comfortable and smooth typing experience.
- **Silent Operation:** The membrane keyboard structure ensures quiet keystrokes, reducing noise by up to 95%.
- **Anti-Ghosting:** Features 26-key anti-ghosting technology, allowing multiple simultaneous keystrokes without conflict, ideal for fast typing or gaming.
- **Adjustable Feet:** Two adjustable feet on the base allow you to set the keyboard at a comfortable 7° angle, along with 4 anti-slip pads for stability.

# 26-key Anti-ghosting & No Lag

No conflict between simultaneous keystrokes



*Image: A close-up of the keyboard's 'water drop' keycaps, highlighting their translucent and ergonomic design.*

# Excellent Water Drop Pudding Keycaps

Fits fingers well, typing more comfortable & smoother



**Noise-99%**

(37db-48db) Silent Membrane Keyboard

**Translucency +100%**

Pudding Structure Transparent

*Image: An illustration of the keyboard demonstrating the 26-key anti-ghosting capability, showing multiple keys being pressed simultaneously without conflict.*

## MAINTENANCE

To ensure the longevity and optimal performance of your SEUNKWANG EWEADN X7S keyboard, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the keyboard surface with a soft, dry, or slightly damp cloth. Avoid using harsh chemicals or abrasive materials. For cleaning between keycaps, use compressed air to remove dust and debris.
- **Charging:** Charge the keyboard using the provided Type-C cable. Avoid using damaged cables or non-standard chargers. Ensure the keyboard is fully charged before extended use to maintain battery health.
- **Storage:** When not in use for extended periods, store the keyboard in a dry, cool place away from direct sunlight and extreme temperatures.
- **Spill Resistance:** While the keyboard is designed with some spill resistance, it is not waterproof. Avoid exposing it to excessive liquids. In case of a spill, immediately disconnect the keyboard, power it off, and allow

it to dry completely before reuse.

## TROUBLESHOOTING

If you encounter issues with your SEUNKWANG EWEADN X7S keyboard, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Keyboard not responding	Low battery; USB receiver not connected; Keyboard not paired.	Charge the keyboard. Ensure the USB receiver is securely plugged into a working USB port. Re-pair the keyboard by pressing <b>ESC + +/-</b> and inserting the receiver.
Backlight not working or dim	Backlight turned off; Brightness set too low; Low battery.	Press <b>Fn + SL</b> to toggle the backlight. Press <b>Fn + PU</b> to increase brightness. Charge the keyboard.
Keys not registering or ghosting	Software conflict; Physical obstruction under key; Anti-ghosting limit reached (unlikely for 26 keys).	Restart your computer. Clean the keyboard. Ensure no debris is under the keycaps.
Charging issues	Faulty cable or port; Keyboard switch damaged.	Try a different Type-C cable and USB charging port. If the power switch is physically damaged, contact customer support.

## SPECIFICATIONS

Feature	Detail
Brand	SEUNKWANG
Model Name	X7S
Connectivity Technology	2.4G Wireless (USB-A receiver)
Keyboard Description	Membrane
Compatible Devices	Personal Computer, Laptop, Smartphone, Tablet (via USB-A)
Special Features	Backlit (White), Ergonomic, Hotkeys & Multimedia Keys, Rechargeable, Spill-proof, Windows & Mac Compatible
Color	White
Material	Metal, Plastic

Feature	Detail
Power Source	Battery
Keyboard Layout	QWERTY
Hand Orientation	Ambidextrous
Included Components	Type-C cable, USB receiver

## WARRANTY AND SUPPORT

---

The SEUNKWANG EWEADN X7S keyboard comes with a **24-month brand support**. Our team of experts is available to assist you with any product-related inquiries or issues.

Additionally, the product is eligible for a **30-day free return** policy, allowing you to return the item without cost within 30 days of purchase if you are not satisfied.

For support, please refer to the contact information provided with your purchase or visit the official SEUNKWANG website.