Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LINKHOO City Adventure Theme

LINKHOO Wooden Train Set & Table: City Adventure Theme Instruction Manual

Model: City Adventure Theme | Brand: LINKHOO

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your LINKHOO Wooden Train Set & Table, City Adventure Theme. Please read all instructions carefully before use to ensure safe and enjoyable play.

Safety Information

- Recommended for ages 36 months to 7 years.
- Product is made from durable, premium wood with a splinter-free finish and non-toxic, child-safe paint.
- All LINKHOO tables are safety certified (ASTM & EN-71).
- Ensure all small parts are securely assembled and regularly checked to prevent choking hazards.
- Adult supervision is recommended during play.

What's Included

Your LINKHOO Wooden Train Set & Table includes the following components:

- Wooden Train Set and Table
- Integrated Storage Drawer with individual containers
- Various wooden track pieces, bridges, and ramps
- Assorted wooden vehicles (e.g., police car, fire truck, helicopter, train cars, taxi)
- Wooden buildings (e.g., fire station, police HQ, hospital, gas station)
- Wooden figures and accessories (e.g., trees, traffic signs, boats)



Image: Overview of the LINKHOO Wooden Train Set and Table with all included components.

Setup and Assembly

Assembly of the LINKHOO Wooden Train Set & Table typically takes less than 30 minutes. Follow these steps for proper setup:

1. Unpack all components and verify against the included parts list.
2. Assemble the table frame according to the visual instructions provided in the packaging. Ensure all screws are tightened securely.
3. Insert the storage drawer into the designated slot beneath the table.
4. Place the reversible tabletop onto the assembled frame. Choose the city landscape side for train play or the plain side for other activities.
5. Arrange the wooden track pieces, bridges, buildings, and accessories as desired to create your city adventure theme.



Image: Assembly of the table frame.

Your browser does not support the video tag.

Video: Demonstrates the assembly process and features of the train set and table.

Operating and Play

The LINKHOO Wooden Train Set & Table offers versatile play options, encouraging creativity and skill development.

- **City Adventure Play:** Use the included police car, fire truck, helicopter, and train to create rescue missions and explore the city landscape.
- **Reversible Tabletop:** The tabletop can be flipped to provide a smooth surface for drawing, crafts, or other activities, extending the table's utility beyond train play.
- **Track Building:** Design and build various transport networks using the multi-level railway and high-arch bridge, fostering early STEM skills like logic and problem-solving. The set is compatible with major wooden train brands like Brio and Thomas.



Image: A child engaging in imaginative play with the wooden vehicles.



Image: The reversible tabletop, offering dual functionality for play and other activities.

Your browser does not support the video tag.

Video: A child demonstrating various play scenarios with the train set and table.

Maintenance and Care

- **Cleaning:** Wipe down the table and wooden pieces with a damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Utilize the built-in slide-out storage drawer to keep all tracks, vehicles, and figures organized and prevent clutter. The individual containers can help sort pieces by type or color.
- **Inspection:** Periodically check all parts for wear and tear, loose connections, or damage. Replace any broken components immediately to ensure continued safety.



Image: Details on the quality and durability of the materials used.

Troubleshooting

- **Tracks not connecting properly:** Ensure all track pieces are aligned correctly and fully inserted into their connectors. Some pieces may require gentle force to fit snugly.
- **Train getting stuck:** Check for any obstructions on the track, such as misplaced accessories or loose track connections. Ensure bridges and ramps are stable and correctly positioned.
- **Missing or damaged parts:** If you find any parts are missing or damaged upon arrival, please contact LINKHOO customer support for assistance.

Specifications

Product Dimensions	38.19 x 24.61 x 15.75 inches
Recommended Age	36 months - 7 years
Material	Durable, premium wood with splinter-free finish
Paint	Non-toxic, child-safe paint
Safety Certifications	ASTM & EN-71

Compatibility	Compatible with major wooden train brands (e.g., Brio, Thomas)



Image: Product dimensions for planning space.

Warranty and Support

For information regarding product warranty, returns, or technical support, please contact LINKHOO customer service directly. Refer to the contact information provided on the product packaging or the official LINKHOO website.
Extended protection plans may be available for purchase separately. Please consult the retailer for details on these plans.

© 2026 LINKHOO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FT3HD9HV

More documents and user manuals: **https://manuals.plus/**