

[Manuals.plus](#) /

› [Status](#) /

› Status Pro X Wireless Earbuds User Manual

Status Pro X

Status Pro X Wireless Earbuds User Manual

Model: Pro X | Brand: Status

1. INTRODUCTION

Welcome to your Status Pro X Wireless Earbuds. These earbuds are designed to deliver a premium audio experience with advanced features. This manual provides essential information for setting up, operating, and maintaining your device.

Key Features:

- **Hi-Res Triple Drivers:** Equipped with a 12mm dynamic driver and dual Knowles Balanced Armature drivers, supporting LDAC Hi-Res Wireless Audio for superior sound quality.
- **Advanced ANC & Transparency:** Features Hybrid Active Noise Cancelling (up to 52dB) to minimize external distractions, along with an Ambient Aware mode for situational awareness.
- **Clear Calls:** Six beamforming microphones integrated with VoiceLoom AI Speech Enhancement ensure clear voice transmission during calls.
- **Future-Ready Connectivity:** Utilizes Bluetooth 5.3 with Multipoint connectivity, LE Audio, LC3 codec, and Auracast support for versatile and stable connections.
- **Durable Design & Power:** Offers 8 hours of playback per charge, extending to 32 hours with the charging case. Rated IP55 for water and dust resistance, and supports Qi wireless charging. The Status app includes a "Find My Earbuds" feature.




Image: Status Pro X Earbuds in use, highlighting the sleek design and fit.

2. SETUP

2.1 What's in the Box

Your Status Pro X package typically includes:

- Status Pro X Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Various Sizes of Silicone Ear Tips
- Quick Start Guide



Image: Status Pro X Earbuds and charging case.

2.2 Charging the Earbuds and Case

Before first use, fully charge your Status Pro X earbuds and charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated; the indicator lights on the earbuds will confirm charging.
2. Connect the USB-C charging cable to the charging port on the case and to a power source. The case's LED indicator will show charging status.
3. Alternatively, place the charging case on a Qi-compatible wireless charging pad for wireless charging.
4. A full charge provides approximately 8 hours of playback for the earbuds, with the case offering an additional 24 hours of battery life.

2.3 Pairing with Your Device

The Status Pro X earbuds use Bluetooth 5.3 for a stable connection.

1. Open the charging case. The earbuds will automatically enter pairing mode (indicated by flashing LED lights).
2. On your device (smartphone, tablet, computer), go to Bluetooth settings.
3. Select "Status Pro X" from the list of available devices.

4. Once connected, the earbud indicator lights will stop flashing.
5. For subsequent uses, the earbuds will automatically connect to the last paired device when removed from the case.




Image: Status Pro X Earbuds highlighting Hi-Res Audio and Fast Pair capabilities.

2.4 Installing the Status App

Download the official Status app from your device's app store to unlock full customization options, including EQ settings, touch control customization, and the "Find My Earbuds" feature.

2.5 Achieving Optimal Fit

A proper fit is crucial for sound quality, noise cancellation, and comfort.

1. Experiment with the different sizes of silicone ear tips provided.
2. Insert the earbud gently into your ear canal and twist slightly to create a secure seal.
3. Test the fit by playing audio and checking for sound leakage or discomfort. The correct ear tip size will provide a snug fit without causing pressure.

3. OPERATING INSTRUCTIONS

3.1 Touch Controls

The Status Pro X earbuds feature intuitive touch controls. Specific functions can be customized via the Status app.

Action	Function (Default)
Single Tap	Play/Pause, Answer/End Call
Double Tap (Left Earbud)	Previous Track
Double Tap (Right Earbud)	Next Track
Triple Tap	Activate Voice Assistant
Long Press (Left Earbud)	Toggle ANC/Ambient Mode
Long Press (Right Earbud)	Toggle ANC/Ambient Mode

Note: For full control customization, please use the Status mobile application.

3.2 Active Noise Cancellation (ANC) and Ambient Aware Mode

Your earbuds offer two distinct listening modes to suit your environment:

- **Active Noise Cancellation (ANC):** Reduces external noise, allowing for an immersive audio experience. Ideal for travel or noisy environments.
- **Ambient Aware Mode:** Allows you to hear your surroundings while still enjoying your audio. Useful for awareness in urban areas or when interacting with others.

Toggle between these modes using the long press touch control on either earbud, or through the Status app for more granular control.




Image: Visual representation of Active Noise Cancellation and Ambient Aware Mode features.

3.3 Making and Receiving Calls

The six beamforming microphones with VoiceLoom AI enhance call clarity.

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Long press on either earbud.

For optimal call quality, ensure the microphones are not obstructed. In windy conditions, consider using the wind reduction feature available in the Status app, if applicable.




Image: Internal view highlighting the three beamforming microphones for enhanced call quality.

3.4 Multipoint Connectivity

The Status Pro X supports Multipoint connectivity, allowing you to connect to two devices simultaneously (e.g., a smartphone and a laptop).

1. Pair the earbuds with your first device as described in Section 2.3.
2. Disconnect the earbuds from the first device's Bluetooth settings (do not unpair).
3. Enter pairing mode again and pair with your second device.
4. Reconnect to the first device from its Bluetooth settings. The earbuds should now be connected to both devices.
5. Audio will automatically switch between devices based on which one is actively playing media or receiving a call.

3.5 Using the Status App

The Status app provides advanced control over your earbuds:

- **Equalizer (EQ):** Customize sound profiles or select from presets to match your listening preferences.
- **Touch Control Customization:** Reassign touch functions to suit your workflow.
- **ANC/Ambient Mode Control:** Fine-tune noise cancellation levels or switch modes.
- **Find My Earbuds:** Locate misplaced earbuds by playing a loud sound (works only when earbuds are out of the case and connected).
- **Firmware Updates:** Keep your earbuds updated with the latest features and improvements.

4. MAINTENANCE

4.1 Cleaning Your Earbuds and Case

Regular cleaning helps maintain performance and hygiene.

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- For ear tips, remove them from the earbuds and clean with mild soap and water. Ensure they are completely dry before reattaching.
- Gently remove any earwax or debris from the earbud nozzles using a small, soft brush or cotton swab.
- Avoid using abrasive materials, alcohol, or chemical cleaners.

4.2 Water and Dust Resistance (IP55)

The Status Pro X earbuds are rated IP55, meaning they are protected against limited dust ingress and low-pressure water jets from any direction.

- This rating applies to the earbuds only, not the charging case.
- Avoid submerging the earbuds in water.
- If the earbuds get wet, dry them thoroughly before placing them back in the charging case to prevent damage.

5. TROUBLESHOOTING

Common Issues and Solutions:

- **No Sound/Connectivity Issues:**
 - Ensure earbuds are charged and powered on.
 - Check Bluetooth settings on your device and ensure "Status Pro X" is connected.
 - Try unpairing and re-pairing the earbuds.
 - Restart your source device.

- If using Multipoint, ensure the correct device is actively playing audio.

• **Poor Sound Quality:**

- Ensure earbuds are clean and free of debris.
- Verify proper ear tip fit for a secure seal.
- Adjust EQ settings in the Status app.
- Ensure your audio source is of high quality.

• **ANC Not Effective:**

- Ensure earbuds are properly seated in your ears with a good seal.
- Confirm ANC mode is active via touch controls or the Status app.

• **Charging Problems:**

- Ensure the charging cable is securely connected to both the case and power source.
- Verify the power source is active.
- Clean charging contacts on both earbuds and case.
- If using wireless charging, ensure the case is correctly positioned on the charging pad.

• **Earbuds Not Responding to Touch Controls:**

- Ensure earbuds are clean and dry.
- Restart the earbuds by placing them in the case and closing it for a few seconds, then reopening.
- Check touch control settings in the Status app.

6. SPECIFICATIONS

Feature	Detail
Model	Pro X
Drivers	12mm Dynamic + Dual Knowles Balanced Armature
Audio Codecs	LDAC, LE Audio, LC3
Bluetooth Version	5.3
Active Noise Cancellation	Hybrid ANC (up to 52dB)
Microphones	6 Beamforming Mics with VoiceLoom AI
Battery Life (Earbuds)	Up to 8 hours
Total Battery Life (with Case)	Up to 32 hours
Charging	USB-C, Qi Wireless Charging
Water Resistance	IP55 (Earbuds only)
Package Dimensions	4.33 x 3.98 x 1.85 inches
Item Weight	7.2 ounces
Date First Available	October 15, 2025

Feature	Detail
Manufacturer	Status

7. WARRANTY AND SUPPORT

7.1 Product Warranty

The Status Pro X Wireless Earbuds typically come with a 1-year limited warranty from the date of purchase, covering manufacturing defects. Please refer to the warranty card included in your product packaging or visit the official Status website for detailed warranty terms and conditions.

7.2 Customer Support

For further assistance, technical support, or warranty claims, please contact Status customer service:

- **Website:** Visit the official [Status Store on Amazon](#) or the manufacturer's website for FAQs, support articles, and contact information.
- **Email/Phone:** Refer to your product packaging or the Status website for specific contact details.

Please have your product model (Pro X) and purchase date ready when contacting support.

