

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [msi](#) /
- › [MSI Bravo 15 Gaming Laptop User Manual](#)

### msi Bravo 15 C7VFKP

# MSI Bravo 15 Gaming Laptop User Manual

Model: Bravo 15 C7VFKP

## INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your MSI Bravo 15 Gaming Laptop. Please read this guide thoroughly to ensure optimal performance and longevity of your device.



Front view of the MSI Bravo 15 Gaming Laptop, showcasing its display and keyboard.

## SETUP

### 1. Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that the following items are included:

- MSI Bravo 15 Gaming Laptop
- 200W AC Adapter
- COU 32GB USB Drive

Inspect the laptop for any physical damage. If any damage is found, contact your retailer immediately.

## 2. Connecting the Power Adapter

Connect the AC adapter to the power input port on the laptop and then plug the power cord into an electrical outlet. It is recommended to fully charge the battery before initial use.

## 3. Initial Power On

Open the laptop lid. Press the power button, typically located above the keyboard, to turn on the device. Follow the on-screen instructions to complete the Windows 11 Pro setup process.

## 4. Connecting Peripherals

Your MSI Bravo 15 laptop offers various ports for connecting external devices:

- **USB-C 3.2 Gen 1:** Supports DisplayPort 1.4 and 5Gbps data transfer.
- **USB 3.2 Gen 1 (Type-A):** Two ports for high-speed data transfer (5Gbps).
- **USB 2.0 (Type-A):** One port for standard USB devices.
- **HDMI 2.1:** For connecting to external displays.
- **RJ-45:** For wired network connection.
- **Headphone / Microphone Combo Jack:** For audio input/output.



Left side of the laptop, illustrating the various connectivity ports.



Right side of the laptop, showing additional ports for peripherals.

## OPERATING YOUR LAPTOP

### 1. Keyboard Functions

The MSI Bravo 15 features a full-size 4-Zone RGB Backlit Keyboard with a Numpad. You can customize the backlighting effects through MSI's utility software. Function keys (F1-F12) provide quick access to system settings when pressed in combination with the Fn key.



Top-down view of the laptop's keyboard, highlighting the 4-Zone RGB backlighting and Numpad.

## 2. Touchpad Usage

The integrated touchpad supports multi-touch gestures for navigation. Refer to Windows settings for customizing touchpad sensitivity and gestures.

## 3. Display Features

The laptop is equipped with a 15.6-inch Full HD (1920 x 1080) IPS display with a 144Hz refresh rate and anti-glare coating. This display provides smooth visuals and reduced reflections for an enhanced viewing experience.

## 4. Camera

A 720p HD camera is integrated for video conferencing and other applications requiring a webcam.

## 5. Audio

The laptop features built-in speakers for audio output and a combo jack for connecting external headphones or a microphone.

## 6. Connectivity

The MSI Bravo 15 supports Intel Wi-Fi 6E AX211 (2x2) for high-speed wireless internet access and Bluetooth 5.2 for connecting wireless peripherals.

# MAINTENANCE

---

## 1. Cleaning Your Laptop

- **Screen:** Use a soft, lint-free cloth lightly dampened with water or a screen cleaner. Avoid harsh chemicals.
- **Keyboard and Chassis:** Use a soft brush or compressed air to remove dust. Wipe surfaces with a slightly damp, soft cloth.

## 2. Battery Care

The laptop is equipped with a 53.5Wh Lithium-Ion battery, providing up to 6 hours of battery life. To prolong battery lifespan:

- Avoid extreme temperatures.
- Do not fully discharge the battery frequently.
- If storing the laptop for an extended period, ensure the battery is charged to around 50-60%.

## 3. Software Updates

Regularly update your Windows 11 Pro operating system and device drivers to ensure optimal performance, security, and compatibility. Check the MSI official website for the latest driver updates for your model.

# TROUBLESHOOTING

---

This section addresses common issues you might encounter. For more complex problems, refer to the MSI support website.

- **Laptop does not power on:** Ensure the AC adapter is securely connected to both the laptop and a working power outlet. Try a different outlet. If the battery is completely drained, it may take a few minutes to respond after connecting power.
- **Display is blank or flickering:** Check if the laptop is connected to an external monitor. Press Fn + F2 (or the appropriate function key for display toggle) to switch display modes. Ensure graphics drivers are up to date.
- **Wi-Fi connection issues:** Verify that Wi-Fi is enabled in Windows settings. Restart your router and the laptop. Check for updated Wi-Fi drivers.

- **Keyboard or touchpad not responding:** Restart the laptop. Ensure no external devices are interfering. Check for driver updates for the keyboard and touchpad.

## SPECIFICATIONS

Feature	Specification
Brand	msi
Model Name	Bravo 15
Model Number	C7VFKP
Screen Size	15.6 Inches
Display Resolution	1920 x 1080 (FHD)
Refresh Rate	144 Hz
CPU Model	AMD Ryzen 9 7940HS (8-Core, up to 5.2 GHz)
Graphics Coprocessor	NVIDIA GeForce RTX 4060 with 8GB GDDR6
RAM Memory Installed Size	64 GB DDR5 5600 MHz
Hard Disk Size	2 TB NVMe M.2 SSD
Operating System	Windows 11 Pro
Wireless Connectivity	Wi-Fi 6E AX211 (2x2), Bluetooth 5.2
Ports	1x USB-C 3.2 Gen 1 (DP 1.4), 2x USB 3.2 Gen 1, 1x USB 2.0, 1x RJ-45, 1x HDMI 2.1, 1x Headphone/Mic Combo
Battery	53.5Wh Lithium-Ion (up to 6 hours)
Dimensions (L x W x H)	14.13" x 10.20" x 0.98"
Weight	4.96 lbs
Keyboard	4-Zone RGB Backlit with Numpad

## WARRANTY INFORMATION

Your MSI Bravo 15 Gaming Laptop is covered by a manufacturer's warranty. The specific terms and duration of the warranty may vary by region and retailer. Please retain your proof of purchase for warranty claims. For detailed warranty information, refer to the warranty card included with your product or visit the official MSI website.

## SUPPORT

For technical assistance, driver downloads, or further product information, please visit the official MSI support website. You can typically find FAQs, troubleshooting guides, and contact information for customer service there.

**MSI Support Website:** [www.msi.com/support](http://www.msi.com/support)

