Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE MR25GA AKB76046603

XINFUTE MR25GA AKB76046603 LG 2025 Magic Voice TV Remote Control Instruction Manual

Model: MR25GA AKB76046603 | Brand: XINFUTE

1. Product Overview

The XINFUTE MR25GA AKB76046603 is a replacement Magic Voice TV Remote Control designed for compatibility with various LG 2025 TV series, including OLED G5, C5, B5 series, QNED 92A, 85A, 80A Series, and UA77 Series. This remote features intelligent voice recognition, intuitive mouse-like pointing, and wheel control for enhanced navigation.



Image 1: Front view of the XINFUTE MR25GA Magic Remote Control, showcasing its ergonomic design and primary buttons.



Image 2: Angled view of the XINFUTE MR25GA Magic Remote Control, highlighting the scroll wheel and dedicated app buttons.

2. Setup and Pairing

2.1 Battery Installation

The remote control requires **two AAA batteries** (not included). To install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Slide the battery cover back into place until it clicks securely.




LG Electronics Inc.
Magic Remote
MODEL : MR25GA
R-C-LGE-MR25GA
LG Electronics Inc. Single Point of Contact (EU/UK)
LG Electronics Deutschland GmbH
Alfred-Herrhausen-Allee 3-5,
65760 Eschborn, Germany
AKB76046603
ZG6
MR25



Image 3: Back view of the XINFUTE MR25GA Magic Remote Control with the battery compartment open, showing where to insert AAA batteries.

2.2 Initial Pairing with LG TV

To pair your XINFUTE MR25GA remote control with your compatible LG TV:

1. Ensure your LG TV is powered on.
2. Point the remote control towards the TV.
3. Press and hold the **OK (Wheel) button** on the remote control for approximately 2 seconds.
4. The remote's LED indicator will stay on during the pairing process.
5. Upon successful pairing, the red LED will flash three times, and your TV screen will display a message confirming that the Magic Remote has been successfully registered.

Your browser does not support the video tag.

Video 1: This video demonstrates the initial pairing process of the MR25GA Magic Remote Control with an LG TV, showing how to hold the OK button and the on-screen confirmation.

3. Operating Instructions

3.1 AI Voice Control

The remote features intelligent voice recognition, allowing for hands-free control:

- Press the **AI Voice button** (often indicated by a microphone icon) on the remote.
- Speak your command clearly into the remote. You can adjust the volume, search for movies, or open applications without needing to manually navigate.

3.2 Intuitive Pointer and Wheel Control

Navigate your TV's interface with precision using the pointer and scroll wheel:

- **Pointer Function:** Simply point the remote at the TV screen, and a cursor will appear. Move your wrist to guide the cursor and select items.
- **Scroll Wheel:** Use the central scroll wheel to quickly scroll through menus, web pages, or lists of content. Press the wheel to confirm selections (acting as the OK button).

3.3 Dedicated App Buttons

Access popular streaming services and features instantly with dedicated buttons:

- Press buttons like **Netflix**, **Prime Video**, **Disney+**, **LG Channels**, or **Alexa** to launch these applications directly.



Image 4: Side view of the XINFUTE MR25GA Magic Remote Control, illustrating its comfortable grip and button placement.

4. Maintenance

4.1 Battery Replacement

When the remote's performance diminishes or it stops responding, it's time to replace the batteries. Follow the battery installation steps in Section 2.1.

4.2 Cleaning

To clean the remote control, use a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

5. Troubleshooting

5.1 Remote Not Responding

- Check if the batteries are correctly installed and have sufficient charge. Replace them if necessary.
- Ensure there are no obstructions between the remote control and the TV's sensor.
- Try re-pairing the remote control with the TV (see Section 5.2).

5.2 Unpairing and Re-pairing

If the remote control is not functioning correctly or you need to pair it with a different TV, you can unpair it:

1. On the remote, simultaneously press and hold the **Home button** and the **Back button** for approximately 6 seconds.
2. A message indicating "Unpairing" or "Remote registration is disconnected" will appear on the top-right of your TV screen.
3. The red LED on the remote will blink once per second for three times, confirming successful unpairing.
4. Once unpaired, follow the initial pairing steps in Section 2.2 to re-register the remote with your TV.

6. Specifications

Feature	Detail
Model Number	MR25GA AKB76046603
Brand	XINFUTE
Compatible Devices	LG 2025 TV's: OLED G5, C5, B5 series, QNED 92A, 85A, 80A Series, UA77 Series
Power Source	2 x AAA Batteries (not included)
Special Feature	Ergonomic, Intelligent Voice Recognition, Intuitive Mouse-like Pointing and Wheel Control
Product Dimensions	6 x 3 x 1 inches
Item Weight	2.82 ounces

7. Warranty and Support

7.1 Warranty Information

Enjoy a **one-year warranty** on all purchases of this product.

7.2 Customer Support

All goods are inspected before shipment. If you are not satisfied with your purchase, please contact our customer support team within 24 hours of receipt for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FT84W1GK

More documents and user manuals: **https://manuals.plus/**