

[Manuals.plus](#) /

› [Briloner](#) /

› BRILONER LED Ceiling Light, Model 3952034, Coffee 78 cm Instruction Manual

Briloner 3952034

BRILONER LED Ceiling Light Instruction Manual

Model: 3952034 (Coffee, 78 cm)

1. PRODUCT OVERVIEW

This manual provides instructions for the BRILONER LED Ceiling Light, Model 3952034. This modern ceiling light features a warm white LED light source and a sleek design with coffee-colored angle profiles, suitable for various indoor spaces.




Figure 1: BRILONER LED Ceiling Light, Coffee 78 cm

Key Features:

- **Pleasant Warm White Light:** Equipped with a 22.5W LED board (2,400lm, 3,000K), providing homogeneous and warm light for a comfortable ambiance.
- **Quality Materials:** Constructed from a blend of polycarbonate (PC) and metal, ensuring an elegant and durable finish.
- **Versatile Application:** Suitable for use in living rooms, hallways, offices, or kitchens as decorative or functional lighting.
- **Compact and Modern Design:** Dimensions of 78.5L x 16W x 7.5H cm allow for discreet integration into various interior styles.

2. SAFETY INSTRUCTIONS

Please read these safety instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- Installation must be performed by a qualified electrician in accordance with local wiring regulations.
- Ensure the main power supply is switched off at the circuit breaker before installation or maintenance.
- Do not connect the fixture to a dimmer switch unless explicitly stated as compatible.
- This product is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- Do not attempt to modify or disassemble the LED module.
- Keep packaging materials out of reach of children.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- BRILONER LED Ceiling Light (Model 3952034)
- Mounting material (screws, wall plugs)
- Instruction Manual (this document)

If any parts are missing or damaged, please contact customer support before proceeding.

4. SETUP AND INSTALLATION


Follow these steps for safe and proper installation of your BRILONER LED Ceiling Light.

4.1 Tools Required (Not Included)

- Screwdriver (Phillips head)
- Drill with appropriate drill bit for wall plugs
- Pencil
- Measuring tape
- Wire strippers
- Voltage tester

4.2 Installation Steps

1. **Turn off Power:** Before starting, ensure the main power supply to the installation area is switched off at the circuit breaker. Use a voltage tester to confirm the power is off.
2. **Mark Drilling Points:** Hold the mounting bracket (part of the light fixture) against the ceiling at the desired installation location. Use a pencil to mark the drilling points.
3. **Drill Holes:** Drill holes at the marked points. Insert the provided wall plugs into the drilled holes.
4. **Secure Mounting Bracket:** Align the mounting bracket with the wall plugs and secure it to the ceiling using the provided screws. Ensure it is firmly attached.
5. **Electrical Connection:** Connect the household electrical wires to the terminal block on the light fixture. Ensure correct polarity (Live to Live, Neutral to Neutral, Earth to Earth). If unsure, consult a qualified electrician.
6. **Attach Light Fixture:** Carefully attach the main body of the ceiling light to the secured mounting bracket. Ensure all wires are tucked safely inside the fixture and not pinched.
7. **Final Check:** Double-check all connections and ensure the fixture is securely mounted.
8. **Restore Power:** Turn the main power supply back on at the circuit breaker.



Maße in mm
Dimensions in mm

Figure 2: Product dimensions (785mm x 160mm x 75mm)



Figure 3: Illustration of warm white light output and side profile

5. OPERATING INSTRUCTIONS

The BRILONER LED Ceiling Light is designed for simple operation.

1. **Power On/Off:** Once installed and connected to the main power supply, operate the light using your standard wall switch.
2. **Light Output:** The fixture provides a consistent warm white light (3000K) at 2400 lumens. It is not dimmable unless connected to a compatible external dimmer (not included and must be installed by a qualified electrician).

6. MAINTENANCE

To ensure the longevity and optimal performance of your LED ceiling light, follow these maintenance guidelines:

- **Cleaning:** Disconnect power before cleaning. Wipe the fixture with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or electrical components.

- **LED Module:** The LED module is integrated and not user-replaceable. Do not attempt to open or service the LED components.
- **Inspection:** Periodically check the fixture for any signs of damage or loose connections. If any issues are found, disconnect power and consult a qualified electrician.

7. TROUBLESHOOTING

If you encounter issues with your BRILONER LED Ceiling Light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	◦ No power supply. ◦ Loose electrical connection. ◦ Faulty wall switch.	◦ Check circuit breaker. ◦ Ensure all wires are securely connected (power off first). ◦ Test the wall switch with another appliance.
Light flickers.	◦ Loose connection. ◦ Incompatible dimmer switch.	◦ Check all electrical connections (power off first). ◦ Ensure no dimmer switch is used unless explicitly compatible.
Light is dim.	◦ Not designed for dimming. ◦ Dust accumulation.	◦ This model provides a fixed light output. ◦ Clean the fixture (power off first).

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Model Number	3952034
Brand	Briloner
Dimensions (L x W x H)	78.5 x 16 x 7.5 cm
Weight	850 grams
Color	Coffee
Material	Polycarbonate (PC), Metal
Light Source Type	Integrated LED
Wattage	22.5 Watts
Luminous Flux	2400 Lumens
Color Temperature	3000K (Warm White)
Power Source	Corded Electric
Indoor/Outdoor Use	Indoor
Water Resistance Level	Not Waterproof
Energy Efficiency Class	F

Assembly Required	No (Mounting required)
Country of Origin	China

9. WARRANTY AND SUPPORT

BRILONER products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Briloner website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Briloner customer service. Have your model number (3952034) and purchase date ready when contacting support.

Contact Information: Please refer to the Briloner official website or your purchase documentation for the most up-to-date contact details.

© 2026 Briloner. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question