



[Manuals.plus](#) /

› [WANBO](#) /

› Wanbo Cube 2 Pro Smart Projector User Manual

WANBO Cube 2 Pro

Wanbo Cube 2 Pro Smart Projector User Manual

Model: Cube 2 Pro | Brand: WANBO

INTRODUCTION

The Wanbo Cube 2 Pro is a smart home cinema projector that combines sophisticated design with intelligent functionality. This mini projector features automatic ToF correction for precise focus and alignment in under a second, eliminating manual adjustments. Its compact design allows for vertical storage, making it suitable for small spaces. Equipped with advanced WiFi and Bluetooth connectivity, integrated Android TV, and an 8-watt speaker, it provides seamless entertainment. The 230° rotating base offers versatile placement options. The Cube 2 Pro delivers high-quality home cinema performance in a compact form.



Figure 1: Front view of the Wanbo Cube 2 Pro Smart Projector.

WHAT'S IN THE BOX

Please check the package contents upon unboxing:

- Wanbo Cube 2 Pro Projector
- Remote Control
- AC Power Cable
- User Manual

SETUP GUIDE

1. Initial Placement and Power Connection

Place the projector on a stable, flat surface. The 230° rotating base allows for flexible projection angles onto walls or ceilings. Connect the AC power cable to the projector's power input port and then to a power outlet.




Figure 2: Rear view of the projector with power and HDMI ports.

2. Powering On and Automatic Adjustment

Press the power button on the projector or the remote control to turn it on. The projector will automatically perform ToF (Time-of-Flight) auto-focus and keystone correction. This process ensures a clear and properly aligned image in less than one second, eliminating manual adjustments.



Figure 3: Projector angled for flexible projection.

3. Network and Bluetooth Connection

- **Wi-Fi:** Navigate to the settings menu on the Android TV interface, select Network & Internet, and connect to your Wi-Fi network.
- **Bluetooth:** For connecting external audio devices or using the projector as a standalone Bluetooth speaker, go to Bluetooth settings and pair your device.

OPERATING INSTRUCTIONS

1. Navigating Android TV

The projector comes with integrated Android TV. Use the provided remote control to navigate the interface. You can

access pre-installed apps like Netflix and YouTube, or download more from the Google Play Store.



Figure 4: Top view of the projector with control buttons.

2. Adjusting Projection

The projector features multi-point sensors that automatically adjust image clarity and alignment as you move it. For manual adjustments, if needed, refer to the display settings within the Android TV interface.

3. Using as a Bluetooth Speaker

When not projecting, the device can function as a standalone 8-watt Bluetooth speaker. Activate Bluetooth mode through the settings or a dedicated button (if available) and connect your audio source.

4. Connecting External Devices

Use the HDMI port to connect external devices such as laptops, gaming consoles, or Blu-ray players. Select the

appropriate HDMI input source from the Android TV menu.

MAINTENANCE

1. Cleaning the Lens

Gently wipe the projector lens with a soft, lint-free cloth specifically designed for optical surfaces. Do not use abrasive cleaners or excessive force.

2. Cleaning the Exterior

Wipe the exterior of the projector with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals.

3. Storage

When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. Its compact design allows it to be stored vertically like a book.

TROUBLESHOOTING

- **No Power:** Ensure the AC power cable is securely connected to both the projector and the power outlet. Check if the power outlet is functional.
- **No Image:** Verify that the projector is powered on. If using an external device, ensure it is connected via HDMI and the correct input source is selected on the projector.
- **Blurry Image:** The projector features automatic focus. If the image remains blurry, try moving the projector slightly or restarting it. Ensure the lens is clean.
- **No Sound:** Check the volume settings on both the projector and any connected external devices. If using Bluetooth, ensure the device is properly paired.
- **Remote Control Not Responding:** Check the battery in the remote control (1 AAAA battery required). Ensure there are no obstructions between the remote and the projector.
- **Android TV Freezing:** If Android TV becomes unresponsive, try restarting the projector. Ensure a stable Wi-Fi connection.

SPECIFICATIONS

Model Number	6970885351044
Brand	WANBO
Dimensions (L x W x H)	11.1 x 11.6 x 21.2 cm
Weight	1.4 kg
Display Technology	LED
Native Resolution	1920 x 1080 (Full HD)
Brightness	2000 lm
Projection Distance	1.2 - 3.5 Meters

Connectivity	Bluetooth, HDMI, Wi-Fi
Operating System	Android TV
Audio Output	8-watt Built-in Speaker
Power Consumption	50 watts
Remote Battery Type	1 AAAA (not included)

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official WANBO website or contact your retailer. Keep your purchase receipt for warranty claims.

Manufacturer: Wanbo

ASIN: B0FT8R519V