

## Ufree AMU-3126-Q311

# Ufree Foil Shaver (Model AMU-3126-Q311) Instruction Manual

Your guide to optimal grooming with precision and comfort.

[Introduction](#) [Safety](#) [Contents](#) [Overview](#) [Setup](#) [Operation & Support](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#)

## 1. INTRODUCTION

Thank you for choosing the Ufree Foil Shaver (Model AMU-3126-Q311). This electric razor is designed to provide a smooth and comfortable shaving experience for men, whether used wet or dry. It features a 3-blade floating system, a powerful 8,500 RPM motor, two speed modes, an LED display, and is IPX7 waterproof for easy cleaning. Please read this manual thoroughly before first use to ensure proper operation and maintenance.

## 2. IMPORTANT SAFETY INFORMATION

- Do not immerse the charging cable or adapter in water.
- Keep the shaver away from children.
- Ensure the charging port is dry before connecting the charging cable.
- Do not disassemble or attempt to repair the shaver yourself. Contact customer support for assistance.
- Avoid using the shaver if the foil head is damaged, as this may cause skin irritation or injury.
- This appliance is intended for shaving facial hair only.

## 3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Ufree Foil Shaver Unit
- USB Charging Cable
- Cleaning Brush
- Magnetic Protective Cover
- Storage Bag
- Instruction Manual

**Video 1:** Unboxing the Ufree Foil Shaver. This video demonstrates the contents of the package, including the shaver unit, charging cable, cleaning brush, magnetic protective cover, and storage bag.

## 4. PRODUCT OVERVIEW

The Ufree Foil Shaver is engineered for a superior shaving experience. Familiarize yourself with its key components:

1. **3-Blade Floating System:** Adapts to facial contours for a close shave.
2. **Middle Trimmer:** Pre-trims longer or flat-lying hairs.
3. **Pop-Up Trimmer:** Integrated for precise edging of sideburns and mustache lines.
4. **Power Button:** Turns the shaver On/Off and switches between speed modes.
5. **LED Display:** Shows battery percentage and speed mode.
6. **Swivel Head Lock/Unlock:** Allows the shaver head to swivel or remain fixed.
7. **Magnetic Protective Cover:** Secures the shaver head for storage and travel.
8. **USB-C Charging Port:** Located at the bottom for convenient charging.



Image 1: The Ufree Foil Shaver highlighting its 3D floating blade system for an ultra-close shave.

# Gentle on Skin

Smooth, continuous cutting at 8,500 RPM for a gentler, skin-friendly shave



**Image 2:** Close-up of the shaver head, illustrating the pressure-responsive blades and the long-hair trimmer for a skin-friendly shave.



**Image 3:** A user demonstrating the integrated pop-up trimmer for precise edging of mustaches and sideburns.

## 5. SETUP

### 5.1 Initial Charging

Before first use, fully charge your Ufree Foil Shaver. A full charge takes approximately 1.5 hours and provides up to 60 minutes of runtime.

1. Connect the USB charging cable to the charging port at the bottom of the shaver.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer USB port.
3. The LED display will show the charging progress. Once fully charged, the display will indicate 100%.



**Image 4:** The Ufree Foil Shaver connected to its charging cable, with the LED display showing battery status and charging reminder.

## 5.2 Attaching/Detaching the Magnetic Protective Cover

The shaver comes with a magnetic protective cover for the foil head.

- To attach: Align the cover with the shaver head and it will snap into place magnetically.
- To detach: Gently pull the cover away from the shaver head.



## Magnetic Protection Cover

Secure magnetic fit for easy protection and storage

Image 5: Exploded view of the Ufree Foil Shaver showing the magnetic protection cover and how it secures the shaver head.

## 6. OPERATING INSTRUCTIONS


### 6.1 Power On/Off and Speed Modes

- To turn On/Off: Press and hold the power button for 2 seconds.
- To switch speed modes: Briefly press the power button while the shaver is on. The LED display will indicate the current speed mode (Low/High).

### 6.2 Shaving

The Ufree Foil Shaver supports both wet and dry shaving.

- **Dry Shaving:** For a quick shave, ensure your face is clean and dry.
- **Wet Shaving:** For a more comfortable shave, apply shaving foam or gel to your face.
- Hold the shaver at a right angle to your skin and move it against the direction of hair growth.
- Use gentle pressure and stretch your skin with your free hand to ensure a close shave.




**Image 6:** Demonstrates the Ufree Foil Shaver's versatility for both dry and wet shaving, highlighting its IPX7 waterproof design.

### 6.3 Using the Pop-Up Trimmer

The integrated pop-up trimmer is ideal for detailing and shaping.

- Slide the trimmer release button upwards to activate the pop-up trimmer.
- Use the trimmer to define sideburns, trim mustaches, or clean up necklines.
- After use, push the trimmer release button downwards to retract the trimmer.



**Image 7:** A close-up of the Ufree Foil Shaver's pop-up trimmer, useful for precise beard and sideburn trimming.

### 6.4 Swivel Head Function

The shaver head can be locked or unlocked to suit your preference.

- To allow the head to swivel: Ensure the lock switch is in the unlocked position.
- To fix the head: Slide the lock switch to the locked position. This is useful for precise areas.

## 7. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and hygiene.

### 7.1 Daily Cleaning

The Ufree Foil Shaver is IPX7 waterproof and can be rinsed under running water.

1. Turn off the shaver.
2. Remove the magnetic shaver head.
3. Tap out any loose hair clippings.
4. Rinse the shaver head and the main body under running water.

5. Use the provided cleaning brush to remove stubborn hair particles from the blades and foils.
6. Allow all parts to air dry completely before reattaching the head and storing.



**Image 8:** Visual guide on how to easily clean the Ufree Foil Shaver by removing the magnetic head, brushing away hair, rinsing, and reattaching.

## 7.2 Storage

- Always ensure the shaver is clean and dry before storing.
- Place the magnetic protective cover over the foil head.
- Store the shaver in the provided storage bag to protect it from dust and damage.
- Keep the shaver in a cool, dry place, away from direct sunlight and high temperatures.

## 8. TROUBLESHOOTING

If you encounter any issues with your Ufree Foil Shaver, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shaver does not turn on.	Low battery.	Charge the shaver fully.
Poor shaving performance.	Foil head is dirty or worn.	Clean the shaver head thoroughly. Consider replacing the foil head if it's old or damaged.
Shaver pulls hair.	Shaver head is dirty or blades are dull.	Clean the shaver head. Ensure the shaver is fully charged. Replace the foil head if necessary.
LED display not working.	Shaver is off or battery is completely drained.	Turn on the shaver. Charge the shaver.

If the problem persists, please contact Ufree customer support for further assistance.

## 9. SPECIFICATIONS

Feature	Detail
Model Number	AMU-3126-Q311
Product Dimensions	5.08 x 7.4 x 2.56 inches
Item Weight	11.68 ounces
Power Source	Battery Powered (Rechargeable)
Head Type	Foil
Number of Blades	3

Feature	Detail
Motor Speed	8,500 RPM
Waterproof Rating	IPX7 (Fully Washable)
Charging Time	Approx. 1.5 hours
Runtime	Up to 60 minutes
Additional Features	Floating Head, Pivoting Head, Pop-Up Trimmer, LED Display
Blade Material	Stainless Steel

## 10. WARRANTY & CUSTOMER SUPPORT

---

Ufree is committed to providing high-quality products and excellent customer service.

- **30-Day Money Back Guarantee:** If you are not satisfied with your purchase, you may be eligible for a refund within 30 days.
- **1-Year Warranty:** Your Ufree Foil Shaver is covered by a 1-year warranty against manufacturing defects.
- **24/7 Customer Support:** For any questions, concerns, or warranty claims, please contact Ufree customer support.

For more information or to contact support, please visit the [Ufree Store on Amazon](#).