AEROSQUAD Astronaut Costume with LED Helmet

AEROSQUAD Astronaut Costume for Kids with LED Helmet Instruction Manual

Model: Astronaut Costume with LED Helmet

1. Product Overview

This AEROSQUAD Astronaut Costume for Kids provides a detailed astronaut experience, complete with a jumpsuit and an interactive LED helmet. The helmet is designed with features to enhance imaginative play.

Key Features:

- **LED Helmet:** Features integrated LED lights to simulate a space environment.
- **Realistic Design:** Helmet and jumpsuit incorporate details inspired by genuine astronaut equipment.
- **Mission Sounds:** Integrated sound effects simulate mission control communications and launch countdowns.
- **Movable Visor:** The helmet includes a functional, movable visor.
- **Movable Flashlight:** A small, movable flashlight is integrated into the helmet design.





Image 1.1: A child in the AEROSQUAD Astronaut Costume holding the LED helmet.

2. Package Contents

Verify that all items are present in the package:

- 1x Astronaut Jumpsuit
- 1x LED Astronaut Helmet with Movable Visor and Flashlight

3. Assembly and Setup

3.1. Helmet Battery Installation

1. Locate the battery compartment on the helmet (typically at the back or base).
2. Open the compartment cover using a small screwdriver if necessary.
3. Insert the required batteries (e.g., AA or AAA, not included) according to the polarity indicators (+/-).
4. Securely close the battery compartment cover.

3.2. Adjusting Helmet Fit

The helmet features an internal adjustable strap to ensure a comfortable and secure fit for various head sizes.

1. Place the helmet on the wearer's head.
2. Locate the adjustable strap inside the helmet.
3. Tighten or loosen the strap until the helmet fits snugly without being too tight.



Image 3.1: Detailed view of the helmet's interactive features.

4. Operating Instructions

4.1. LED Lights

The helmet is equipped with LED lights around the visor and ears. Locate the power button (often near the base or side of the helmet) to activate the lights. Some models may feature multiple light modes or colors, which can be cycled through by pressing the button repeatedly.

4.2. Mission Sounds

Press the designated sound effect buttons on the helmet to activate various mission control sounds, such as radio communications or launch countdowns. Refer to the helmet's exterior for button labels or icons indicating sound functions.

4.3. Movable Visor

The helmet's visor can be moved up and down. Gently slide the visor along its tracks to open or close it as desired.

4.4. Movable Flashlight

The integrated flashlight can be rotated to direct light. Activate the flashlight using its dedicated button, and adjust its position by gently moving it.



Image 4.1: Children demonstrating the LED helmet's features.

5. Care and Maintenance

5.1. Jumpsuit Care

- **Fabric Type:** Polyester
- **Care Instructions:** Hand Wash Only. Do not bleach. Do not tumble dry. Line dry. Cool iron if needed.

5.2. Helmet Care

- Wipe the helmet surface with a soft, damp cloth. Do not use abrasive cleaners.
- Avoid submerging the helmet in water.
- Remove batteries if the helmet will not be used for an extended period to prevent leakage.

6. Sizing Information

Refer to the size chart below to select the appropriate costume size. Measurements are approximate and intended as a guide.



Image 6.1: AEROSQUAD Astronaut Costume Size Chart.

AEROSQUAD Astronaut Costume Size Chart (Approximate)

Measurement	M (Ages 6-8)	L (Ages 8-10)	XL (Ages 10-12)	XXL (Ages 12-14)
Height (Kid)	4'2"	4'9"	5'4"	5'7"
Weight (Kid)	57 lb	84 lb	106 lb	128 lb

Measurement	M (Ages 6-8)	L (Ages 8-10)	XL (Ages 10-12)	XXL (Ages 12-14)
Body Length	43.6"	46.7"	50.75"	53.9"
Collar Opening	14.5"	15.3"	16.5"	17.4"
Cross Shoulder	14.5"	15.3"	16.5"	17.5"
Bust	34.5"	37"	39"	42.5"
Waist Relaxed	22"	23"	24"	25"
Cuffs	6.5"	6.5"	7"	7.5"
Front Rise	23.4"	25.7"	27.3"	28.7"
Hip	34.5"	37"	39"	41.5"
Inseam	20.2"	21"	23.3"	25.8"
Leg Opening Relaxed	11.6"	13"	13.6"	14.0"

7. Troubleshooting

- **Helmet Lights/Sounds Not Working:**
  - Ensure batteries are correctly installed with proper polarity.
  - Replace old or depleted batteries with new ones.
  - Check for any loose connections in the battery compartment.
- **Helmet Not Fitting Comfortably:**
  - Adjust the internal strap for a snug but comfortable fit.
  - Consider adding soft padding (not included) if the helmet is too loose or causes discomfort.
- **Visor Movement is Stiff:**
  - Ensure no debris is obstructing the visor's tracks.
  - Gently clean the tracks if necessary.

8. Product Specifications

- **Brand:** AEROSQUAD
- **Model:** Astronaut Costume with LED Helmet
- **ASIN:** B0FTK3LQ7D (Parent ASIN), B0CK8PC479 (Current Variant ASIN)
- **Fabric Type:** Polyester
- **Care Instructions:** Hand Wash Only
- **First Available Date:** October 1, 2025

9. Warranty and Support

For any questions, concerns, or support regarding your AEROSQUAD Astronaut Costume, please contact the seller directly through the platform where the purchase was made. Please retain your proof of purchase for any warranty claims or support requests.