Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Houlyn LX410-11

Houlyn LX410-11 Sleep Earbuds User Manual

Model: LX410-11

1. Introduction

Thank you for choosing the Houlyn LX410-11 Sleep Earbuds. These wireless earbuds are designed to provide a comfortable audio experience, particularly for side sleepers, by offering noise cancellation and a secure fit. This manual provides essential information on how to set up, operate, and maintain your earbuds to ensure optimal performance.



Image 1.1: Front and back view of the Houlyn LX410-11 Sleep Earbuds, highlighting their compact and ergonomic design with charging contacts.

2. Setup

2.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. The LED power display on the case will indicate the charging status and battery level. A full charge provides up to 6 hours of listening time for the earbuds, with the charging case extending total listening time to up to 30 hours.



Image 2.1: Visual representation of the earbud and charging case battery life, showing 6 hours per charge and 30 hours total with the case.

2.2 Wearing the Earbuds

Proper fit is crucial for comfort and optimal sound quality, especially for noise attenuation. The LX410-11 earbuds come with various ear tip sizes (Small, Medium, Large) to ensure a secure and comfortable fit.

1. **Select Ear Tips:** Choose the ear tips that best fit your ear canal. Experiment with different sizes for the most comfortable and secure seal.
2. **Insert Earbud:** Point the ear tip downward and gently insert it into your ear canal.
3. **Adjust and Lock:** Twist the earbud slightly to lock it in place, ensuring the wing tip sits comfortably in your outer ear for stability.




Image 2.2: Step-by-step diagram illustrating the correct method for inserting and securing the LX410-11 Sleep Earbuds in the ear.

2.3 Bluetooth Pairing

The LX410-11 earbuds utilize advanced Bluetooth 5.3 technology for a stable and efficient connection.

1. **Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode (indicated by a flashing LED light).
2. **Activate Bluetooth:** On your device (smartphone, tablet, computer), enable Bluetooth.
3. **Select Device:** Search for "LX410" in the list of available Bluetooth devices and select it to connect.
4. **Confirmation:** Once connected, a voice prompt will confirm successful pairing, and the LED light on the earbuds will stop flashing.




Image 2.3: A visual guide demonstrating the one-step Bluetooth connection process for the LX410-11 earbuds with a mobile device.

3. Operating Instructions

The LX410-11 earbuds feature touch controls for various functions.

3.1 Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically power off and begin charging.

3.2 Touch Controls (Binaural Mode)

When both earbuds are in use:

- **Play/Pause:** Double tap either earbud (L/R).
- **Next Song:** Triple tap the Right earbud (R).
- **Previous Song:** Triple tap the Left earbud (L).
- **Answer Call:** Tap once either earbud (L/R).
- **End Call:** Double tap either earbud (L/R).
- **Reject Call:** Long press either earbud for 2 seconds (L/R).
- **Activate Voice Assistant (Siri):** Long press either earbud for 2 seconds (L/R).
- **Sleep Mode On/Off:** Tap four times quickly either earbud (L/R).



Image 3.1: Detailed diagram illustrating the touch control functions for the LX410-11 earbuds when used in Binaural Mode.

3.3 Touch Controls (Single Mode)

When only one earbud is in use:

- **Play/Pause:** Double tap the active earbud (L/R).
- **Answer Call:** Tap once the active earbud (L/R).
- **End Call:** Double tap the active earbud (L/R).
- **Reject Call:** Long press the active earbud for 2 seconds (L/R).
- **Activate Voice Assistant (Siri):** Long press the active earbud for 2 seconds (L/R).
- **Sleep Mode On/Off:** Tap four times quickly the active earbud (L/R).



Image 3.2: Detailed diagram illustrating the touch control functions for the LX410-11 earbuds when used in Single Mode.

3.4 Sleep Mode

The LX410-11 features a dedicated Sleep Mode designed for uninterrupted rest. When activated:

- **No Touch Control:** Prevents accidental touches during sleep.
- **No Low Battery Alerts:** Eliminates disruptive notifications.
- **No Shutdown Alarm:** Ensures continuous playback without sudden power-off sounds.

To activate Sleep Mode, quickly tap either earbud four times in a row. To deactivate, tap four times again. All keys and announcements will return to normal operation.



Image 3.3: Visual representation of the key benefits of Sleep Mode, including no touch control, no low battery alerts, and no shutdown alarm.

4. Maintenance

4.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water, then dry thoroughly before reattaching.
- Use a cotton swab to gently clean the charging contacts on both the earbuds and the case.
- Avoid using abrasive materials, alcohol, or chemical cleaners.

4.2 Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Keep the device in a cool, dry place, away from extreme temperatures and direct sunlight.

5. Troubleshooting

If you encounter issues with your Houlyn LX410-11 Sleep Earbuds, refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing	• Ensure earbuds are charged. • Turn off and on your device's Bluetooth. • Forget "LX410" from your device's Bluetooth list and re-pair. • Place earbuds back in case, close, then reopen to reset.

Problem	Possible Solution
No sound or low volume	• Check device volume and earbud volume. • Ensure earbuds are properly seated in your ears. • Clean ear tips and earbud mesh for any obstructions. • Reconnect the earbuds to your device.
Earbuds not charging	• Ensure charging cable is securely connected to both case and power source. • Clean charging contacts on earbuds and case. • Try a different charging cable or power adapter.
Sleep Mode not activating/deactivating	• Ensure you are tapping four times quickly and consecutively. • Try tapping the other earbud.

If the issue persists after trying these steps, please contact customer support for further assistance.

6. Specifications

Feature	Detail
Model Number	LX410-11
Brand	Houlyn
Connectivity	Bluetooth 5.3
Earbud Battery Life	Up to 6 hours (single charge)
Total Battery Life	Up to 30 hours (with charging case)
Noise Attenuation	NRR -28dB (Passive)
Product Dimensions	2.36 x 2.36 x 1.18 inches
Item Weight	2.89 ounces
UPC	717956556993

7. Warranty and Support

The Houlyn LX410-11 Sleep Earbuds come with a standard manufacturer's warranty. For detailed warranty information, product support, or to report any issues, please refer to the contact information provided with your purchase or visit the official Houlyn website. Please retain your proof of purchase for warranty claims.

© 2025 Houlyn. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FTKGN38W

More documents and user manuals: **https://manuals.plus/**