

[Manuals.plus](#) /

› [Hands Craft](#) /

› Hands Craft Flower Shop DIY Book Nook Kit Instruction Manual

Hands Craft MIN203

Hands Craft Flower Shop DIY Book Nook Kit

Model: MIN203

INTRODUCTION

Welcome to the world of miniature crafting with the Hands Craft Flower Shop DIY Book Nook Kit. This kit allows you to construct a detailed, illuminated miniature flower shop designed to fit perfectly between your books. It features 248 precision laser-cut wooden pieces and touch-sensitive LED lighting to bring your creation to life. This manual provides essential information for assembly, operation, and care of your book nook. Recommended for ages 14 and up.

SAFETY INFORMATION

- **Small Parts:** This kit contains small parts which may pose a choking hazard. Keep out of reach of small children.
- **Batteries:** The LED lighting system requires 2x AAA batteries (not included). Ensure correct battery polarity. Do not mix old and new batteries. Remove batteries if the product is not used for an extended period.
- **Sharp Edges:** Exercise caution when handling laser-cut wooden pieces, as some edges may be sharp.
- **Adhesive:** Glue is required for assembly and is not included. Use a suitable craft adhesive and follow its safety instructions.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Precision pre-cut wooden components (248 pieces)
- Touch-activated LED lighting system
- Illustrated assembly guide
- Tweezers (may be included, check packaging)

Note: 2x AAA batteries and glue are **not** included and must be purchased separately.

SETUP AND ASSEMBLY

Assembly of the Flower Shop Book Nook Kit typically takes 6+ hours. Follow the detailed, illustrated assembly guide provided in

your kit for step-by-step instructions.

1. **Preparation:** Unpack all components. Organize the laser-cut wooden sheets and identify the numbered parts. Prepare your workspace with good lighting and ensure you have glue and 2x AAA batteries ready.
2. **Part Removal:** Carefully remove each wooden piece from its sheet. Use the included tweezers or a craft knife if necessary to ensure clean breaks.
3. **Initial Structure Assembly:** Begin by assembling the main structural elements of the book nook, such as the walls and base, as indicated in the guide.
4. **Interior Details:** Proceed to assemble the interior elements, including shelves, furniture, and decorative items. Pay close attention to the placement of each miniature piece.



Image: The exterior of the Hands Craft Flower Shop Book Nook, showcasing its detailed design.

5. **LED Lighting Installation:** Integrate the touch-activated LED lighting system according to the instructions. Ensure all connections are secure before sealing any sections.
6. **Exterior Decoration:** Attach exterior decorative elements, such as hanging plants and signage.

7. **Final Assembly:** Secure all parts and ensure the structure is stable. Insert 2x AAA batteries into the designated compartment for the LED lights.



Image: The fully assembled Hands Craft Flower Shop Book Nook, illuminated by its LED lights.

Your browser does not support the video tag.

Video: Official product video demonstrating the assembly process and showcasing the completed Hands Craft Flower Shop DIY Book Nook Kit.

OPERATING INSTRUCTIONS

The Hands Craft Flower Shop Book Nook features touch-sensitive LED lighting.

- **Powering On/Off:** Gently touch the designated sensor (refer to your assembly guide for exact location, typically on the top or side) to turn the LED lights on or off.
- **Battery Replacement:** When the lights dim or stop working, replace the 2x AAA batteries in the battery compartment. Ensure proper polarity.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth or a small brush to gently remove dust from the book nook. Avoid using liquids or abrasive cleaners.
- **Storage:** Store the book nook in a dry environment away from direct sunlight and extreme temperatures to prevent warping or fading of materials.
- **Handling:** Handle the assembled book nook with care to avoid damaging delicate miniature components.

TROUBLESHOOTING

- **Lights Not Working:**
 - Check if batteries are inserted correctly with proper polarity.
 - Replace with fresh 2x AAA batteries.
 - Ensure all wiring connections for the LED system are secure as per the assembly guide.
- **Pieces Not Fitting:**
 - Refer to the illustrated assembly guide to confirm you are using the correct pieces for the current step.
 - Ensure pieces are oriented correctly.
 - Do not force pieces; gentle pressure should be sufficient. If a piece is too tight, carefully sand the edges slightly.
- **Missing or Damaged Parts:** If you encounter missing or damaged parts, please contact Hands Craft customer support for assistance.

SPECIFICATIONS

Model Number	MIN203
Brand	Hands Craft
Assembled Dimensions (L x W x H)	5 x 4.1 x 7.2 inches (12.7 x 10.5 x 18.2 cm)
Material	Wood
Number of Pieces	248
Lighting	Touch-activated LED
Batteries Required	2x AAA (not included)
Recommended Age	14+
GTIN/UPC	810101582479

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Hands Craft Flower Shop DIY Book Nook Kit, please refer to the contact information provided in your product packaging or visit the official Hands Craft website. Please retain your proof of purchase for any warranty claims.



