Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- , RAF /
- > RAF R.7937 Multifunctional Health Pot Electric Kettle User Manual

RAF R.7937

RAF R.7937 Multifunctional Health Pot Electric Kettle User Manual

Model: R.7937

1. Introduction

Thank you for choosing the RAF R.7937 Multifunctional Health Pot Electric Kettle. This appliance is designed to prepare a variety of beverages and light meals, including teas, soups, and porridges, with convenience and efficiency. Please read this manual thoroughly before first use to ensure safe operation and optimal performance. Keep this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury, do not immerse the power base, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer support for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- . Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to 'off', then remove the plug from the wall outlet.
- Do not use the appliance for other than intended use.

- Exercise extreme caution when moving an appliance containing hot liquid.
- Ensure the lid is securely closed during operation.
- Do not overfill the kettle beyond the maximum fill line to prevent boiling water from spilling.
- Use only the power base provided with this appliance.

3. PRODUCT OVERVIEW

3.1 Components

- Borosilicate Glass Pot (1.8L capacity)
- Lid
- Power Base with Digital Touch Control Panel
- Power Cord

3.2 Key Features

- 1.8L Borosilicate Glass: Food-grade, heat-resistant, and durable material that preserves natural flavors.
- 20 Smart Cooking Menus: Pre-programmed settings for precise preparation of various items like herbal tea, fruit infusions, soups, porridge, and noodles.
- 800W Rapid Heating: High-efficiency heating element for fast water boiling and even cooking.
- 24-Hour Preset Timer & Keep-Warm Function: Allows for delayed cooking or keeping contents warm for up to 24 hours.
- Boil-Dry & Overheat Protection: Automatic shut-off mechanism activates when water levels are low to prevent damage and ensure safety.
- Digital Touch Control: Easy-to-use interface with an LED display for temperature and timer settings.



Figure 1: RAF R.7937 Health Pot with ingredients, showcasing its transparent glass design and base.



Figure 2: Overview of key features including 800W power, 20 smart menus, 24-hour timer, and borosilicate glass construction.



Figure 3: The health pot positioned on a table, highlighting its sleek design and the integrated control panel on the base.

4. SETUP AND FIRST USE

- 1. **Unpacking:** Carefully remove all packaging materials and inspect the appliance for any damage.
- 2. **Cleaning:** Before first use, wash the glass pot and lid with warm, soapy water. Rinse thoroughly and dry. Wipe the power base with a damp cloth. Do not immerse the power base in water.
- 3. **Placement:** Place the power base on a stable, flat, heat-resistant, and dry surface, away from the edge of the counter.
- 4. **Initial Boil:** Fill the glass pot with clean water up to the MAX line. Place the pot securely on the power base and close the lid. Plug the power cord into a grounded electrical outlet. Boil the water once and discard it. This helps to remove any manufacturing residues.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

- 1. Fill the glass pot with your desired ingredients and water. Ensure the water level is between the MIN and MAX marks.
- 2. Place the pot securely on the power base and close the lid.

- 3. Plug the power cord into a suitable electrical outlet. The display will illuminate.
- 4. Press the 'On/Off' button to activate the appliance.

5.2 Using the 20 Smart Menus

The R.7937 offers 20 pre-programmed functions for various preparations. While specific menu names may vary, common functions include:

- Boil Water: For quick heating of water.
- Herbal Tea: Optimized for brewing various herbal infusions.
- Fruit Tea: Ideal for preparing fruit-based teas.
- Soup: For simmering light soups.
- Porridge: For cooking grains and porridges.
- Noodles: For quick preparation of instant noodles.
- Keep Warm: Maintains the temperature of the contents for an extended period.

To select a menu:

- 1. After turning on the appliance, press the 'Function' button repeatedly to cycle through the available menus. The selected menu will be displayed.
- 2. Once the desired menu is selected, the appliance will automatically begin the cooking process after a few seconds, or you may press 'On/Off' to start immediately.
- 3. Some menus may allow for temperature or time adjustments using the 'Adjust' button. Refer to the display for options.

5.3 Using the 24-Hour Timer and Keep-Warm Function

- **Preset Timer:** To set a delayed start, select your desired function, then press the 'Preset/Timer' button. Use the 'Adjust' button to set the desired delay time (up to 24 hours). Confirm the setting, and the appliance will start automatically after the set time.
- **Keep Warm:** After some cooking programs conclude, the appliance may automatically switch to a 'Keep Warm' mode. This function can also be manually selected as a menu option to maintain the temperature of your beverage or food.



Multifunctional health pot

Rapid heating

Figure 4: Close-up views of the appliance's stainless steel bottom, ergonomic handle, digital control panel, and rapid heating element.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygiene of your health pot.

- 1. **Before Cleaning:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
- 2. **Glass Pot and Lid:** Wash the glass pot and lid with warm, soapy water using a soft sponge or cloth. Rinse thoroughly under running water and dry completely. The glass pot is generally dishwasher safe, but hand washing is recommended to preserve its clarity.
- 3. **Power Base:** Wipe the exterior of the power base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads. Never immerse the power base in water or any other liquid.
- 4. **Descaling:** Over time, mineral deposits (limescale) may build up inside the pot, especially in hard water areas. To descale, fill the pot with a mixture of water and white vinegar (1:1 ratio) or a commercial descaling solution. Boil the mixture, then let it stand for 30 minutes to an hour. Discard the solution, rinse the pot thoroughly several times with fresh water, and wipe dry.
- 5. Storage: Ensure all parts are clean and dry before storing. Store the appliance in a cool, dry place.

7. TROUBLESHOOTING

If you encounter any issues, please refer to the following table before contacting customer support.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the plug is securely in the outlet. Check the power supply. Try a different outlet.
Water not heating.	Kettle not properly seated on base; boil-dry protection activated.	Ensure the pot is correctly placed on the base. If boil-dry protection activated, unplug, let cool, then refill and restart.
Limescale buildup.	Hard water deposits.	Descale the pot as described in the Maintenance section.
Unusual odor during first use.	Manufacturing residues.	This is normal for first use. Perform the initial boil and discard water. The odor should dissipate.

8. Specifications

Feature	Detail
Brand	Generic (RAF R.7937)
Model	R.7937
Capacity	1.8 Liters (1500 Milliliters)
Power / Wattage	800 Watts
Voltage	220 Volts
Material	Borosilicate Glass, Plastic
Auto Shutoff	Yes
Special Features	20 Smart Menus, 24-hour Timer, Boil Dry Protection
Item Weight	1 Kilogram
Item Dimensions (L x W x H)	20 x 15 x 25 cm



Figure 5: Dimensional diagram of the RAF R.7937 Health Pot and its power base.

9. WARRANTY AND SUPPORT

The RAF R.7937 Multifunctional Health Pot Electric Kettle comes with a **3-Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use from the date of purchase.

The warranty does not cover damage resulting from misuse, accident, alteration, neglect, unauthorized repair, or commercial use. Please retain your proof of purchase for warranty claims.

For warranty service or technical support, please refer to your purchase documentation or contact the retailer from whom the product was purchased. Specific contact details for support are typically provided with your product packaging or on the seller's website.





Figure 6: Example of the 3-Year Warranty Certificate provided with the product.



RAF 800W Juicer Extractor R.92817S-110 - Powerful & Quiet Kitchen Appliance

Discover the RAF 800W Juicer Extractor (Model R.92817S-110). Features a powerful yet quiet motor, 600ml capacity, and easy-to-clean design for fresh fruit and vegetable juices. Ideal for home use.



RAF R.8060 Infrared Electric Stove User Manual

Comprehensive user manual for the RAF R.8060 infrared electric stove, covering specifications, features, safe operation, troubleshooting, and maintenance. Includes detailed instructions and safety recommendations.



Ficha Técnica Molinillo de Café RAF 300W - Modelo R.97132-110

Descubre la ficha técnica completa del Molinillo de Café RAF 300W (Modelo R.97132-110). Potente, multifuncional y fácil de usar para moler café, especias y más. Especificaciones detalladas.



Manual de Instrucciones para Batidora de Sobremesa RAF R.6637

Instrucciones detalladas para la limpieza, almacenamiento y operación segura de la batidora de sobremesa RAF R.6637, incluyendo guías de mezcla y precauciones de seguridad.



Máguina Centrífuga Extractora de Jugos RAF R.92811-110 - 800W, 1.5L

Especificaciones técnicas detalladas para la máquina centrífuga extractora de jugos RAF R.92811-110. Cuenta con un motor de 800W, capacidad de 1.5L, 2 velocidades y componentes duraderos de acero inoxidable. Ideal para uso doméstico.



RAF Hair Straightener Brush 45W - Model R.412-110

Technical data sheet for the RAF Hair Straightener Brush, 45W, featuring 5 temperature settings, rapid heating up to 950°F, and ergonomic design. Ideal for thick or rebellious hair.