

**Ikea LAGERGÅNG LED Screen Lamp (Model 00542427)**

# Ikea LAGERGÅNG LED Screen Lamp User Manual

Model: LAGERGÅNG LED Screen Lamp (00542427)

## 1. INTRODUCTION

---

The Ikea LAGERGÅNG LED Screen Lamp is designed to provide targeted illumination for your workspace. This 40 cm lamp features a magnetic attachment for easy mounting on most screens, adjustable light intensity, and a touch-sensitive dimmer. It connects via USB-C and includes integrated cable management to maintain a tidy desk environment. This manual provides instructions for the proper setup, operation, and care of your LAGERGÅNG LED screen lamp.




Figure 1: Ikea LAGERGÅNG LED screen lamp in a typical desk setup.

## 2. IMPORTANT SAFETY INFORMATION

---

Please read all safety instructions before using the product. Keep this manual for future reference.

- Do not expose the lamp to moisture or extreme temperatures.
- Use only with a compatible USB-C power source (5V).
- Do not attempt to disassemble or modify the lamp. This may void the warranty and pose a safety risk.
- Keep out of reach of children.
- Ensure the lamp is securely mounted to prevent accidental falls.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

## 3. PACKAGE CONTENTS

---

Verify that all components are present in the package:

- LED Lamp
- Mounting Bracket
- USB-C Cable

## 4. SETUP INSTRUCTIONS

---

### 4.1 Mounting the Lamp

The LAGERGÅNG lamp features a magnetic attachment system for easy and secure mounting on your screen. The adjustable holder is designed to fit various screen types and sizes.

1. Attach the mounting bracket to the top edge of your monitor. Ensure it is stable and centered.
2. Align the lamp with the magnetic points on the mounting bracket. The lamp will snap into place securely.
3. Adjust the angle of the lamp to direct illumination towards your keyboard area.



Figure 2: Magnetic attachment for secure mounting.

### 4.2 Connecting Power

The lamp is powered via a USB-C connection.

1. Connect the provided USB-C cable to the port on the lamp.
2. Plug the other end of the USB-C cable into a compatible USB-C port on your laptop, monitor, or a USB power adapter (not included).
3. Utilize the integrated cable management system on the mounting bracket to keep the cable tidy and out of the way.



Figure 3: Integrated cable management system.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Power On/Off and Dimming

The LAGERGÅNG lamp features a touch-sensitive dimmer for controlling power and light intensity.

- **To Turn On/Off:** Lightly touch the designated touch area on the lamp.
- **To Adjust Brightness:** The lamp offers three adjustable light intensity levels. Repeatedly touch the touch area to cycle through the brightness settings (Low, Medium, High) and Off.

### 5.2 Adjusting Light Direction

The lamp can be manually adjusted to direct the light precisely where needed.

- Gently pivot the lamp body on its magnetic attachment points to change the angle of illumination.
- Ensure the adjustment is smooth and does not strain the mounting bracket.




Figure 4: Lamp providing glare-free illumination to the workspace.

## 6. CARE AND MAINTENANCE

Proper care ensures the longevity and performance of your LAGERGÅNG LED screen lamp.

- **Cleaning:** Disconnect the lamp from its power source before cleaning. Wipe the lamp and mounting bracket with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Storage:** If storing the lamp for an extended period, ensure it is clean and dry. Store in a cool, dry place away from direct sunlight.

## 7. TROUBLESHOOTING

If you encounter issues with your LAGERGÅNG LED screen lamp, refer to the following common solutions:

- **Lamp not turning on:**
  - Ensure the USB-C cable is securely connected to both the lamp and the power source.
  - Verify that the USB-C power source is functional and providing power (e.g., try connecting another device).
  - Try a different USB-C cable or power port.
- **Dimming function not working:**
  - Ensure you are touching the correct sensor area.
  - Clean the touch sensor area with a dry cloth to remove any dust or debris.
- **Lamp is unstable on the monitor:**
  - Re-position the mounting bracket to ensure it is centered and firmly seated on the monitor.
  - Verify that the lamp is correctly aligned with the magnetic points on the bracket.

## 8. PRODUCT SPECIFICATIONS

Feature	Specification
Model Name	LAGERGÅNG LED Screen Lamp
Model Number	00542427
Dimensions (L x W x H)	40D x 9W x 11H Centimeters
Item Weight	0.3 Kilograms (300 g)
Light Source Type	LED
Lumen Output	370 lumens
Power Source	USB-C (5 Volts)
Control Method	Touch Dimmer (3 Light Intensity Levels)
Mounting Type	Screen Mount (Magnetic Attachment)
Materials	ABS Plastic, Aluminium, Polycarbonate Plastic, Steel
Cord Length	150 cm
Special Features	3 Light Intensity Levels, Cable Management, Dimmable, Magnetic Attachment, USB-C Connector

## 9. WARRANTY AND SUPPORT

For information regarding warranty coverage and customer support, please refer to the documentation provided at the time of purchase or visit the official Ikea website. You may also contact Ikea customer service directly for assistance with product inquiries, technical support, or warranty claims.

**Ikea Customer Service:** Please visit [www.ikea.com](http://www.ikea.com) for local contact information.

© 2025 Ikea. All rights reserved.