

ZAKE ZAKE 4.0-inch IPS MP3 Player

ZAKE 4.0-inch IPS MP3 Player with Bluetooth and WiFi User Manual

Model: ZAKE 4.0-inch IPS MP3 Player

1. INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your ZAKE 4.0-inch IPS MP3 Player. This multi-functional device features Bluetooth and Wi-Fi connectivity, a 4.0-inch 1080P HD full-color screen, and support for various media applications. Please read this manual thoroughly to ensure proper usage and to maximize your experience with the device.



Image 1.1: The ZAKE 4.0-inch HiFi MP3 Player, highlighting its compact design and key features like 80GB storage, Wi-Fi, Bluetooth, Android OS, and a full-touch screen.

2. PACKAGE CONTENTS

Please verify that all items are present in the package:

- ZAKE 4.0-inch IPS MP3 Player
- USB Type-C Charging Cable
- Protective Case

- User Manual (this document)

3. DEVICE OVERVIEW

Familiarize yourself with the physical components of your MP3 player.





Image 3.1: Front view of the ZAQUE MP3 Player, showcasing its 4.0-inch IPS display with various application icons.

Key Components:

- **4.0-inch IPS Touch Screen:** Main display for interaction and content viewing.
- **Power Button:** Located on the side, used for powering on/off, locking/unlocking the screen, and taking screenshots.
- **Volume Buttons:** Located on the side, used to adjust audio volume.
- **USB Type-C Port:** For charging and data transfer.
- **3.5mm Headphone Jack:** For wired audio output.
- **MicroSD Card Slot:** For expandable storage up to 1TB.
- **Built-in Speaker:** For audio playback without headphones.

4. GETTING STARTED (SETUP)

4.1 Charging the Device

Before first use, fully charge the MP3 player. Connect the provided USB Type-C cable to the device and a compatible USB power adapter (not included) or a computer's USB port.

- A full charge provides up to 40 hours of continuous music playback or 3-5 months of standby time.



Image 4.1: The ZAQE MP3 Player connected to a USB Type-C cable for charging, illustrating its 2000mAh battery capacity.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the screen illuminates.
- **To Power Off:** Press and hold the Power button, then select 'Power Off' from the on-screen options.

4.3 Connecting to Wi-Fi

The device supports Wi-Fi for online streaming and app downloads.

1. Go to **Settings > Network & Internet > Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired Wi-Fi network from the list.
4. Enter the password if prompted and tap **Connect**.

4.4 Bluetooth Pairing

Connect to Bluetooth headphones, speakers, or car stereos for wireless audio.

1. Go to **Settings > Connected devices > Bluetooth**.
2. Toggle Bluetooth **On**.
3. Ensure your Bluetooth audio device is in pairing mode.
4. Select your device from the list of available devices to pair.

Wider Bluetooth Compatibility More stable signal, faster connection



Image 4.2: The ZAQE MP3 Player demonstrating Bluetooth connectivity with wireless earbuds, indicating a stable and fast connection.

4.5 Inserting a MicroSD Card

Expand your storage up to 1TB using a MicroSD card (not included).

1. Locate the MicroSD card slot on the device.
2. Gently insert the MicroSD card into the slot until it clicks into place.
3. The device may prompt you to format the card. Follow the on-screen instructions. Formatting will erase all data on the card.

Download whatever you want

Max support up to **1TB** via SD card slot.
Enjoy downloading tons of music, movies, and ebooks




Image 4.3: The ZAQE MP3 Player next to a MicroSD card, illustrating its capability to expand storage up to 1TB for music, movies, and e-books.

5. BASIC OPERATION

5.1 Navigating the Interface

The ZAQE MP3 Player features a 4.0-inch full-touch IPS screen for intuitive navigation.

- **Tap:** Select an item or open an application.
- **Swipe:** Scroll through lists or switch between screens.
- **Pinch-to-Zoom:** Adjust zoom in supported applications.

4.0 inch full touch screen

Running smoothly No lag on touch



Image 5.1: A hand interacting with the 4.0-inch full-touch screen of the ZAQE MP3 Player, demonstrating smooth and responsive operation.

5.2 Music Playback

Enjoy high-fidelity lossless sound with support for various audio formats.

- **Supported Formats:** MP3, OGG, FLAC, AAC, WAV, WMA, APE.
- **Built-in Speaker:** Play music directly without headphones.
- **Features:** Synchronized lyrics display, playlist creation, custom equalizer settings.

HiFi Sound Quality

Supports music formats including:

MP3, OGG, FLAC, AAC, WAV, WMA, APE



Image 5.2: The ZAQE MP3 Player's music playback screen, illustrating its HiFi sound quality and options for sequential play, loop, and shuffle.

5.3 Video Playback

The 4-inch 1080P HD screen supports direct playback of high-definition videos.

- **Supported Formats:** RM, RMVB, FLV, MP4, DAT, MKV, MPG, MOV, TS.
- No format conversion is required for 720P and 1080P videos.

POWERFUL 8 CORES CPU

Enjoy the audio-visual experience the system more energy-efficient
energy-efficient, and more stable



Supports most formats



1080P HD video



2GB RAM+16GB ROM



Video format support: RM、RMVB、MP4、DAT、MKV、MPG、MOV、TS

Image 5.3: The ZAQE MP3 Player displaying a video, emphasizing its powerful 8-core CPU, 1080P HD video support, and 2GB RAM + 16GB ROM for a smooth audio-visual experience.

5.4 Using Pre-installed Applications

The device comes with several mainstream media apps and tools pre-installed.

- **Media Apps:** Spotify, Audible, Amazon Music, Deezer.
- **Tools:** FM Radio, Video Player, Calendar, Recorder, Clock, Sound Recorder, Browser.
- Access these applications from the home screen.

Most Popular APPs

Various types of applications meet your personalization needs



Image 5.4: The ZAQE MP3 Player's screen displaying a variety of popular pre-installed applications such as Spotify, Audible, Amazon Music, Deezer, FM Radio, and a web browser.

5.5 Lock Screen and Screenshot

- **Lock Screen:** Briefly press the Power button to lock the screen and prevent accidental touches. Press again to wake, then swipe to unlock.
- **Screenshot:** Press and hold the Power button to capture a screenshot.

6. ADVANCED FEATURES

6.1 Offline Playback via HiByMusic

The built-in HiByMusic app allows for offline playback of downloaded music and video files.

- Transfer music or video files from your PC to the player's internal 80GB storage (2GB RAM + 16GB ROM + 128GB card) or an inserted MicroSD card.
- Open the HiByMusic app to access and play your local media library without a network connection.



Image 6.1: The ZAQE MP3 Player showcasing its 80GB built-in storage and 1TB expandable memory, capable of storing approximately 32,000 lossless quality songs or 100 movies.

6.2 HiFi Sound Settings

Customize your audio experience:

- Access the equalizer settings within your music player application to adjust bass, treble, and other audio frequencies.
- Experiment with different presets or create your own custom sound profile.

7. MAINTENANCE

7.1 Battery Care

- Avoid extreme temperatures, which can degrade battery life.
- For long-term storage, charge the device to about 50% and store it in a cool, dry place.
- Use only the provided USB Type-C cable for charging.

7.2 Cleaning

- Use a soft, lint-free cloth to clean the screen and body of the device.
- Do not use abrasive cleaners or solvents.

7.3 Storage Management

- Regularly check the available storage space in **Settings > Storage**.
- Delete unnecessary files or applications to free up space.
- Utilize the MicroSD card for large media files to preserve internal memory.

8. TROUBLESHOOTING

This section addresses common issues you might encounter.

Issue	Possible Solution
-------	-------------------

Issue	Possible Solution
Device does not power on.	Ensure the device is fully charged. Connect to a power source and try again.
Cannot connect to Wi-Fi.	Check if Wi-Fi is enabled in settings. Verify the Wi-Fi password. Restart your router and the MP3 player.
Bluetooth connection is unstable or drops.	Ensure the MP3 player and Bluetooth device are within close proximity. Disconnect and re-pair the devices. Avoid obstacles between devices.
Low audio volume.	Adjust the volume using the side buttons. Check volume settings within the music application. Ensure headphones are properly connected or Bluetooth volume is maximized.
Difficulty downloading music or apps.	Ensure a stable Wi-Fi connection. Check available storage space. Some services may require a subscription.
Forgot screen lock password.	Contact ZAQE customer support for assistance with password recovery.

9. SPECIFICATIONS

Technical details of the ZAQE 4.0-inch IPS MP3 Player.

Feature	Detail
Model	ZAQE 4.0-inch IPS MP3 Player
Display	4.0-inch IPS HD Full-Color Touch Screen
Processor	Advanced 8-Core CPU
Operating System	Android 9.0 OS
Memory	2GB RAM + 16GB ROM (Internal)
Expandable Storage	Up to 1TB via MicroSD card
Connectivity	Bluetooth, Wi-Fi
Battery	2000mAh (Type-C rechargeable)
Music Playback Time	Up to 40 hours
Standby Time	3-5 months
Supported Audio Formats	MP3, OGG, FLAC, AAC, WAV, WMA, APE
Supported Video Formats	RM, RMVB, FLV, MP4, DAT, MKV, MPG, MOV, TS (1080P HD)
Dimensions	5.79 x 5.75 x 0.75 inches

Feature	Detail
Item Weight	7.8 ounces
UPC	765826120102

10. WARRANTY AND SUPPORT





For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. For technical support, product inquiries, or assistance with any issues not covered in this manual, please contact ZAQE customer service.



You can also visit the official ZAQE store on Amazon for additional resources and contact options:[ZAQE Amazon Store](#)



© 2025 ZAQE. All rights reserved.

Related Documents - ZAQE 4.0-inch IPS MP3 Player

	<p>ZAQE M505 Pro Digital Player User Manual</p> <p>Comprehensive user manual for the ZAQE M505 Pro digital player, covering setup, features, troubleshooting, and specifications. Learn how to download music, manage playlists, and use various device settings.</p>
	<p>ZAQE M505 Pro Digital Player User Manual</p> <p>Comprehensive user manual for the ZAQE M505 Pro Digital Player, covering setup, features, troubleshooting, and specifications. Learn how to download music, manage settings, and get the most out of your device.</p>
	<p>ZAQE M4 MP3 Player User Manual</p> <p>Comprehensive user manual for the ZAQE M4 MP3 player. Learn about device features, music playback, video, FM radio, Bluetooth connectivity, e-book reading, and specifications.</p>
	<p>ZAQE-A55 Digital Voice Recorder User Manual</p> <p>This user manual provides comprehensive instructions for operating the ZAQE-A55 Digital Voice Recorder, covering basic operations, recording features, music playback, settings, and technical specifications.</p>

<div>USER MANUAL</div> <div></div>	<div>V66 Voice Recorder User Manual</div> <div>User manual for the V66 Voice Recorder by ZAQE, detailing its basic operations, app integration, recording functions, file management, and technical specifications.</div>
<div>USER'S MANUAL</div> <div></div> <div><small>Thanks for choosing LUORAN M4 Pro music player. Before using this device, please read this user manual carefully to make sure that you have properly understood its operation. Please refer to the back of the package for more information and details. For details, please visit our website: www.luoran.com</small></div>	<div>Luoran M4 Pro Music Player User Manual</div> <div>Comprehensive user manual for the Luoran M4 Pro music player, covering key functions, button descriptions, connectivity options for PC and mobile devices, troubleshooting, specifications, warranty information, and safety warnings.</div>