

[Manuals.plus](#) /

› [AGLUCKY](#) /

› AGLUCKY Countertop Portable Ice Maker User Manual

AGLUCKY B0FT7FJT48

AGLUCKY Countertop Portable Ice Maker User Manual

Model: B0FT7FJT48

1. INTRODUCTION

Thank you for purchasing the AGLUCKY Countertop Portable Ice Maker. This appliance is designed to provide convenient and efficient ice production for various settings, including your home, kitchen, office, bar, or party. Please read this manual thoroughly before operating the ice maker to ensure safe and optimal performance. Keep this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before use.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not immerse the power cord, plug, or any part of the appliance in water or other liquids.
- Ensure the appliance is placed on a stable, level surface away from heat sources and direct sunlight.
- Use only potable water in the ice maker.
- Unplug the appliance before cleaning or when not in use.
- Keep children away from the ice maker during operation.
- **DANGER – Risk of Fire or Explosion:** Flammable Refrigerant Used. Do Not Use Mechanical Devices To Defrost Ice Maker. Do Not Puncture Refrigerant Tubing.

3. PRODUCT OVERVIEW

The AGLUCKY Ice Maker is a compact and efficient unit designed for ease of use. It features a transparent lid, allowing you to monitor the ice-making process.



Figure 1: AGLUCKY Countertop Portable Ice Maker. This image shows the overall design of the ice maker, including its transparent lid, control panel, and the ice basket filled with bullet-shaped ice cubes, alongside an ice scoop.

Components:

- **Main Unit:** The primary body of the ice maker.
- **Transparent Lid:** Allows visibility of the ice-making process.
- **Control Panel:** Features buttons for power, ice size selection, and indicator lights.
- **Ice Basket:** Removable basket for collecting ice cubes.
- **Ice Scoop:** For easily serving ice.
- **Water Reservoir:** Internal tank for water supply.
- **Drain Plug:** Located at the bottom for water drainage.

4. SETUP

1. **Unpack:** Carefully remove the ice maker and all accessories from its packaging.

2. **Clean:** Before first use, clean the interior of the ice maker, including the water reservoir, ice basket, and ice scoop, with a mild detergent and warm water. Rinse thoroughly and dry.
3. **Placement:** Place the ice maker on a flat, stable surface, ensuring adequate ventilation around the unit. Avoid placing it near heat sources or in direct sunlight.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.
5. **Fill Water Reservoir:** Open the transparent lid and fill the water reservoir with potable water up to the "MAX" fill line. Do not overfill.

5. OPERATING INSTRUCTIONS

Initial Operation:

1. Ensure the water reservoir is filled.
2. Press the **ON/OFF** button to start the ice-making cycle. The "POWER" indicator light will illuminate.
3. **Select Ice Size:** Press the **SELECT** button to choose between small (S) or large (L) bullet-shaped ice cubes. The corresponding indicator light will illuminate.
4. The ice maker will begin producing ice. The first batch of ice may take slightly longer (approximately 6-12 minutes) and may be smaller or irregular. Discard the first few batches of ice.
5. The "ICE FULL" indicator will light up when the ice basket is full, and the machine will pause operation.
6. The "ADD WATER" indicator will light up when the water level is low, and the machine will pause operation. Add more water to resume.

Portable Countertop Ice Maker

Enjoy the fresh ice anytime



Figure 2: Two Ice Cube Sizes. This image illustrates the two available ice cube sizes: small, suitable for frozen sashimi, and large, ideal for cocktail drinks.

Two Ice Cube Sizes

Choose between small or large ice cubes to suit any drink or occasion.



Small

For Frozen Sashimi



Large

For Cocktail Drinks

Figure 3: Fast Ice Making. This image highlights the ice maker's efficiency, producing ice in 6 minutes and up to 26.5 pounds per day.

Important Notes:

- The ice maker is not a freezer. Ice will slowly melt if left in the basket. For long-term storage, transfer ice to a freezer.
- The melted water will return to the reservoir and be re-used for ice production.
- The unit operates quietly, ensuring a peaceful environment.

Fast Ice Making



6mins



2.6lbs



26.5lbs

Figure 4: Low Noise Operation. This image indicates the ice maker's quiet operation, with a noise level of 35dB.

6. MAINTENANCE AND CLEANING

Self-Cleaning Function:

The AGLUCKY Ice Maker includes a convenient self-cleaning function:

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the **ON/OFF** button for 5 seconds to activate the self-cleaning cycle.
3. The machine will run a cleaning cycle, circulating water through its internal components.
4. Once the cycle is complete, drain the water from the reservoir using the drain plug.



Figure 5: Self-Cleaning Function. This diagram illustrates the process of activating the self-cleaning feature by holding the ON/OFF button for 5 seconds.

General Cleaning:

- Regularly clean the ice basket and ice scoop with warm, soapy water.
- Wipe the exterior of the unit with a soft, damp cloth.
- For thorough cleaning, drain all water from the reservoir and wipe the interior with a clean cloth.
- Ensure all parts are dry before reassembling and storing the unit.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in the reservoir.	Fill the water reservoir to the MAX line.

Problem	Possible Cause	Solution
"ADD WATER" indicator is on.	Water level is too low.	Add water to the reservoir.
"ICE FULL" indicator is on.	Ice basket is full.	Remove ice from the basket.
Ice cubes are too small or irregular.	First cycle, or water temperature is too high.	Discard first few batches. Use colder water for faster and firmer ice.
Machine is noisy.	Normal operation sounds (compressor, water pump).	Ensure the unit is on a stable, level surface. If noise is excessive or unusual, contact support.

8. SPECIFICATIONS

- **Brand:** AGLUCKY
- **Model Name:** Countertop Ice Maker
- **Product Dimensions:** 10.39"D x 8.66"W x 11.22"H
- **Capacity:** 26 Pounds (ice production per day)
- **Wattage:** 150 watts
- **Voltage:** 120 Volts
- **Refrigerant:** R600a
- **Ice Production Time:** 6-12 minutes per batch (8 cubes)
- **Ice Cube Sizes:** Small (S) and Large (L) bullet-shaped ice

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact AGLUCKY customer service directly. Keep your purchase receipt as proof of purchase.
Online Support: Visit the [AGLUCKY Store on Amazon](#) for product information and support resources.

© 2024 AGLUCKY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why does my AGLUCKY HZB-12/H ice maker run for a short time and then show a red 'Ice Full' light when the basket is not full?

When an ice maker indicates the basket is full even when it is empty, it is usually due to a sensor obstruction or environmental interference. For the AGLUCKY HZB-12/H (and related model B0FT7FJT48), please...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B0FV2W4BDZ>

More documents and user manuals: <https://manuals.plus/>