

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Cosco](#) /

› [Cosco Kids Finale DX 2-in-1 Booster Car Seat Instruction Manual](#)

Cosco BC207EPQ

Cosco Kids Finale DX 2-in-1 Booster Car Seat Instruction Manual

Model: BC207EPQ

INTRODUCTION

This manual provides essential information for the safe and proper installation, use, and maintenance of your Cosco Kids Finale DX 2-in-1 Booster Car Seat. Please read all instructions carefully before using the product and keep this manual for future reference. The Finale DX is designed to adapt as your child grows, offering two modes of use: a forward-facing harness booster and a belt-positioning booster.

PRODUCT OVERVIEW

The Cosco Kids Finale DX 2-in-1 Booster Car Seat is a versatile child restraint system. It features a lightweight design for easy transfer between vehicles and a narrow profile that allows for three-across seating in most vehicles. Key features include a 5-point safety harness for younger children and a belt-positioning mode for older children, along with removable, dishwasher-safe cup holders.



Figure 1: Front view of the Cosco Kids Finale DX 2-in-1 Booster Car Seat.

SAFETY INFORMATION

- Always read and follow all instructions in this manual and your vehicle owner's manual.
- Ensure the car seat is properly installed and secured before each use.
- Never leave a child unattended in the car seat.
- The car seat meets or exceeds Federal Safety Standards.
- Do not use this car seat if it has been involved in a moderate to severe crash, even if there is no visible damage.

SETUP AND INSTALLATION

Modes of Use:

- **Forward-Facing Harness Booster:** For children weighing 40-65 lbs and measuring 43.4"-49" in height.
- **Belt-Positioning Booster:** For children weighing 40-100 lbs and measuring 43.4"-52" in height.

General Installation Steps:

1. Place the car seat on the vehicle seat, ensuring at least 80% of the car seat base is on the vehicle seat.
2. Route the vehicle's seat belt through the designated belt path for the chosen mode of use.
3. Buckle the vehicle seat belt and remove all slack to ensure a tight fit. The car seat should not move more than 1 inch side-to-side or front-to-back at the belt path.
4. Attach and tighten the top tether strap to the vehicle's tether anchor point, if applicable for the installation mode.

Visual Guide:

Your browser does not support the video tag.

Video: An overview of the Cosco Finale DX 2-in-1 Booster Car Seat, demonstrating its features and general use. This video provides a visual aid for understanding the product's functionality.



Figure 2: Frontal view of the car seat, highlighting the harness system.

**dishwasher-safe
cup holder**



Figure 3: Side view of the car seat, showing its profile and headrest.



Figure 4: Rear view of the car seat, illustrating the back structure.

OPERATING INSTRUCTIONS

Securing Your Child in Harness Mode:

1. Place your child in the car seat with their back flat against the seat back.
2. Bring the harness straps over your child's shoulders. Ensure the harness straps are at or above your child's shoulders for forward-facing use.
3. Buckle the crotch buckle between your child's legs.
4. Connect the chest clip at armpit level.
5. Tighten the harness straps until snug. Perform the "Pinch Test": if you can pinch any excess webbing at your child's shoulder, the harness is too loose and needs further tightening.



**lightweight and
easy to move
from car to car**

Figure 5: A child properly secured in the car seat using the 5-point harness.



Figure 6: A child demonstrating how to buckle the seat belt in booster mode.

Using in Belt-Positioning Booster Mode:

1. Remove the 5-point harness system as instructed in the full product manual.
2. Place your child in the booster seat.
3. Route the vehicle's lap and shoulder belt over your child and through the designated belt guides on the booster seat.
4. Ensure the lap belt lies low across the hips, touching the thighs, and the shoulder belt rests snugly across the center of the child's shoulder and chest.
5. Buckle the vehicle seat belt and remove all slack.



Figure 7: A child seated in the belt-positioning booster mode, secured by the vehicle's seat belt.

MAINTENANCE

- **Seat Pad:** The removable seat pad is machine-washable and dryer-safe. Refer to the care label for specific washing instructions.
- **Cup Holders:** The removable cup holders are dishwasher-safe for easy cleaning.
- **Harness Straps:** Wipe harness straps with a damp cloth. Do not machine wash or immerse in water, as this may weaken the webbing.
- **Plastic/Metal Parts:** Wipe plastic and metal parts with a damp cloth and mild soap.



Figure 8: The removable cup holder, designed for easy cleaning.

TROUBLESHOOTING

- **Car Seat is Loose After Installation:** Ensure all slack is removed from the vehicle seat belt. Press down firmly on the car seat while tightening the belt. Re-check for movement (should not move more than 1 inch).
- **Harness Straps are Difficult to Adjust:** Check for any twists in the harness webbing. Ensure the harness adjuster strap is pulled straight out from the car seat.
- **Child's Head is Slumping:** Ensure the headrest is adjusted to the correct height for your child. For forward-facing, the harness straps should be at or above the shoulders.
- **Cup Holder Not Fitting:** Ensure the cup holder is correctly aligned with its slot and pushed firmly into place.

SPECIFICATIONS

Feature	Detail
Model Number	BC207EPQ

Feature	Detail
Product Dimensions	18.5 x 17.75 x 18.5 inches
Item Weight	8 pounds
Maximum Weight Recommendation	100 Pounds
Material Type	Polyester
Material Composition	PP: 75%, Poly web thread (harnesses): 6%, Steel: 9%, Aluminum: 0.2%, Polyurethane/Polyester Foam Pad: 9.8%
Number of Reclining Positions	3
Orientation	Forward Facing
Harness Type	5-Point
Installation Type	LATCH, Seatbelt



Figure 9: Product dimensions for the Cosco Kids Finale DX 2-in-1 Booster Car Seat.

WARRANTY AND SUPPORT

For warranty information or product support, please contact Cosco customer service. Details can typically be found on the product's registration card or the manufacturer's official website. Keep your proof of purchase for any warranty claims.

Manufacturer: Cosco