

[Manuals.plus](#) /

› [Wahl Professional](#) /

› Wahl Professional Vanquish Compact Hair Dryer User Manual

## Wahl Professional 3028756

# Wahl Professional Vanquish Compact Hair Dryer User Manual

Model: 3028756

## INTRODUCTION

The Wahl Professional Vanquish Compact Hair Dryer is designed for efficient and comfortable hair drying. This ultra-lightweight digital motor corded dryer features multiple heat and speed settings, along with an auto-clean function for easy maintenance. This manual provides essential information for safe and effective use of your new hair dryer.



LIGHT, QUIET & QUICK DRYING

# Vanquish Compact

DIGITAL MOTOR  
HAIR DRYER

The Vanquish Compact is ultra-light and delivers controlled airflow and efficient power for fast, even hair drying.



Figure 1: Wahl Professional Vanquish Compact Hair Dryer.

## SAFETY INFORMATION

Please read all instructions before using this appliance. Keep this manual for future reference. Always follow basic safety precautions to reduce the risk of fire, electric shock, and injury.

- Do not use near water.
- Unplug when not in use.
- Keep away from children.
- Do not operate with a damaged cord or plug.
- Do not block air openings.

## SETUP

Before first use, ensure all packaging materials are removed. Inspect the hair dryer for any damage. Connect the power cord to a suitable electrical outlet.

## Attaching Nozzles

The Vanquish Compact Hair Dryer comes with magnetic attachments for easy and secure styling. To

attach a nozzle, simply align it with the front of the dryer and it will snap into place magnetically. To remove, gently pull the nozzle away from the dryer.

## THE NEW DRYING STANDARD, NOW EVEN LIGHTER.



Figure 2: Magnetic attachments for the hair dryer.

Your browser does not support the video tag.

Video 1: Demonstrating the attachment and removal of magnetic nozzles on the Vanquish Compact Hair Dryer.

### OPERATING INSTRUCTIONS

The hair dryer features intuitive controls for heat and speed settings, along with a cool shot function.

#### Power On/Off

Press the power button located on the handle to turn the dryer on or off.

#### Heat and Speed Settings

The dryer offers three heat settings and three speed settings. Use the dedicated buttons on the handle to adjust these settings. The dryer includes a memory function, which will recall your last used settings upon powering on.

#### Cool Shot Function

Activate the cool shot button to deliver a burst of cool air. This feature is ideal for setting your hairstyle and adding shine.



## MAGNETIC ATTACHMENTS

Premium magnetic attachments fit securely to the dryer for safe styling

Figure 3: Controls for heat, speed, and cool shot on the handle.

Your browser does not support the video tag.

Video 2: Overview of the Wahl Vanquish Compact Dryer's features and operation.

## MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your hair dryer.

### Auto-Clean Function

The Vanquish Compact Hair Dryer features an auto-clean function. Refer to the specific instructions in the included quick start guide for activating this feature to keep the filter clear of debris.



## MAGNETIC ATTACHMENTS

Premium magnetic attachments fit securely to the dryer for safe styling.

Figure 4: The auto-clean function helps maintain the dryer's performance.

## General Cleaning

Ensure the appliance is unplugged before cleaning. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Dryer does not turn on.	No power supply; faulty outlet.	Check power cord connection. Test outlet with another appliance.
Weak airflow.	Blocked air intake/filter.	Perform auto-clean function or manually clean the filter.
Overheating.	Blocked air intake/filter; prolonged use.	Clean filter. Allow dryer to cool down before resuming use.

## SPECIFICATIONS

**Model:** 3028756

**Brand:** Wahl Professional

**Power:** 1600W

**Motor:** High-speed digital motor

**Heat Settings:** 3

**Speed Settings:** 3

**Special Features:** Cool shot, Memory function, Auto-clean function, Magnetic attachments

**Dimensions:** 8 x 2 x 6 inches

**Weight:** 1.9 Pounds

**Power Source:** Corded Electric

**UPC:** 043917049205



Figure 5: Key features and specifications diagram.

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Wahl Professional website. Keep your purchase receipt as proof of purchase for any warranty claims.