

[Manuals.plus](#) /

> [Roku](#) /

> Roku 32-Inch Select Series 1080p Full HD Smart TV (Model 32R3E5) Instruction Manual

## Roku 32R3E5

# Roku 32-Inch Select Series 1080p Full HD Smart TV Instruction Manual

Model: 32R3E5

## INTRODUCTION

---

This manual provides essential information for setting up, operating, and maintaining your Roku 32-Inch Select Series 1080p Full HD Smart TV. Designed for a delightful streaming experience, this TV offers excellent picture quality, clear sound, and automatic updates. Please read this manual thoroughly before using your television.

## WHAT'S IN THE BOX

---

Verify that all components are present in the packaging:

- Roku 32-Inch Select Series 1080p Full HD Smart TV
- Remote Control
- Stand (2 pieces)
- Stand Screws (4 pieces)
- Power Cable
- User Manual (this document)

# A perfect fit for any smart home



Sports

Search

Streaming Store

Settings

*"Alexa, show me comedies on living room Roku."*



Roku, the Roku logo, Roku Smart Home, and the Roku Smart Home logo are the trademarks or registered trademarks of Roku, Inc. Only supports English language. Apple, Apple Home, AirPlay, and Siri are trademarks of Apple Inc., registered in the U.S. and other countries and regions. The Works with Apple Home badge is a trademark of Apple Inc. Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates. Alexa enabled device is required to work with Alexa. Google and Google Home are trademarks of Google LLC. Third party features and services may be subject to change or removal without notice.

Image: Contents of the Roku TV box, showing the television, remote control, two stand pieces, and four screws.

## SETUP INSTRUCTIONS

### 1. Attaching the TV Stand

1. Carefully place your TV face-down on a soft, clean surface to prevent damage to the screen.
2. Align the stand pieces with the screw holes on the bottom of the TV.
3. Secure each stand piece with two screws using a Phillips head screwdriver. Do not overtighten.

### 2. Connecting Power and Devices

1. Connect the power cable to the TV's power input and then to a wall outlet.
2. Connect your external devices (e.g., cable box, gaming console, Blu-ray player) to the available HDMI ports on the back of the TV. This model features 3 HDMI ports.
3. For older devices, use the AV input ports (yellow, white, red).
4. An optical audio output is available for connecting to soundbars or home theater systems.
5. A USB port is provided for media playback.



Image: Rear view of the Roku TV displaying HDMI, AV, Antenna, USB, Optical, and Headphone ports.

### 3. Initial Power On and Network Connection

1. Press the power button on the remote control or the TV.
2. Follow the on-screen instructions to select your language and connect to your Wi-Fi network.
3. Activate your Roku account or create a new one. This is required to access streaming channels and features.

## OPERATING INSTRUCTIONS

### 1. Roku OS Interface

The Roku OS provides a simple and intuitive home screen for accessing all your entertainment. Easily navigate between streaming apps, live TV, and connected devices.

# Easily discover new favorites

When you're out of old favorite movies and shows, easily find new ones.



What to watch



Save List



Zones / Categories



Recommended





Image: The Roku TV home screen with a menu on the left and app icons on the right, including Netflix, Disney+, Apple TV, and Roku Channel.

## 2. Voice Remote

Your Roku TV comes with a voice remote for convenient control. Use your voice to search for content, launch apps, and control playback.

- **Voice Search:** Press the voice button and speak your command (e.g., "Find comedies," "Open Netflix").
- **App Shortcuts:** Dedicated buttons provide quick access to popular streaming services.
- **Volume Control:** Adjust volume using the side buttons.



## What's in the box

- Roku Select Series 32" FHD TV
- Stands and screws
- Roku Voice Remote with batteries
- Quick Start Guide

Image: Close-up of the Roku Voice Remote, highlighting buttons for TV power, volume, mute, voice search, instant replay, options, and dedicated app shortcuts.

### 3. Streaming Apps and Live TV

Access thousands of streaming channels, including Netflix, Disney+, Hulu, Prime Video, and Apple TV+. The Roku Channel also offers free live TV and on-demand content.

## There's a Roku device for everyone




Image: A vibrant Roku TV home screen displaying a selection of popular streaming applications and recommended shows.

### 4. Picture Settings

Optimize your viewing experience with various picture settings:

- **Roku Smart Picture:** Automatically adjusts picture mode for optimal viewing.
- **Picture Modes:** Choose from presets like Movie, Sports, Vivid, Standard, or Low Power.
- **Customization:** Adjust brightness, contrast, sharpness, color, and tint for a personalized picture.

### 5. Sound Settings

Enhance your audio experience:

- **Dolby Audio:** Enjoy clear speech and louder sound.
- **Sound Modes:** Select from Standard, Dialogue, Movie, Music, or Night mode.
- **Bluetooth Headphone Mode:** Connect your wireless headphones to listen without disturbing others.




Image: A child wearing wireless headphones while watching the Roku TV, demonstrating the Bluetooth Headphone Mode.

### 6. Smart Home Integration

Your Roku TV is compatible with various smart home ecosystems:

- **Voice Control:** Use Roku Voice, Siri, Alexa, or Google Assistant for hands-free control.
- **Apple AirPlay:** Effortlessly share videos, photos, and music from your Apple devices.

# Home sweet home screen

Jump right in with a home screen that easily gets you to what you want to watch fast.



Image: The Roku TV screen displaying smart home compatibility logos for Roku Smart Home, Apple AirPlay, Apple Home, Alexa, and Google Home, with a smart speaker nearby.

## 7. Parental Controls

Manage content access with built-in parental controls, including V-Chip technology, to ensure a safe viewing environment for children.

## OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An overview of the Roku TV OS, demonstrating its user-friendly interface, app selection, and smart features. This video is provided by Roku, Inc.

## SPECIFICATIONS

### Screen Size:

32 Inches

**Resolution:**

1080p Full HD

**Display Technology:**

LED

**Refresh Rate:**

60 Hz

**Special Features:**

Bluetooth Headphone Mode, Dolby Audio, Voice Remote, Roku Smart Picture

**Connectivity Technology:**

Bluetooth, Wi-Fi

**Hardware Interface:**

3 HDMI Ports, 1 USB Port, S/PDIF (Optical Audio Out)

**Operating System:**

Roku OS

**Product Dimensions (D x W x H):**

7.1"D x 28.3"W x 18.4"H

**Item Weight:**

7.7 Pounds (with stand)

**VESA Mount Standard:**

200 x 200 mm

**Model Number:**

32R3E5

**UPC:**

829610009469

## TROUBLESHOOTING

---

If you encounter issues with your Roku TV, please refer to the following common solutions:

- **No Power:** Ensure the power cable is securely connected to both the TV and a working electrical outlet. Try a different outlet.
- **No Picture/Sound:** Verify that the correct input source is selected on your TV. Check all cable connections (HDMI, AV, etc.) for looseness.
- **Remote Not Responding:** Replace the batteries in your remote control. Ensure there are no obstructions between the remote and the TV.
- **Network Connection Issues:** Restart your Wi-Fi router and modem. Go to the TV's Settings > Network > Check connection to diagnose and reconnect.
- **App Not Loading:** Restart the app. If the issue persists, try removing and reinstalling the app from the Roku Channel Store.

For more detailed troubleshooting, visit the official Roku support website.

## MAINTENANCE

---

To ensure the longevity and optimal performance of your Roku TV, follow these maintenance guidelines:

- **Cleaning the Screen:** Gently wipe the screen with a soft, dry microfiber cloth. For stubborn smudges, lightly dampen the cloth with water or a screen-cleaning solution specifically designed for electronics. Do not spray liquid directly onto

the screen.

- **Cleaning the TV Body:** Use a soft, dry cloth to wipe the exterior of the TV. Avoid abrasive cleaners or solvents.
- **Ventilation:** Ensure the TV's ventilation openings are not blocked to prevent overheating. Maintain adequate space around the TV for air circulation.
- **Software Updates:** Your Roku TV automatically receives software updates. Ensure your TV is connected to the internet to receive the latest features and performance improvements.
- **Power Management:** Unplug the TV from the power outlet during lightning storms or when it will be left unattended for long periods.

## WARRANTY AND SUPPORT

---

### Warranty Information

Roku warrants the hardware of this device against defects in materials and workmanship under normal use for a period of one (1) year from the date of purchase ("Warranty Period"). If Roku determines that the device's hardware is defective during the Warranty Period, Roku's sole obligation, and your exclusive remedy, will be to either repair or replace the unit with either a new or rebuilt device, at its option. This warranty applies if the device is used in accordance with the provided documentation.

Important information about warranty returns and replacements is available on the Roku support site. You may also return a device for any reason, subject to the terms of the applicable return policy: 1) Within thirty (30) days from the date of purchase from Roku; or 2) within the applicable return period if purchased from an authorized reseller or distributor. Additional details regarding product returns can be found on the Roku support site.

### Customer Support

For further assistance, technical support, or to access the full range of support resources, please visit the official Roku support website. You can find FAQs, troubleshooting guides, and contact information for customer service there.