

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Roku](#) /

> [Roku Select Series 40-Inch 1080p Full HD Smart TV \(Model 40R3E5\) User Manual](#)

Roku 40R3E5

Roku Select Series 40-Inch 1080p Full HD Smart TV User Manual

Model: 40R3E5 | Brand: Roku




INTRODUCTION

The Roku Select Series 40-Inch 1080p Full HD Smart TV is designed to provide a seamless and enjoyable streaming experience. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your television. Enjoy bright Full HD picture quality, clear sound, and access to a wide range of entertainment options.

WHAT'S IN THE BOX

Verify that all components are present before beginning setup.

- Roku Select Series 40-Inch Full HD TV
- Roku Voice Remote with batteries
- TV Stands and screws
- Power Cable
- Quick Start Guide (this manual)



What's in the box

- Roku Select Series 40" FHD TV
- Stands and screws
- Roku Voice Remote with batteries
- Quick Start Guide

Image: Contents of the Roku TV box, showing the television, remote control, stand components, and power cable.

SETUP

1. Attaching the TV Stand

1. Carefully place the TV screen-down on a soft, clean surface to prevent damage.
2. Align the TV stands with the screw holes on the bottom of the TV.
3. Secure each stand with the provided screws using a Phillips head screwdriver.

2. Wall Mounting (Optional)

This TV supports VESA wall mounts with a standard of 200 x 300 mm. Refer to your wall mount's instructions for proper installation. Ensure the wall mount can support the TV's weight of 10.4 pounds (without stand).

3. Connecting Devices

Your Roku TV offers multiple connectivity options:

- **HDMI:** 3 ports available for connecting gaming consoles, Blu-ray players, or other HDMI-enabled devices. HDMI 1 supports ARC.

- **USB:** 1 USB 2.0 port for media playback or connecting compatible accessories.
- **S/PDIF (Optical):** For digital audio output to a soundbar or home theater system.
- **AV (Composite):** For older devices using red, white, and yellow cables.
- **Antenna/Cable:** For connecting an antenna for over-the-air broadcasts or a cable TV connection.



Image: Rear view of the Roku TV displaying the HDMI, USB, optical, and AV input ports.

4. Power Connection

Connect the provided power cable to the TV and then to a power outlet (110 VAC 60 Hz).

5. Initial Setup and Network Connection

Upon first power-on, follow the on-screen instructions to set up your Roku TV. This includes connecting to your Wi-Fi network (Bluetooth and Wi-Fi connectivity are supported) and linking to a Roku account. Automatic software updates will ensure you have the latest features.

OPERATING INSTRUCTIONS

1. Roku Home Screen Navigation

The Roku home screen provides quick access to all your entertainment. You can easily move apps around to customize your viewing experience.




Image: The Roku TV home screen showing a grid of streaming applications like Netflix, Disney+, and Prime Video, along with navigation menus.

2. Using the Voice Remote

The included Roku Voice Remote allows for easy navigation and control. Use your voice to search across thousands of apps, play entertainment, and control streaming functions. The remote requires 2 AAA batteries.

No-nonsense voice remote



Voice search
& control



TV controls



Simple setup



App
shortcuts




Image: Close-up of the Roku Voice Remote, highlighting buttons for power, volume, voice search, and dedicated app shortcuts.

3. Streaming and Apps

Access a world of entertainment with pre-installed apps like Netflix, Prime Video, Disney+, Hulu, and Apple TV+. The Streaming Store offers thousands more. Roku also provides over 500 free TV channels, including live in-season shows, movies, weather, and local news.

4. Picture Settings

Optimize your viewing experience with various picture settings:

- **Roku Smart Picture:** Automatically cleans up incoming TV signals, optimizes them, and selects the best picture mode.
- **Picture Modes:** Choose from presets like Movie, Standard, Vivid, Sports, or Low Power.
- **Custom Picture:** Adjust backlight, brightness, contrast, sharpness, color, and tint manually.


5. Sound Settings

The Roku TV features Dolby Audio for clear speech and louder sound. Adjust sound modes (Standard, Dialogue, Movie,

Music, Night, Auto) or customize settings for volume mode, speech clarity, bass, and treble.

6. Bluetooth Headphone Mode

Connect your favorite wireless headphones via Bluetooth to enjoy audio privately without disturbing others.



Bright, clear picture

With double the pixels of standard HD, 1080p Full HD resolution offers a sharper, clearer image with better color accuracy.

Image: A person using Bluetooth headphones while watching the Roku TV, illustrating the private listening feature.

7. Smart Home Integration

Enjoy easy voice control with Roku Voice, Siri, Alexa, or Google Assistant. Effortlessly share videos, photos, and music from your Apple devices to your smart TV with Apple AirPlay.

Home sweet home screen

Jump right in with a home screen that easily gets you to what you want to watch fast.




Image: A smart speaker positioned near the Roku TV, illustrating the TV's compatibility with voice assistants like Alexa for smart home control.

8. Sleep Timer

The TV includes a sleep timer function, allowing you to set the TV to automatically turn off after a specified duration (e.g., 30 minutes, 1 hour, 1.5 hours, 2 hours, 3 hours).

MAINTENANCE

To ensure the longevity and optimal performance of your Roku TV, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the screen and TV cabinet. Avoid abrasive cleaners or solvents.
- **Software Updates:** Your Roku TV receives automatic software updates to provide the newest apps and features. Ensure your TV is connected to the internet for these updates.
- **Ventilation:** Ensure adequate ventilation around the TV to prevent overheating. Do not block ventilation openings.

TROUBLESHOOTING

If you encounter issues with your Roku TV, try the following basic troubleshooting steps:

- **No Power:** Check if the power cable is securely connected to both the TV and the power outlet. Try a different outlet.
- **No Picture/Sound:** Verify that the correct input source is selected. Check all cable connections (HDMI, AV, etc.).
- **No Internet Connection:** Restart your Wi-Fi router and modem. Go to Settings > Network > Check connection on your TV to diagnose network issues.
- **Remote Not Responding:** Replace the batteries in the Roku Voice Remote. Ensure there are no obstructions between the remote and the TV.
- **General Issues:** Try restarting the TV by unplugging it from the power outlet for 30 seconds, then plugging it back in.

SPECIFICATIONS

Feature	Detail
Brand	Roku
Model Name	Roku 40" Select Series FHD
Model Number	40R3E5
Screen Size	40 Inches
Display Technology	LED
Resolution	1080p Full HD
Refresh Rate	60 Hz
Special Features	Bluetooth Headphone Mode, Dolby Audio, Voice Remote, Roku Smart Picture
Connectivity Technology	Bluetooth, Wi-Fi, Infrared
Hardware Interface	3x HDMI, 1x USB, S/PDIF (Optical)
Product Dimensions (D x W x H)	7.1"D x 35.1"W x 21.9"H
Item Weight (without stand)	10.4 Pounds
VESA Mount Standard	200 x 300 mm
Operating System	Roku OS
Speaker Output Power	14 Watts
Parental Control Technology	V-Chip
UPC	829610009476

WARRANTY AND SUPPORT

Roku warrants the hardware against defects in materials and workmanship under normal use for a period of one (1) year from the date of purchase ("Warranty Period"), provided it is used in accordance with the provided documentation. If a defect is determined during the Warranty Period, Roku's sole obligation and your exclusive remedy will be to either repair or replace the unit with a new or rebuilt device, at its option.

For important information about warranty returns and replacements, or additional details regarding product returns, please visit the official Roku support site. You may also return a device within thirty (30) days from the date of purchase from Roku, or within the applicable return period if purchased from an authorized reseller or distributor.

OFFICIAL PRODUCT VIDEO

Video: An official product video from Roku, Inc. showcasing the features and user experience of the 2026 Roku TV Select Series.

