

[Manuals.plus](#) /

› [BEWISHOME](#) /

› BEWISHOME 3-Tier Rolling Kitchen Cart Instruction Manual

BEWISHOME 3 Tier Rolling Kitchen Cart

BEWISHOME 3-Tier Rolling Kitchen Cart Instruction Manual

Model: 3 Tier Rolling Kitchen Cart

Brand: BEWISHOME

INTRODUCTION

This BEWISHOME 3-Tier Rolling Kitchen Cart is designed for versatile use in various settings such as kitchens, living rooms, bathrooms, and offices. Its modern industrial design features a durable tabletop and two high-density iron mesh shelves, providing ample storage for appliances, food, or office supplies. Equipped with four 360° swivel lockable casters, the cart offers both mobility and stability.

SAFETY INFORMATION

Ensure all parts are properly secured before use. Do not allow children to play on, with, or around the cart. Always lock the wheels when the cart needs to remain stationary to prevent accidental movement. Do not exceed the maximum weight capacity for each shelf or the tabletop.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. Refer to the included parts list in your package for detailed identification.

- Wooden Top Panel
- Metal Side Frames (4 pieces)
- Mesh Shelves (2 pieces)
- 360° Swivel Lockable Casters (4 pieces)
- S-shaped Hooks (4 pieces)
- Assembly Hardware (bolts, screws, wrench)
- Instruction Manual

Kitchen Rolling Cart



Image: All components of the BEWISHOME 3-Tier Rolling Kitchen Cart laid out for assembly.

SETUP AND ASSEMBLY

Assembly of the BEWISHOME 3-Tier Rolling Kitchen Cart is straightforward and typically takes approximately 20-25 minutes. Follow these steps carefully:

Video: Official assembly guide for the BEWISHOME Rolling Kitchen Cart, demonstrating the unboxing and step-by-step construction process.

Step 1: Unpack and Identify Parts

Carefully remove all components from the packaging. Each piece is securely wrapped to prevent scratches. Lay out all metal frames, wooden top, mesh shelves, wheels, bolts, screws, and S-shaped hooks. Refer to the included manual for a complete parts list.

Step 2: Assemble the Frame

Attach the metal side frames to the wooden top panel using the provided bolts and screws. Ensure all connections are

secure but do not overtighten initially.

3-Tier Multi-Function Storage Rack



Living room



Laundry Storage Rack



Office Supplies Organizer



Balcony storage rack

Image: Assembly in progress, showing metal frames being attached to the wooden top panel.

Step 3: Install Shelves

Slide the two mesh shelves into their designated slots on the assembled frame. Secure them with the remaining bolts and screws. Once all parts are in place, tighten all bolts firmly.




Durable, easy-to-clean tabletop



High-density iron mesh



4-360° swivel castors, all lockable



4 S-shaped Hooks

Image: Mesh shelves being installed into the cart frame.

Step 4: Attach Wheels and Hooks

Screw the four 360° swivel casters into the bottom of the cart's frame. Ensure all wheels are firmly attached. Attach the S-shaped hooks to the side bars for additional hanging storage.

Living Room Storage



Image: Close-up of the cart's wheels and S-shaped hooks.

OPERATING INSTRUCTIONS

The BEWISHOME 3-Tier Rolling Kitchen Cart is designed for ease of use and versatility.

Mobility and Stability

To move the cart, ensure all wheel stoppers are disengaged. The 360° swivel casters allow for smooth movement across various floor surfaces. To keep the cart stationary, press down on the stoppers located on each wheel until they click into place. This locks the wheels, preventing unintended movement.



Image: Close-up of a 360-degree swivel caster with lock and unlock indicators.

Storage Capacity

The top wooden surface can support a maximum weight of 90 lbs. Each mesh shelf can hold up to 60 lbs. Utilize the shelves for appliances like microwaves or toasters, and the S-shaped hooks for hanging utensils or towels. Distribute weight evenly to maintain stability.



Image: BEWISHOME 3-Tier Rolling Kitchen Cart with dimensions and indicated weight capacities for the top (90 lbs) and each shelf (60 lbs).

MAINTENANCE

To ensure the longevity and appearance of your cart, follow these simple maintenance guidelines:

- **Cleaning:** Wipe with a dry cloth to remove dust and spills. For stubborn stains, use a damp cloth with mild soap and dry immediately. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically check all bolts and screws to ensure they remain tight. Retighten as necessary to maintain stability.
- **Wheel Care:** Keep the wheels free of debris to ensure smooth rolling. Lubricate the wheel axles if necessary to prevent squeaking or stiffness.

TROUBLESHOOTING

If you encounter any issues with your BEWISHOME 3-Tier Rolling Kitchen Cart, refer to the following common solutions:

- **Cart is wobbly:** Ensure all bolts and screws are fully tightened. Verify that the cart is on a flat, even surface. Adjust items on shelves to distribute weight evenly.
- **Wheels not rolling smoothly:** Check for debris caught in the casters. Ensure the wheel locks are fully disengaged. Clean and lubricate the wheels if needed.
- **Difficulty assembling:** Review the assembly instructions carefully, paying attention to part numbers and orientation. Do not force parts together; if a part doesn't fit, re-check the steps.

SPECIFICATIONS

Feature	Detail
Product Dimensions	13.38"D x 22.83"W x 30"H
Shelf Type	Tiered Shelf
Material	Metal, Wood
Frame Material	Metal
Brand	BEWISHOME
Manufacturer	BEWISHOME
Included Components	All installation tools
Product Care Instructions	Wipe with Dry Cloth
Maximum Weight Recommendation (Top)	90 Pounds
Maximum Weight Recommendation (Each Shelf)	60 Pounds
Required Assembly	Yes
Color	Brown
Furniture Finish	Brown and black paint
Shape	Rectangular
Style Name	Modern
Item Weight	12.78 Pounds
Number Of Shelves	3

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official BEWISHOME website. You can also visit the [BEWISHOME Store on Amazon](#) for more product information and assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FV8FWBZF>

More documents and user manuals: <https://manuals.plus/>