

[Manuals.plus](#) /

› [Queenmew](#) /

› Queenmew Anti Barking Device (Model B0FV8MPGZB) - User Manual

Queenmew B0FV8MPGZB

Queenmew Anti Barking Device (Model B0FV8MPGZB) - User Manual

Effective and Humane Bark Control for Dogs

INTRODUCTION

The Queenmew Anti Barking Device is designed to help manage and reduce excessive dog barking using safe, dog-friendly ultrasonic technology. This device emits a high-frequency sound, inaudible to most humans, that is intended to deter unwanted barking without causing harm to your dog or other animals. It features multiple modes and an adjustable range to suit various situations and dog temperaments.

100% Safe for Dogs and Human



Stop your neighbors's barking dog ✓

Train dogs not to bark ✓

✓ Automatic detection of dog barking

✓ The ultrasonic frequency can only be heard by dogs

Image: The Queenmew Anti Barking Device placed on the floor in a living room, with a golden retriever and a child nearby. Text on the image highlights "100% Safe for Dogs and Human" and its functions like "Stop your neighbor's barking dog" and "Train dogs not to bark."

PACKAGE CONTENTS

Please check the package to ensure all items are present:

- 1 x Anti Bark Device
- 1 x USB Cable
- 1 x Wrist Strap
- 1 x User Manual
- Mounting Screws and Anchors (typically included for wall mounting)
- Dog Whistle (may be included as an accessory)

① Sonic Bark Deterrent

② Mounting Screws and Anchors

③ Dog Whistle

④ User Manual

⑤ USB Cable



Image: An exploded view of the Queenmew Anti Barking Device package contents, showing the device, USB cable, user manual, mounting screws and anchors, and a dog whistle. Dimensions of the device are also shown.

PRODUCT FEATURES

- **Rechargeable Battery:** Built-in 1500 mAh lithium battery provides up to 30 days of continuous use on a 5-hour charge.
- **Ultrasonic Technology:** Emits safe, dog-friendly sonic waves to deter barking, inaudible to humans.
- **3 Adjustable Modes:** Allows customization of ultrasonic frequency based on dog size and temperament.
- **Effective Range:** Detects barking up to 33 feet (10 meters), with optimal effect within 25 feet.
- **Automatic Detection:** Activates automatically when dog barking is detected and stops when barking ceases.
- **Durable and Waterproof Design:** Suitable for both indoor and outdoor use.
- **Easy Operation:** Simple one-button control and frequency adjustment knob.

SETUP AND INSTALLATION

1. **Charge the Device:** Before first use, fully charge the device using the provided USB cable. Refer to the "Charging and Battery" section for details.

2. **Select Placement:** The device can be hung on a garden fence, tree, table, or dog house. Ensure the sensor faces the direction from which barking typically occurs.
3. **Mounting:** Use the included mounting screws and anchors if you wish to permanently install the device on a wall or fence. Alternatively, place it on a flat surface.
4. **Optimal Positioning:** For best results, place the device within 25 feet of the barking dog. Avoid placing it behind obstacles that could block the ultrasonic waves.

Durable and Waterproof Design

can be hung on the tree, anywhere in the house, outdoors and so on.



Image: The Queenmew Anti Barking Device shown mounted on a tree outdoors, on a white picket fence, and on an indoor wall, illustrating its versatile and waterproof design for various placements.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Locate the ON/OFF switch on the device. Slide it to the "ON" position to activate the device. Slide to "OFF" to power down.
2. **Select Frequency Mode:** Use the adjustable knob to select one of the three ultrasonic frequency modes:
 - **15KHz-30KHz:** Suitable for small dogs.

- **20KHz:** Recommended for docile dogs.
- **30KHz:** Best for large or more persistent barking dogs.

Experiment with different modes to find the most effective setting for your dog.

3. **Automatic Operation:** Once powered on and a mode is selected, the device will automatically detect dog barking within its range and emit the chosen ultrasonic sound. The sound stops when the barking stops.

3 Adjustable Ultrasonic Levels & Up to 33 Feet

Automatically detects dog barking and emits safe ultrasonic sound



Image: The Queenmew Anti Barking Device with an overlay illustrating its 3 adjustable ultrasonic levels (15KHz-30KHz for small dogs, 20KHz for docile dogs, 30KHz for large naughty dogs) and an effective range of up to 33 feet.



Image: A diagram illustrating two modes for the anti-bark device, specifying "Ordinary Ultrasound" at 15-20KHz for small/docile dogs and "Enhanced Ultrasound" at 20-30KHz for large/naughty dogs. The image also features a small dog running.



Image: A diagram illustrating a dog barking with a 30-foot effective range, emphasizing the device's coverage area for bark detection.

CHARGING AND BATTERY

The device is equipped with a built-in 1500mAh rechargeable lithium battery. To charge:

1. Connect the provided USB cable to the charging port on the device.
2. Plug the other end of the USB cable into a compatible USB power source (e.g., charger, power bank, computer USB port, USB socket).
3. The charging indicator light will show the charging status.
4. A full charge typically takes 5 hours and provides approximately 30 days of standby use.

5. **Important:** Do not use the device while it is charging.

Light Indicators:

- **Low Battery:** Flashes red constantly.
- **Stand-by:** Flashes blue once every 6 seconds.
- **Turn On:** Flashes red once and emits one beep sound.
- **Turn Off:** Flashes red twice and emits two beep sounds.
- **Activated (Ultrasonic Emission):** Stays red for 3 seconds with the ultrasonic sound.
- **Charging:** Red light indicates charging.
- **Fully Charged:** Blue light indicates the battery is full.

USB Rechargeable



Built-in 1500mAh rechargeable lithium battery, no battery needed.






Image: The Queenmew Anti Barking Device being charged via a USB cable, with visual cues for "Working/Charging Status: Red Light" and "Standby Status: Blue Light." Various USB power sources like a charger, power bank, computer USB port, and USB socket are also depicted.

IMPORTANT CONSIDERATIONS

For optimal effectiveness and safety, please note the following:

- **Adaptation Period:** Each dog learns at a different pace. Allow your dog up to 2 weeks to adapt to the device.
- **Effective Range:** While the device detects up to 33 feet, the best effect is typically within 25 feet. A smaller range generally yields better results.
- **Obstacles:** Low battery levels and physical obstacles (walls, dense foliage) will decrease the effectiveness of the bark control. Ensure a clear line of sight to the barking dog.
- **Not for All Dogs:** This device may not be suitable for:
 - Dogs with hearing problems.
 - Aggressive or violent dogs.
 - Dogs under 6 months or over 8 years of age.
 - Dogs weighing more than 50 pounds (some sources suggest this, though the product claims "all breeds and sizes").
 - Environments with noisy surroundings that might interfere with bark detection.
 - Situations with two or more dogs together, as it might be difficult to target specific barking.



Works on All Breeds and Sizes



Use it for 6 months to 8 years dogs



Not for dogs with hearing impairment



Not for aggressive fierce dogs



6 Months - 8 Years

Image: The Queenmew Anti Barking Device with text stating "Works on All Breeds and Sizes." Below, it lists conditions where it may not be suitable: "Not for dogs with hearing impairment," "Not for aggressive fierce dogs," and "Use it for 6 months to 8 years dogs." Several small dogs are pictured below.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not turning on.	Battery is depleted.	Charge the device fully (approx. 5 hours).
Device not activating when dog barks.	• Device is out of range. • Obstacles blocking the sensor. • Low battery. • Incorrect frequency mode selected for the dog. • Noisy environment interfering with detection.	• Move the device closer to the dog (within 25 feet). • Ensure a clear line of sight to the dog. • Recharge the device. • Adjust the frequency knob to a different mode. • Relocate the device to a quieter area.
Dog is not responding to the device.	• Dog has hearing problems. • Dog is aggressive or too young/old. • Dog needs more time to adapt. • Incorrect frequency mode.	• Confirm the dog's hearing ability. • Review "Important Considerations" for suitability. • Allow up to 2 weeks for adaptation. • Try different frequency settings.

SPECIFICATIONS

- **Brand:** Queenmew
- **Model:** B0FV8MPGZB
- **Item Weight:** 0.18 ounces (approx. 5g)
- **Package Dimensions:** 4.61 x 3.58 x 2.17 inches
- **Battery:** 1 x Lithium Ion battery (included), 1500mAh
- **Charging Time:** Approximately 5 hours
- **Usage Time:** Up to 30 days (standby)
- **Effective Range:** Up to 33 feet (10 meters)
- **Frequency Modes:** 15KHz-30KHz, 20KHz, 30KHz
- **Color:** Black

WARRANTY AND SUPPORT

Queenmew provides a **1-year warranty** for this product and a **30-day unconditional return policy**. If you encounter any issues or have questions regarding your Anti Barking Device, please do not hesitate to contact our customer support. We are committed to resolving any problems you may experience.

For support, please refer to the contact information provided in your purchase documentation or on the official Queenmew website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FV8MPGZB>

More documents and user manuals: **<https://manuals.plus/>**