

[Manuals.plus](#) /

› [Monster](#) /

› Monster Open Ear AC225 Earbuds User Manual

Monster AC225

Monster Open Ear AC225 Earbuds User Manual

Model: AC225

INTRODUCTION

Thank you for choosing the Monster Open Ear AC225 Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your new earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.




Image: Banner displaying the Monster Open Ear AC225 Earbuds with the brand slogan.

WHAT'S IN THE BOX

Verify that all items are present in your package:

- Open Ear Buds (Left and Right)
- Wireless Charging Case
- User Manual (this document)
- Charging Cable (USB-C)



Image: A pair of Monster Open Ear AC225 Earbuds, showcasing their design.

PRODUCT OVERVIEW

The Monster Open Ear AC225 Earbuds feature an innovative open-ear design for comfort and situational awareness, combined with advanced audio technology.

Key Features:

- **Open-Ear Design:** Allows you to hear your surroundings while enjoying audio.
- **13mm Dynamic Drivers:** Deliver immersive sound with deep bass and crystal-clear highs.
- **Bluetooth 6.0:** Provides stable, low-latency wireless connectivity.
- **ENC Microphone:** Enhances call clarity by reducing background noise.
- **IPX6 Waterproof:** Resistant to sweat and rain, suitable for workouts and outdoor activities.
- **36 Hours Total Playtime:** 8 hours on a single charge, extended with the charging case.
- **Touch Control:** Intuitive controls for music, calls, and voice assistants.

Innovative Ergonomic Clip-On Design



Image: Illustrates the ergonomic clip-on design, adaptive fit, and directional audio technology of the earbuds.

13mm Dynamic Driver for Immersive Sound

Feel powerful bass &
crystal-clear highs. Hear
every detail



Image: Detailed view of the 13mm dynamic driver, emphasizing its role in delivering powerful bass and clear highs.

IPX6 Waterproof

Fear No Sweat or Rain
For Hiking / Running / Workouts



Image: Earbuds shown with water droplets, demonstrating their IPX6 waterproof capability.

Bluetooth 6.0

Lag-Free, Ultra-Stable Connection
Next-Gen Connectivity
For Seamless Music & Calls Everywhere



Image: An internal view of an earbud, illustrating the Bluetooth 6.0 technology for stable connectivity.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case, ensuring they are correctly seated.
2. Connect the charging case to a power source using the provided USB-C cable.
3. The indicator light on the charging case will show charging status. A full charge typically takes approximately 1.5-2 hours.
4. Once fully charged, disconnect the charging cable.

Power Through Day and Night

8 Hrs
Single Charge

36 Hrs
With Charging Case

36H



Image: Earbuds in their charging case, illustrating the battery life capabilities.

2. Bluetooth Pairing

Follow these steps to pair your earbuds with a Bluetooth-enabled device:

1. Open the charging case. The earbuds will automatically enter pairing mode, indicated by a flashing LED light on the earbuds.
2. On your device (smartphone, tablet, etc.), go to Bluetooth settings and ensure Bluetooth is enabled.
3. Search for available devices. Select "Monster Open Ear AC225" from the list.
4. Once connected, the LED indicator on the earbuds will turn off or show a solid light, and you will hear an audible confirmation.
5. If pairing fails, place the earbuds back in the case, close it, and repeat the steps.



Image: A smartphone screen showing successful Bluetooth connection to the Monster Open Ear AC225 earbuds.

OPERATING INSTRUCTIONS

1. Wearing the Earbuds

The AC225 earbuds are designed for a comfortable and secure open-ear fit. Gently clip them onto your ear, ensuring the speaker is positioned correctly over your ear canal for optimal sound delivery while keeping your ear open to ambient sounds.



Breathable Open-Ear

5.1g Ultra-Light Comfort,
All-Day Fit



Image: A person wearing the earbuds, demonstrating their comfortable and lightweight design.

2. Touch Controls

The earbuds feature intuitive touch controls on their outer surface. Refer to the diagram below for specific functions:

Simple Taps, Total Control




Image: A visual guide to the touch controls for various functions like calls, music, and volume.

- **Play/Pause:** Tap L/R earbud 2 times.
- **Next Song:** Tap R earbud 3 times.
- **Previous Song:** Tap L earbud 3 times.
- **Volume Up:** Tap R earbud 1 time.
- **Volume Down:** Tap L earbud 1 time.
- **Answer/End Call:** Tap L/R earbud 2 times.
- **Reject Call:** Press and hold L/R earbud for 2 seconds.
- **Activate Voice Assistant:** Press and hold L/R earbud for 2 seconds (when not on a call).

3. Call Functions

The built-in ENC microphone ensures clear communication during calls, even in noisy environments.

- **Answering/Ending Calls:** Use the touch controls as described above.
- **Rejecting Calls:** Use the touch controls as described above.

Crystal-Clear Calls

Built-in ENC Mic cancels 95% of background noise for perfect calls in crowds and during workouts.




Image: A user making a call in a busy environment, highlighting the effectiveness of the ENC microphone for clear calls.

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Avoid getting moisture into any openings.

Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place, away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Earbuds not turning on	Low battery	Place earbuds in the charging case and charge fully.
Cannot pair with device	Bluetooth off, earbuds not in pairing mode, device too far	Ensure Bluetooth is enabled on your device. Place earbuds in case, close, then open to re-enter pairing mode. Keep device within 1 meter.
No sound or low volume	Volume too low, earbuds not connected, incorrect audio output	Increase volume on both earbuds and connected device. Reconnect earbuds. Check device's audio output settings.
Intermittent connection	Interference, distance, low battery	Move closer to your device. Avoid areas with strong Wi-Fi or other Bluetooth signals. Charge earbuds.
Microphone not working	Microphone blocked, incorrect input device selected	Ensure microphone is not covered. Check device's audio input settings to confirm earbuds are selected.

Specifications

Feature	Detail
Model Name	Monster Open Ear AC225 Earbuds
Connectivity Technology	Wireless (Bluetooth 6.0)
Bluetooth Range	12 Meters
Audio Driver Size	13 Millimeters
Battery Life (Earbuds)	8 Hours (single charge)
Total Playtime (with Case)	36 Hours
Water Resistance Level	IPX6 (Waterproof)
Noise Control Features	Environmental Noise Cancellation (ENC)
Control Type	Touch Control
Earpiece Shape	Clip-On Earbuds
Item Weight	5.6 ounces (total package)
Material	Plastic
Included Components	Open Ear Buds, User Manual, Wireless Charging Case

Safety Information

- Do not disassemble or modify the product.
- Keep away from extreme temperatures, humidity, and corrosive substances.
- Avoid dropping or subjecting the earbuds to strong impacts.

- Do not use the earbuds at excessively high volumes for prolonged periods to prevent hearing damage.
- Be aware of your surroundings when using open-ear earbuds, especially in traffic or hazardous situations.
- Keep out of reach of children and pets.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Monster website or contact their customer service. Keep your purchase receipt for warranty claims.

Manufacturer: Monster

Date First Available: October 14, 2025

© 2025 Monster. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FV8RH1GN>

More documents and user manuals: <https://manuals.plus/>