

Tork 257021

Tork Constant Air Freshener Refill, Blossom A3 (Model 257021) - Instruction Manual

For use with Tork Constant Air Freshener Dispensers

1. PRODUCT OVERVIEW

The Tork Constant Air Freshener Refill in Blossom A3 scent is designed to maintain a consistently fresh and welcoming atmosphere in washrooms. This refill features a delicate floral fragrance combined with an odor neutralizer to eliminate unpleasant odors rather than just masking them. It is compatible with Tork Constant Air Freshener Dispensers.

Each refill is part of a propellant-free system, utilizing only scented oils for fragrance distribution. The system is certified as easy to use for refilling by the Swedish Rheumatism Association, ensuring effortless maintenance.

Up to
540
days of
constant
freshness



6 x
32 ml



118 mm x
111.7 mm

Image 1.1: Tork Constant Air Freshener Refill 6-pack, highlighting extended freshness duration.

Key Features:

- **Odor Neutralization:** Unique formulation actively neutralizes bad odors.
- **Constant Freshness:** Utilizes a unique distribution technology for a continuous fresh air flow.
- **Adjustable Duration:** Controlled delivery allows for dose adjustment to last 30, 60, or 90 days.
- **Easy Refilling:** Designed for simple and flexible refilling.
- **Non-Flammable & Non-Pressurized:** Safe propellant-free system.
- **Tork Vision Cleaning Compatible:** Supports efficient cleaning and refill management.

A welcoming, fresh scent with delicate floral notes and odor neutralizer



Image 1.2: Detailed view of the refill, illustrating its odor neutralizing and distribution features.

2. SETUP AND INSTALLATION

This refill is designed for use with Tork Constant Air Freshener Dispensers (A3 system). Ensure you have a compatible dispenser before proceeding with installation.

Compatible Dispensers:

The Tork Constant Air Freshener Refill (Model 257021) is compatible with Tork A3 system dispensers, such as the Tork Elevation line dispensers (Models 256021 and 256023).

A3

Compatible Tork dispensers

Elevation



256021



256023

Image 2.1: Examples of compatible Tork Elevation A3 dispensers.

Installation Steps:

1. **Open the Dispenser:** Locate the release button or key slot on your Tork Constant Air Freshener Dispenser and open the front cover.
2. **Remove Old Refill (if applicable):** If an old refill is present, carefully remove it from the dispenser.
3. **Insert New Refill:** Align the new Tork Constant Air Freshener Refill (Blossom A3) with the designated slot inside the dispenser. Push it firmly until it clicks into place.
4. **Close the Dispenser:** Close the front cover of the dispenser securely. Ensure it latches properly.

Controlled delivery - Adjustable dose size to last up to 90 days

Designed to deliver a constant, pleasant experience



Image 2.2: Illustration of inserting the refill into the dispenser.

3. OPERATION AND SCENT DURATION ADJUSTMENT

The Tork Constant Air Freshener system allows for adjustment of the scent delivery duration to meet specific needs, offering options for 30, 60, or 90 days of continuous freshness.

Adjusting Scent Duration:

Refer to your Tork Constant Air Freshener Dispenser's specific instructions for adjusting the scent intensity and duration settings. Typically, this involves a dial or switch located within the dispenser unit. Select the desired duration (30, 60, or 90 days) based on room size and desired fragrance level.

- **30-Day Setting:** Provides a higher intensity of fragrance for a shorter period.

- **60-Day Setting:** Offers a balanced fragrance intensity and duration.
- **90-Day Setting:** Delivers a milder fragrance over an extended period.

Once the setting is chosen, the dispenser will automatically release the fragrance at a constant rate until the refill is depleted.

4. MAINTENANCE

Refill Replacement:

The Tork Constant Air Freshener Refill should be replaced when the scent diminishes or after the selected duration (30, 60, or 90 days) has passed. The dispenser may have an indicator to signal when a refill is low or empty.

1. Open the dispenser cover.
2. Remove the empty refill cartridge.
3. Dispose of the empty cartridge responsibly according to local regulations.
4. Insert a new Tork Constant Air Freshener Refill as described in the "Setup and Installation" section.
5. Close the dispenser cover.

Certified Easy to use for effortless refilling*



Flexible placement

Constant freshness

*Certified by the Swedish Rheumatism association, tested according to The Design for All Test, published in the Swedish Design Research Journal, 2011

Image 4.1: Demonstrating the easy refilling process of the Tork dispenser.

Dispenser Cleaning:

Periodically clean the exterior of your Tork dispenser with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the dispenser's finish.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
No scent or very faint scent.	• Refill is empty. • Refill not installed correctly. • Dispenser setting is too low or for a longer duration.	• Replace with a new refill. • Ensure the refill is firmly clicked into place. • Adjust the dispenser setting to a shorter duration (e.g., 30 days) for stronger scent.

Problem	Possible Cause	Solution
Scent is too strong.	Dispenser setting is too high or for a shorter duration.	Adjust the dispenser setting to a longer duration (e.g., 90 days) for a milder scent.
Dispenser not working.	Dispenser malfunction.	Refer to your Tork dispenser's specific instruction manual or contact Tork customer support.

6. SPECIFICATIONS

Brand	Tork
Model Number	257021
Scent	Blossom
Item Form	Pod
Area Odor Remover Type	Area Deodorizer
Recommended Uses	Room
Number of Items (per pack)	6
Unit Count	6.0 Count (32mL each)
Package Dimensions	9.02 x 7.56 x 5.16 inches
Weight	2.34 Pounds
Manufacturer	Essity North America Inc.

7. SAFETY INFORMATION

Please read and follow all safety instructions to ensure safe use of the Tork Constant Air Freshener Refill:

- **Keep Out of Reach of Children and Pets:** Store the refills in a secure location inaccessible to children and animals.
- **Avoid Direct Contact:** Do not allow the liquid contents to come into direct contact with skin, eyes, or clothing. In case of contact, rinse thoroughly with water. If irritation persists, seek medical attention.
- **Do Not Ingest:** The product is not for consumption. If ingested, seek immediate medical advice.
- **Ventilation:** Use in well-ventilated areas.
- **Flammability:** While the product is propellant-free and not classified as flammable, keep away from open flames and high heat sources.
- **Disposal:** Dispose of empty refills according to local waste disposal regulations.

8. CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your Tork Constant Air Freshener Refill or dispenser, please

contact Tork customer support. Refer to the contact information provided with your Tork dispenser or visit the official Tork website for support details.

Manufacturer: Essity North America Inc.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question