

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ULANZI](#) /

› [ULANZI MT85 Automatic Phone Tripod User Manual](#)

ULANZI MT85

ULANZI MT85 Automatic Phone Tripod User Manual

Model: MT85

PRODUCT OVERVIEW

The Ulanzi MT85 is an automatic phone tripod and extendable selfie stick designed for content creation, vlogging, and general smartphone photography. It features an innovative auto-open mechanism, a stable four-leg design, a strong dual-side magnetic phone mount, and a detachable wireless remote control.

Key Features:

- **Automatic Pop-up Tripod Legs:** Legs deploy automatically upon contact with a surface.
- **Enhanced Four-Leg Support:** Provides superior stability compared to traditional three-leg designs.
- **60-inch (1.5m) Extendable Pole:** Adjustable height for various shooting scenarios, from desktop to full-body shots.
- **Dual-Side Magnetic Phone Mount:** Securely holds MagSafe-compatible phones and allows attachment of accessories.
- **Detachable Wireless Remote:** Control your phone's camera from up to 10 meters away.
- **Multi-Axis Folding and Rotation:** Offers flexible angle adjustments for optimal framing.
- **Lightweight and Portable:** Weighs only 385g for easy transport.

PACKAGE CONTENTS

- Ulanzi MT85 Automatic Phone Tripod (Selfie Stick) x 1
- Magnetic Ring x 1 (for non-MagSafe compatible phones)
- User Manual x 1

MT85 Automatic Phone Tripod(Magsafe)

Hands-Free Opening with Every Drop



Figure 1: Included items in the ULANZI MT85 package.

SETUP INSTRUCTIONS

1. Deploying the Tripod Legs

1. Hold the tripod vertically with the base facing downwards.
2. Gently drop the tripod onto a flat, stable surface. The four legs will automatically pop open and lock into position.
3. Ensure all four legs are fully extended and stable before attaching your device.



Figure 2: Automatic leg deployment.

2. Extending the Pole

1. Hold the base of the tripod firmly.
2. Grasp the top section of the pole and pull upwards to extend it. The pole has multiple sections that can be extended to reach a maximum height of 60 inches (1.5 meters).
3. Twist each section clockwise to lock it in place, or counter-clockwise to unlock for adjustment.



Figure 3: Tripod extended to maximum height.

3. Attaching Your Phone

The MT85 features a dual-side magnetic mount. Ensure your phone is MagSafe compatible or use the provided magnetic ring.

- **For MagSafe Compatible Phones:** Simply align your phone with the magnetic mount on the front side until it snaps securely into place.
- **For Non-MagSafe Phones:** Attach the included magnetic ring to the back of your phone or phone case. Then, align your phone with the magnetic mount.
- The reverse side of the magnetic mount can be used to attach additional accessories.




Figure 4: Dual-side magnetic phone mount.

4. Pairing the Wireless Remote

1. Locate the detachable remote control on the tripod handle. Slide it down and out to remove it.
2. Turn on the remote control (usually by pressing and holding a button).
3. On your smartphone, go to Bluetooth settings and search for available devices.
4. Select "ULANZI Remote" or a similar name to pair. Once paired, the remote's indicator light will confirm connection.



Figure 5: Detachable wireless remote control.

OPERATING INSTRUCTIONS

1. Adjusting Shooting Angles

The magnetic mount offers multi-axis folding and rotation for precise angle adjustments.

- **Tilt Adjustment:** The phone mount can be tilted up to 315 degrees.
- **Height Adjustment:** The arm connecting the mount to the pole can be adjusted up to 175 degrees.
- **Rotation:** The base of the phone mount can rotate 160 degrees.
- Carefully adjust these points to achieve your desired shooting angle.



Figure 6: Flexible angle adjustments.

2. Using as a Selfie Stick

1. Ensure the tripod legs are folded and secured.
2. Extend the pole to your desired length.
3. Hold the handle firmly and use the detached wireless remote to capture photos or videos.

Figure 7: Selfie stick mode.

3. Using as a Desktop Tripod

1. Deploy the tripod legs as described in the setup section.
2. Keep the pole at its shortest length or extend it slightly for a stable desktop setup.
3. Adjust the phone mount angle as needed for video calls, streaming, or tabletop content creation.




Figure 8: Desktop tripod mode.

MAINTENANCE

- **Cleaning:** Wipe the tripod with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the tripod in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the legs are folded and the pole is retracted for compact storage.
- **Remote Battery:** The wireless remote is rechargeable. Recharge it using a standard USB charging cable (not included) when the battery is low.
- **Magnetic Ring:** If using the magnetic ring, ensure it is securely attached to your phone or case for optimal magnetic hold.

TROUBLESHOOTING

- **Tripod legs do not deploy automatically:**

Ensure the tripod is dropped onto a flat, firm surface. If the issue persists, gently pull the legs outwards manually until they click into place.

- **Pole sections are difficult to extend/retract:**

Ensure all twist-locks are in the unlocked position before attempting to extend or retract. Do not force the sections.

- **Phone does not attach securely to the magnetic mount:**

Verify your phone is MagSafe compatible. If not, ensure the magnetic ring is correctly and securely attached to your phone or case. Remove any thick cases that might interfere with the magnetic connection.

- **Wireless remote not pairing or functioning:**

Ensure the remote is charged and turned on. Check your phone's Bluetooth settings to ensure it's discoverable and try re-pairing. If the remote has been idle for a long time, it might need a full charge.

- **Tripod feels unstable at maximum height:**

While designed for stability, extreme heights can introduce slight movement. Ensure the tripod is on a perfectly flat and stable surface. Avoid using in windy conditions when fully extended. For maximum stability, use at lower heights.

SPECIFICATIONS

Model Number	MT85
Brand	ULANZI
Material	Aluminum
Maximum Height	150 Centimeters (60 inches)
Number of Leg Sections	4
Item Weight	1.04 pounds (approx. 472g)
Special Features	Automatic open, 4 legs support, Angle adjustable, Magnetic mount, Wireless remote
Compatible Devices	Smartphones (iPhone 12/13/14/15/16/17 and Android with magnetic ring)

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact the seller directly. For technical support or further assistance, please reach out to Ulanzi customer service through their official website or the platform where the product was purchased.